



PROGRAMMING MANUAL

TJ1-MC04
TJ1-MC16

Trajexia motion control system

OMRON

152E-EN-04
Cat. No.

Notice

OMRON products are manufactured for use according to proper procedures by a qualified operator and only for the purposes described in this manual. The following conventions are used to indicate and classify precautions in this manual. Always heed the information provided with them. Failure to heed precautions can result in injury to people or damage to property.

Definition of precautionary information



WARNING

Indicates a potentially hazardous situation, which, if not avoided, could result in death or serious injury.



Caution

Indicates a potentially hazardous situation, which, if not avoided, may result in minor or moderate injury, or property damage.

Trademarks and Copyrights

PROFIBUS is a registered trademark of PROFIBUS International.

MECHATROLINK is a registered trademark of Yaskawa Corporation.

DeviceNet is a registered trademark of Open DeviceNet Vendor Assoc INC.

CIP is a registered trademark of Open DeviceNet Vendor Assoc INC.

CANopen is a registered trademark of CAN in Automation (CiA).

ModbusTCP is a registered trademark of Modbus IDA.

Trajexia is a registered trademark of OMRON.

Motion Perfect is a registered trademark of Trio Motion Technology Ltd.

All other product names, company names, logos or other designations mentioned herein are trademarks of their respective owners.

© OMRON, 2008

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.

No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

About this manual

This manual describes the installation and operation of the Trajexia Motion Control System.

Please read this manual and the related manuals listed in the following table carefully and be sure you understand the information provided before attempting to install or operate the Trajexia Motion Control units. Be sure to read the precautions provided in the following section.

Name	Cat. No.	Contents
Trajexia motion control system QUICK START GUIDE	I50E	Describes how to get quickly familiar with Trajexia, moving a single axis using MECHATROLINK-II, in a test set-up.
Trajexia motion control system HARDWARE REFERENCE MANUAL	I51E	Describes the installation and hardware specification of the Trajexia units, and explains the Trajexia system philosophy.
Trajexia motion control system PROGRAMMING MANUAL	I52E	Describes the BASIC commands to be used for programming Trajexia, communication protocols and Trajexia Tools software, gives practical examples and troubleshooting information.
Sigma-II Servo Driver manual	SIEP S800000 15	Describes the installation and operation of Sigma-II Servo Drivers
Sigma-III with MECHATROLINK interface manual	SIEP S800000 11	Describes the installation and operation of Sigma-III Servo Drivers with MECHATROLINK-II interface
Sigma-V Servo Driver manual	SIEP S800000-44-O-OY SIEP S800000-46-O-OY SIEP S800000-48-O-OY	Describes the installation and operation of Sigma-V Servo Drivers
JUNMA series servo drive manual	TOEP-C71080603 01-OY	Describes the installation and operation of JUNMA Servo Drivers

Name	Cat. No.	Contents
V7 Inverter	TOEP C71060605 02-OY	Describes the installation and operation of V7 Inverters
F7Z Inverter	TOE S616-55 1-OY	Describes the installation and operation of F7Z Inverters
G7 Inverter	TOE S616-60	Describes the installation and operation of G7 Inverters
JUSP-NS115 manual	SIEP C71080001	Describes the installation and operation of the MECHATROLINK-II application module
SI-T MECHATROLINK interface for the G7 & F7	SIBP-C730600-08	Describes the installation and operation of MECHATROLINK-II interfaces for G7 and F7 Inverters
ST-T/V7 MECHATROLINK interface for the V7	SIBP-C730600-03	Describes the installation and operation of MECHATROLINK-II interfaces for V7 Inverters
MECHATROLINK IO Modules	SIE C887-5	Describes the installation and operation of MECHATROLINK-II input and output modules and the MECHATROLINK-II repeater
SYSMAC CS/CJ Series Communications Commands	W342	Describes FINS communications protocol and FINS commands
Omron Smartslice GRT1-Series, slice I/O units, Operation manual	W455-E1	Describes the installation and operation of Omron slice I/O units



WARNING

Failure to read and understand the information provided in this manual may result in personal injury or death, damage to the product, or product failure. Please read each section in its entirety and be sure you understand the information provided in the section and related sections before attempting any of the procedures or operations given.

Functions supported by unit versions

During the development of Trajexia new functionality was added to the controller unit after market release.

This functionality is implemented in the firmware, and/or the FPGA of the controller unit.

In the table below, the overview of the applicable functionality is shown related to the firmware and FPGA version of the TJ1-MC__.

Functionality	TJ1-MC__ Firmware version	TJ1-MC__ FPGA version
Full support TJ1-FL02	V1.6509	21 and higher
Support BASIC commands FINS_COMMS	V1.6509	All versions
Support TJ1-DRT	V1.6509	All versions
Support TJ1-MC04 and TJ1-ML04	V1.6607	21 and higher
Support TJ1-CORT, GRT1- ML2, ModbusTCP, Sigma-V series Servo Drivers (except DATUM and REGIST BASIC commands) and allow Inverters to be controlled as servo axes	V1.6652	21 and higher

Verify the firmware and FPGA versions of the TJ1-MC__

Connect the TJ1-MC__ to Trajexia Tools software. Refer to the Programming Manual.

Open the terminal window and type the following commands:

Type `PRINT VERSION` in the terminal window. The version parameter returns the current firmware version number of the motion controller.

Type `PRINT FPGA_VERSION SLOT(-1)` in the terminal window. The parameter returns the current FPGA version number of the TJ1-MC__.

1 Safety warnings and precautions	16
1.1 Intended audience	16
1.2 General precautions	16
1.3 Safety precautions	16
1.4 Operating environment precautions	17
1.5 Application precautions	18
1.6 Unit assembly precautions	20
2 Trajexia system	21
2.1 Introduction	21
2.1.1 Trajexia hardware	21
2.1.2 This manual	22
2.2 Multitasking BASIC programming	22
2.3 BASIC programming	23
2.3.1 Axis, system and task statements	23
2.3.2 Memory areas	23
2.3.3 Data structures and variables	24
2.3.4 Mathematical specifications	26
2.4 Motion execution	27
2.5 Command line interface	28
2.6 BASIC programs	28
2.6.1 Managing programs	28
2.6.2 Program compilation	29
2.6.3 Program execution	29
3 BASIC commands	31
3.1 Categories	31
3.1.1 Axis commands	31
3.1.2 Axis parameters	32
3.1.3 Communication commands and parameters	34
3.1.4 Constants	34
3.1.5 I/O commands, functions and parameters	34
3.1.6 Mathematical functions and operands	35
3.1.7 Program commands	35
3.1.8 Program control commands	36
3.1.9 Slot parameters and modifiers	36
3.1.10 System commands and functions	36
3.1.11 System parameters	37
3.1.12 Task commands and parameters	38
3.2 All BASIC commands	39

3.2.1	+ (Addition)	39
3.2.2	- (Subtraction)	39
3.2.3	* (Multiplication)	39
3.2.4	/ (Division)	39
3.2.5	^ (Power)	40
3.2.6	= (Is equal to)	40
3.2.7	= (Assignment)	40
3.2.8	<> (Is not equal to)	40
3.2.9	> (Is greater than)	41
3.2.10	>= (Is greater than or equal to)	41
3.2.11	< (Is less than)	41
3.2.12	<= (Is less than or equal to)	41
3.2.13	\$ (Hexadecimal input)	42
3.2.14	' (Comment field)	42
3.2.15	: (Statement separator)	42
3.2.16	#	42
3.2.17	ABS	43
3.2.18	ACC	43
3.2.19	ACCEL	43
3.2.20	ACOS	43
3.2.21	ADD_DAC	44
3.2.22	ADDAX	45
3.2.23	ADDAX_AXIS	49
3.2.24	AIN	49
3.2.25	ALL	49
3.2.26	AND	50
3.2.27	AOUT	50
3.2.28	ASIN	50
3.2.29	ATAN	50
3.2.30	ATAN2	51
3.2.31	ATYPE	51
3.2.32	AUTORUN	51
3.2.33	AXIS	52
3.2.34	AXIS_DISPLAY	52
3.2.35	AXIS_ENABLE	52
3.2.36	AXISSTATUS	53
3.2.37	B_SPLINE	53
3.2.38	BACKLASH	54
3.2.39	BACKLASH_DIST	54
3.2.40	BASE	54

3.2.41	BASICERROR	55
3.2.42	BATTERY_LOW	56
3.2.43	BREAK_RESET	56
3.2.44	CAM	56
3.2.45	CAMBOX	62
3.2.46	CAN_CORT	70
3.2.47	CANCEL	71
3.2.48	CHECKSUM	73
3.2.49	CHR	73
3.2.50	CLEAR	73
3.2.51	CLEAR_BIT	73
3.2.52	CLEAR_PARAMS	73
3.2.53	CLOSE_WIN	74
3.2.54	CLUTCH_RATE	74
3.2.55	COMMSError	74
3.2.56	COMMSTYPE	75
3.2.57	COMPILE	75
3.2.58	CONNECT	76
3.2.59	CONSTANT	78
3.2.60	CONTROL	78
3.2.61	COPY	78
3.2.62	COS	78
3.2.63	CREEP	79
3.2.64	D_GAIN	79
3.2.65	D_ZONE_MAX	79
3.2.66	D_ZONE_MIN	80
3.2.67	DAC	80
3.2.68	DAC_OUT	80
3.2.69	DAC_SCALE	80
3.2.70	DATE	80
3.2.71	DATE\$	81
3.2.72	DATUM	81
3.2.73	DATUM_IN	86
3.2.74	DAY	86
3.2.75	DAY\$	86
3.2.76	DECEL	86
3.2.77	DEFPOS	87
3.2.78	DEL	90
3.2.79	DEMAND_EDGES	90
3.2.80	DEVICENET	90

Contents

3.2.81	DIR	91
3.2.82	DISABLE_GROUP	92
3.2.83	DISPLAY	94
3.2.84	DPOS	94
3.2.85	DRIVE_ALARM	95
3.2.86	DRIVE_CLEAR	95
3.2.87	DRIVE_CONTROL	96
3.2.88	DRIVE_INPUTS	96
3.2.89	DRIVE_MONITOR	97
3.2.90	DRIVE_READ	97
3.2.91	DRIVE_RESET	98
3.2.92	DRIVE_STATUS	98
3.2.93	DRIVE_WRITE	99
3.2.94	EDIT	100
3.2.95	ELSE	100
3.2.96	ELSEIF	100
3.2.97	ENCODER	100
3.2.98	ENCODER_BITS	100
3.2.99	ENCODER_CONTROL	101
3.2.100	ENCODER_ID	101
3.2.101	ENCODER_RATIO	101
3.2.102	ENCODER_READ	102
3.2.103	ENCODER_STATUS	102
3.2.104	ENCODER_TURNS	102
3.2.105	ENCODER_WRITE	103
3.2.106	ENDIF	103
3.2.107	ENDMOVE	103
3.2.108	EPROM	103
3.2.109	ERROR_AXIS	103
3.2.110	ERROR_LINE	104
3.2.111	ERRORMASK	104
3.2.112	ETHERNET	104
3.2.113	EX	105
3.2.114	EXP	105
3.2.115	FALSE	105
3.2.116	FAST_JOG	105
3.2.117	FASTDEC	106
3.2.118	FE	106
3.2.119	FE_LATCH	106
3.2.120	FE_LIMIT	106

3.2.121	FE_LIMIT_MODE	107
3.2.122	FE_RANGE	107
3.2.123	FHOLD_IN	107
3.2.124	FHSPEED	107
3.2.125	FINS_COMMES	108
3.2.126	FLAG	109
3.2.127	FLAGS	110
3.2.128	FOR..TO..STEP..NEXT	110
3.2.129	FORWARD	112
3.2.130	FPGA_VERSION	114
3.2.131	FRAC	114
3.2.132	FRAME	114
3.2.133	FREE	114
3.2.134	FS_LIMIT	115
3.2.135	FWD_IN	115
3.2.136	FWD_JOG	115
3.2.137	GET	115
3.2.138	GLOBAL	116
3.2.139	GOSUB..RETURN	116
3.2.140	GOTO	117
3.2.141	HALT	117
3.2.142	HEX	117
3.2.143	HLM_COMMAND	117
3.2.144	HLM_READ	119
3.2.145	HLM_STATUS	120
3.2.146	HLM_TIMEOUT	121
3.2.147	HLM_WRITE	122
3.2.148	HLS_NODE	123
3.2.149	HW_PSWITCH	123
3.2.150	I_GAIN	124
3.2.151	IDLE	124
3.2.152	IEEE_IN	124
3.2.153	IEEE_OUT	124
3.2.154	IF..THEN..ELSE..ENDIF	124
3.2.155	IN	125
3.2.156	INDEVICE	126
3.2.157	INITIALISE	126
3.2.158	INPUT	126
3.2.159	INT	127
3.2.160	INVERT_IN	127

3.2.161 INVERT_STEP	127
3.2.162 INVERTER_COMMAND	128
3.2.163 INVERTER_READ	129
3.2.164 INVERTER_WRITE	130
3.2.165 JOGSPEED	131
3.2.166 KEY	131
3.2.167 LAST_AXIS	132
3.2.168 LINKAX	132
3.2.169 LINPUT	132
3.2.170 LIST	133
3.2.171 LIST_GLOBAL	133
3.2.172 LN	134
3.2.173 LOCK	134
3.2.174 MARK	134
3.2.175 MARKB	134
3.2.176 MECHATROLINK	135
3.2.177 MERGE	135
3.2.178 MHELICAL	137
3.2.179 MOD	140
3.2.180 MOTION_ERROR	140
3.2.181 MOVE	140
3.2.182 MOVEABS	142
3.2.183 MOVECIRC	145
3.2.184 MOVELINK	148
3.2.185 MOVEMODIFY	153
3.2.186 MPOS	156
3.2.187 MSPEED	156
3.2.188 MTYPE	156
3.2.189 NAI0	157
3.2.190 NEG_OFFSET	157
3.2.191 NEW	157
3.2.192 NEXT	157
3.2.193 NIO	157
3.2.194 NOT	158
3.2.195 NTYPE	158
3.2.196 OFF	158
3.2.197 OFFPOS	159
3.2.198 ON	161
3.2.199 ON.. GOSUB	161
3.2.200 ON.. GOTO	161

3.2.201 OP	161
3.2.202 OPEN_WIN	162
3.2.203 OR	162
3.2.204 OUTDEVICE.....	163
3.2.205 OUTLIMIT.....	163
3.2.206 OV_GAIN.....	164
3.2.207 P_GAIN.....	164
3.2.208 PI.....	164
3.2.209 PMOVE.....	164
3.2.210 POS_OFFSET.....	165
3.2.211 POWER_UP	165
3.2.212 PRINT	165
3.2.213 PROC	166
3.2.214 PROC_STATUS.....	166
3.2.215 PROCESS	166
3.2.216 PROCNUMBER.....	167
3.2.217 PROFIBUS	167
3.2.218 PSWITCH.....	167
3.2.219 RAPIDSTOP.....	169
3.2.220 READ_BIT	171
3.2.221 READ_OP	171
3.2.222 REG_POS	171
3.2.223 REG_POSB.....	172
3.2.224 REGIST	173
3.2.225 REMAIN.....	179
3.2.226 REMOTE_ERROR.....	179
3.2.227 RENAME	179
3.2.228 REP_DIST	179
3.2.229 REP_OPTION	180
3.2.230 REPEAT..UNTIL.....	180
3.2.231 RESET.....	181
3.2.232 RETURN.....	181
3.2.233 REV_IN	181
3.2.234 REV_JOG	181
3.2.235 REVERSE	182
3.2.236 RS_LIMIT	184
3.2.237 RUN.....	184
3.2.238 RUN_ERROR.....	184
3.2.239 RUNTYPE	186
3.2.240 S_REF	187

3.2.241 S_REF_OUT	187
3.2.242 SCOPE	187
3.2.243 SCOPE_POS	188
3.2.244 SELECT	188
3.2.245 SERVO	188
3.2.246 SERVO_PERIOD	189
3.2.247 SET_BIT	189
3.2.248 SETCOM	189
3.2.249 SGN	190
3.2.250 SIN	190
3.2.251 SLOT	190
3.2.252 SPEED	191
3.2.253 SPEED_SIGN	191
3.2.254 SQR	191
3.2.255 SRAMP	191
3.2.256 STEP	192
3.2.257 STEP_RATIO	192
3.2.258 STEPLINE	193
3.2.259 STOP	193
3.2.260 SYSTEM_ERROR	193
3.2.261 T_REF	194
3.2.262 TABLE	194
3.2.263 TABLEVALUES	195
3.2.264 TAN	195
3.2.265 THEN	195
3.2.266 TICKS	195
3.2.267 TIME	196
3.2.268 TIME\$	196
3.2.269 TO	196
3.2.270 TRANS_DPOS	196
3.2.271 TRIGGER	196
3.2.272 TROFF	197
3.2.273 TRON	197
3.2.274 TRUE	197
3.2.275 TSIZE	198
3.2.276 UNITS	198
3.2.277 UNLOCK	198
3.2.278 UNTIL	198
3.2.279 VERIFY	198
3.2.280 VERSION	199

3.2.281 VFF_GAIN	199
3.2.282 VP_SPEED.....	199
3.2.283 VR.....	199
3.2.284 VRSTRING	200
3.2.285 WA.....	200
3.2.286 WAIT IDLE.....	200
3.2.287 WAIT LOADED.....	201
3.2.288 WAIT UNTIL	201
3.2.289 WDOG	202
3.2.290 WHILE..WEND	202
3.2.291 XOR.....	202

4 Communication protocols	204
4.1 Available interfaces.....	204
4.2 Ethernet	204
4.2.1 Communicate with Trajexia directly from your computer	205
4.2.2 Communicate with Trajexia remotely	207
4.2.3 Trajexia Tools protocol	208
4.2.4 FINS server protocol	208
4.2.5 FINS client protocol	210
4.2.6 ModbusTCP protocol.....	210
4.3 Serial protocol	211
4.3.1 Host Link master	211
4.3.2 Host Link slave	216
4.3.3 User-defined protocol	218
4.4 PROFIBUS	219
4.4.1 Introduction.....	219
4.4.2 Communication set-up.....	219
4.4.3 Communication Status	224
4.5 DeviceNet	224
4.5.1 Introduction.....	224
4.5.2 Communication set-up.....	225
4.5.3 Communication Status	229
4.6 CANopen	230
4.6.1 Communication setup.....	230
4.6.2 Communication status	232
4.6.3 Communication operation.....	233
4.7 MECHATROLINK-II	233
4.8 GRT1-ML2 I/O mapping	234
4.8.1 Unit numbers	234

4.8.2	SmartSlice I/O mapping	234
4.8.3	GRT1-ML2 status word	238
4.8.4	Table registration.....	239
5	Trajexia Tools interface	241
5.1	Introduction	241
5.2	Specifications and connections	241
5.2.1	PC Specifications	241
5.2.2	Install the Trajexia Tools software	242
5.2.3	Connection to the TJ1-MC.....	247
5.3	Projects	251
5.3.1	Trajexia Tools Projects	251
5.3.2	Check Project window	252
5.4	Trajexia Tools application window	254
5.4.1	Control panel	254
5.4.2	Menu bar	254
5.4.3	Toolbar	255
5.5	Menu descriptions	256
5.5.1	Project menu	256
5.5.2	Controller menu	258
5.5.3	Program menu	262
5.5.4	Tools menu	264
5.5.5	Options menu	279
5.5.6	Windows Menu	282
5.5.7	Help Menu	282
6	Examples and tips	283
6.1	How-to's.....	283
6.1.1	Startup program	283
6.1.2	Gain settings	287
6.1.3	Setting the UNITS axis parameter and gear ratio.....	296
6.1.4	Mapping Servo Driver inputs and outputs	309
6.1.5	Origin search	312
6.1.6	Registration	319
6.1.7	Tracing and monitoring.....	327
6.2	Practical examples.....	336
6.2.1	Shell program	336
6.2.2	Initialization program	349
6.2.3	Single axis program	352
6.2.4	Position with product detection	353
6.2.5	Position on a grid	354

6.2.6	Bag feeder program	356
6.2.7	CAM table inside a program	359
6.2.8	Flying shear program	360
6.2.9	Correction program	363
7	Troubleshooting.....	365
7.1	Voltage and analysis tools	365
7.2	TJ1-MC.....	365
7.2.1	System errors	365
7.2.2	Axis errors	365
7.2.3	Unit errors.....	366
7.2.4	Configuration errors.....	367
7.2.5	Replace the battery	367
7.3	TJ1-PRT	368
7.3.1	System errors	368
7.3.2	I/O data communication problems.....	368
7.4	TJ1-DRT	369
7.4.1	System errors	369
7.4.2	I/O data communication problems.....	369
7.5	TJ1-CORT	369
7.5.1	System errors	369
7.5.2	I/O data communication problems.....	369
7.6	TJ1-ML.....	370
7.6.1	System errors	370
7.6.2	Bus errors	370
7.7	GRT1-ML2	370
7.7.1	Unit power supply errors.....	371
7.7.2	I/O power supply errors	371
7.7.3	Unit errors.....	371
7.7.4	SmartSlice I/O errors	372
7.7.5	MECHATROLINK-II initialization errors.....	373
7.8	TJ1-FL02	373
7.8.1	System errors	373
A	GRT1-ML2 timing	374
A.1	Timing concepts.....	374
A.1.1	Refresh cycles	374
A.1.2	Paging	375
A.2	Examples	376
A.2.1	Example 1.....	378
A.2.2	Example 2.....	378

1 Safety warnings and precautions

1.1 Intended audience

This manual is intended for personnel with knowledge of electrical systems (electrical engineers or the equivalent) who are responsible for the design, installation and management of factory automation systems and facilities.

1.2 General precautions

The user must operate the product according to the performance specifications described in this manual.

Before using the product under conditions which are not described in the manual or applying the product to nuclear control systems, railroad systems, aviation systems, vehicles, safety equipment, petrochemical plants, and other systems, machines and equipment that can have a serious influence on lives and property if used improperly, consult your OMRON representative.

1.3 Safety precautions



WARNING

Do not attempt to take the Unit apart and do not touch any of the internal parts while power is being supplied.

Doing so may result in electrical shock.



WARNING

Do not touch any of the terminals or terminal blocks while power is being supplied.

Doing so may result in electric shock.



WARNING

Never short-circuit the positive and negative terminals of the batteries, charge the batteries, disassemble them, deform them by applying pressure, or throw them into a fire.
The batteries may explode, combust or leak liquid.



WARNING

Fail-safe measures must be taken by the customer to ensure safety in the event of incorrect, missing, or abnormal signals caused by broken signal lines, momentary power interruptions, or other causes.

Not doing so may result in serious accidents.



WARNING

Emergency stop circuits, interlock circuits, limit circuits, and similar safety measures must be provided by the customer as external circuits, i.e., not in the Trajexia motion controller.

Not doing so may result in serious accidents.



WARNING

When the 24-VDC output (I/O power supply to the TJ1) is overloaded or short-circuited, the voltage may drop and result in the outputs being turned off. As a countermeasure for such problems, external safety measures must be provided to ensure safety in the system.



WARNING

The TJ1 outputs will go off due to overload of the output transistors (protection). As a countermeasure for such problems, external safety measures must be provided to ensure safety in the system.

**WARNING**

The TJ1 will turn off the WDOG when its self-diagnosis function detects any error. As a countermeasure for such errors, external safety measures must be provided to ensure safety in the system.

**WARNING**

Provide safety measures in external circuits, i.e., not in the Trajexia Motion Controller (referred to as "TJ1"), in order to ensure safety in the system if an abnormality occurs due to malfunction of the TJ1 or another external factor affecting the TJ1 operation. Not doing so may result in serious accidents.

**WARNING**

Do not attempt to disassemble, repair, or modify any Units. Any attempt to do so may result in malfunction, fire, or electric shock.

**Caution**

Confirm safety at the destination unit before transferring a program to another unit or editing the memory. Doing either of these without confirming safety may result in injury.

**Caution**

User programs written to the Motion Control Unit will not be automatically backed up in the TJ1 flash memory (flash memory function).

**Caution**

Pay careful attention to the polarity (+/-) when wiring the DC power supply. A wrong connection may cause malfunction of the system.

**Caution**

Tighten the screws on the terminal block of the Power Supply Unit to the torque specified in this manual. Loose screws may result in burning or malfunction.

1.4**Operating environment precautions****Caution**

Do not operate the Unit in any of the following locations. Doing so may result in malfunction, electric shock, or burning.

- Locations subject to direct sunlight.
- Locations subject to temperatures or humidity outside the range specified in the specifications.
- Locations subject to condensation as the result of severe changes in temperature.
- Locations subject to corrosive or flammable gases.
- Locations subject to dust (especially iron dust) or salts.
- Locations subject to exposure to water, oil, or chemicals.
- Locations subject to shock or vibration.

**Caution**

Take appropriate and sufficient countermeasures when installing systems in the following locations.

Inappropriate and insufficient measures may result in malfunction.

- Locations subject to static electricity or other forms of noise.
- Locations subject to strong electromagnetic fields.
- Locations subject to possible exposure to radioactivity.
- Locations close to power supplies.

**Caution**

The operating environment of the TJ1 System can have a large effect on the longevity and reliability of the system. Improper operating environments can lead to malfunction, failure, and other unforeseeable problems with the TJ1 System. Make sure that the operating environment is within the specified conditions at installation and remains within the specified conditions during the life of the system.

1.5 Application precautions

**WARNING**

Do not start the system until you check that the axes are present and of the correct type. The numbers of the Flexible axes will change if MECHATROLINK-II network errors occur during start-up or if the MECHATROLINK-II network configuration changes.

**WARNING**

Check the user program for proper execution before actually running it in the Unit. Not checking the program may result in an unexpected operation.

**Caution**

Always use the power supply voltage specified in this manual. An incorrect voltage may result in malfunction or burning.

**Caution**

Take appropriate measures to ensure that the specified power with the rated voltage and frequency is supplied. Be particularly careful in places where the power supply is unstable. An incorrect power supply may result in malfunction.

**Caution**

Install external breakers and take other safety measures against short-circuiting in external wiring. Insufficient safety measures against short-circuiting may result in burning.

**Caution**

Do not apply voltage to the Input Units in excess of the rated input voltage. Excess voltage may result in burning.

**Caution**

Do not apply voltage or connect loads to the Output Units in excess of the maximum switching capacity. Excess voltage or loads may result in burning.

**Caution**

Disconnect the functional ground terminal when performing withstand voltage tests. Not disconnecting the functional ground terminal may result in burning.

**Caution**

Always connect to a class-3 ground (to 100Ω or less) when installing the Units.
Not connecting to a class-3 ground may result in electric shock.

**Caution**

Always turn off the power supply to the system before attempting any of the following.
Not turning off the power supply may result in malfunction or electric shock.

- Mounting or dismounting expansion Units, CPU Units, or any other Units.
- Assembling the Units.
- Setting dipswitches or rotary switches.
- Connecting or wiring the cables.
- Connecting or disconnecting the connectors.

**Caution**

Be sure that all mounting screws, terminal screws, and cable connector screws are tightened to the torque specified in this manual.
Incorrect tightening torque may result in malfunction.

**Caution**

Leave the dust protective label attached to the Unit when wiring.
Removing the dust protective label may result in malfunction.

**Caution**

Remove the dust protective label after the completion of wiring to ensure proper heat dissipation.
Leaving the dust protective label attached may result in malfunction.

**Caution**

Use crimp terminals for wiring. Do not connect bare stranded wires directly to terminals.
Connection of bare stranded wires may result in burning.

**Caution**

Double-check all the wiring before turning on the power supply.
Incorrect wiring may result in burning.

**Caution**

Wire correctly.
Incorrect wiring may result in burning.

**Caution**

Mount the Unit only after checking the terminal block completely.

**Caution**

Be sure that the terminal blocks, expansion cables, and other items with locking devices are properly locked into place.
Improper locking may result in malfunction.

**Caution**

Confirm that no adverse effect will occur in the system before changing the operating mode of the system.
Not doing so may result in an unexpected operation.

**Caution**

Resume operation only after transferring to the new CPU Unit the contents of the VR and table memory required for operation. Not doing so may result in an unexpected operation.

**Caution**

When replacing parts, be sure to confirm that the rating of a new part is correct. Not doing so may result in malfunction or burning.

**Caution**

Do not pull on the cables or bend the cables beyond their natural limit. Doing so may break the cables.

**Caution**

Before touching the system, be sure to first touch a grounded metallic object in order to discharge any static build-up. Otherwise it might result in a malfunction or damage.

**Caution**

UTP cables are not shielded. In environments that are subject to noise use a system with shielded twisted-pair (STP) cable and hubs suitable for an FA environment.
Do not install twisted-pair cables with high-voltage lines.
Do not install twisted-pair cables near devices that generate noise.
Do not install twisted-pair cables in locations that are subject to high humidity.
Do not install twisted-pair cables in locations subject to excessive dirt and dust or to oil mist or other contaminants.

**Caution**

Use the dedicated connecting cables specified in operation manuals to connect the Units. Using commercially available RS-232C computer cables may cause failures in external devices or the Motion Control Unit.

**Caution**

Outputs may remain on due to a malfunction in the built-in transistor outputs or other internal circuits. As a countermeasure for such problems, external safety measures must be provided to ensure the safety of the system.

**Caution**

The TJ1 will start operating in RUN mode when the power is turned on and if a BASIC program is set to Auto Run mode.

1.6 Unit assembly precautions

**Caution**

Install the unit properly.
Improper installation of the unit may result in malfunction.

**Caution**

Be sure to mount the Termination Unit supplied with the TJ1-MC ____ to the right most Unit.
Unless the Termination Unit is properly mounted, the TJ1 will not function properly.

2 Trajexia system

2.1 Introduction

Trajexia is OMRON's motion platform that offers you the performance and the ease of use of a dedicated motion system.

Trajexia is a stand-alone modular system that allows maximum flexibility and scalability. At the heart of Trajexia lies the TJ1 multi-tasking motion coordinator. Powered by a 32-bit DSP, it can do motion tasks such as e-cam, e-gearbox, registration control and interpolation, all using simple motion commands.

Trajexia offers control of up to 16 axes over a MECHATROLINK-II motion bus or traditional analogue or pulse control with independent position, speed or torque control for every axis. And its powerful motion instruction set makes programming intuitive and easy.

You can select from a wide choice of best-in-class rotary, linear and direct-drive servos as well as Inverters. The system is scalable up to 16 axes and 8 Inverters & I/O modules.


2.1.1 Trajexia hardware

The Trajexia hardware is described in the Trajexia Hardware Reference manual. It is recommended to read the Hardware Reference manual first. The Trajexia system gives these advantages:

Direct connectivity via Ethernet

Trajexia's Ethernet built-in port provides direct and fast connectivity to PCs, PLCs, HMIs and other devices while providing full access to the drives over a MECHATROLINK-II motion bus. It allows explicit messaging over Ethernet and through MECHATROLINK-II to provide full transparency down to the actuator level, and making remote access possible.

fig. 1



Keep your know-how safe

Trajexia's encryption method guarantees complete protection and confidentiality for your valuable know-how.

Serial Port and Local I/Os

A serial port provides direct connectivity with any OMRON PLC, HMIs or any other field device. 16 Inputs and 8 outputs are freely configurable embedded I/Os in the controller to enable you to tailor Trajexia to your machine design.

MECHATROLINK-II Master

The MECHATROLINK-II master performs control of up to 16 servos, Inverters or I/Os while allowing complete transparency across the whole system. MECHATROLINK-II offers the communication speed and time accuracy essential to guarantee perfect motion control of servos. The motion cycle time is selectable between 0.5 ms, 1 ms or 2 ms.

TJ1-FL02 (Flexible Axis Unit)

The TJ1-FL02 allows full control of two actuators via an analogue output or pulse train. The module supports the main absolute encoder protocols allowing the connection of an external encoder to the system.

Drives and Inverters

A wide choice of rotary, linear and direct-drive servos as well as Inverters are available to fit your needs in compactness, performance and reliability. The Inverters connected to the MECHATROLINK-II are driven at the same update cycle time as the Servo Drivers.

Remote I/Os

The I/Os on the MECHATROLINK-II motion bus provide for system expansion while keeping the devices under one motion bus.

PROFIBUS-DP

The PROFIBUS-DP slave allows connectivity to the PROFIBUS network in your machine.

DeviceNet

The DeviceNet slave allows connectivity to the DeviceNet network in your machine.

CANopen

The CANopen master allows connectivity to the CANopen network in your machine.

2.1.2 This manual

This Programming Manual gives the dedicated information for:

- The description and use of the BASIC commands
- The communication protocols necessary for the Trajexia system
- The use and description of the parts of the Trajexia Tools interface
- Program examples and good programming practices
- Troubleshooting and fault finding.

2.2 Multitasking BASIC programming

The TJ1-MC__ units (Motion Controller Unit) feature a multitasking version of the BASIC programming language. The motion control language is largely based upon a tokenised BASIC and the programs are compiled into the tokenised form prior to their execution.

Multitasking is simple to set up and use and allows very complex machines to be programmed. Multitasking gives the TJ1-MC__ a significant advantage over equivalent single task systems. It allows modular applications where the logically connected processes can be grouped together in the same task program, thus simplifying the code architecture and design.

The TJ1-MC__ can hold up to 14 programs if memory size permits. The execution of the programs is user controlled using BASIC.

The BASIC commands, functions and parameters presented here can be found in chapter 3.

2.3 BASIC programming

The BASIC language consists among others of commands, functions and parameters. These BASIC statements are the building blocks provided to control the TJ1-MC__ operation.

Commands are words recognized by the processor that perform a certain action but do not return a value. For example, **PRINT** is a recognized word that will cause the value of the following functions or variables to be printed on a certain output device.

Functions are words recognized by the processor that perform a certain action and return a value related to that action. For example, **ABS** will take the value of its parameter and return the absolute value of it to be used by some other function or command. For example **ABS(-1)** will return the value 1, which can be used by the **PRINT** command, for example, to generate a string to be output to a certain device.

Parameters are words recognized by the processor that contain a certain value. This value can be read and, if not read only, written. Parameters are used to determine and monitor the behavior of the system. For example, **ACCEL** determines the acceleration rate of a movement for a certain axis.

2.3.1 Axis, system and task statements

The commands, functions and parameters apply either to (one of) the axes, the tasks running or the general system.

Axis statements

The motion control commands and the axis parameters apply to one or more axes. Axis parameters determine and monitor how an axis reacts on commands given and how it reacts to the outside world. Every axis has a set of parameters, so that all axes can work independently of each other. The motion control commands are able to control one or more of the axes simultaneously, while every axis has its own behavior. The axis parameters are reset to their default values for each startup.

The commands and parameters work on some base axis or group of axes, specified by the **BASE** command. The **BASE** command is used to change this base axis group and every task has its own group which can be changed at any time. The default base axis is 0.

Individual axis dependent commands or parameters can also be programmed to work on a temporary base axis by including the **AXIS** function as a modifier in the axis dependent command. A temporary base axis is effective only for the command or parameter after which **AXIS** appears.

Task statements

The task parameters apply to a single task. The task parameters monitor the task for example for error handling. The **PROC** modifier allows the user to access a parameter of a certain task. Without **PROC** the current task is assumed. The **BASE** command (see above) is task specific and can be used with the **PROC** modifier.

System statements

These statements govern the overall system features, which are basically all statements which do not belong to the first two groups.

2.3.2 Memory areas

Three main memory areas can be identified in the Trajexia Motion Controller Unit:

- I/O memory.
- VR memory.
- TABLE memory.

I/O memory

I/O memory is used for holding the status of input and output devices connected to the Trajexia system. It is divided into two sub-areas: one for digital I/O memory, and one for analog I/O memory. The digital I/O memory holds input and output statuses of digital I/O devices. Its capacity is 256 bits (input points) for input and 256 bits (output points) for outputs. The inputs in this memory can be accessed using the **IN** command. The outputs can be accessed using the **OUT** command.

The analog I/O memory holds input and output values of analog I/O devices. Its capacity is 36 input channels and 36 output channels. The analog input channels can be accessed using the **AIN** command. The analog output channels can be accessed using the **AOUT** command.

VR memory

VR memory is commonly used if some data or value needs to be global, which means that it is accessible from all programs in the project at the same time. The size of this memory is 1024 slots with indexes 0 to 1023. A memory slot is addressed using the **VR(x)** macro where **x** is index of the VR memory slot. The VR memory is accessible for reading and writing. Writing is done by making mathematical assignment using the **=** command in the program. The content of this memory is held in the battery powered RAM memory and is preserved during power off. The VR memory is also preserved when changing the battery, if this is done quickly.

TABLE memory

TABLE is commonly used if some data or value needs to be global, which means that it is accessible from all programs in the project at the same time. Whereas the VR memory is used for similar purposes to define several global data and values, TABLE memory is used for much bigger amounts of global data, which also need to be arranged in a certain order. For this reason, TABLE memory is commonly used for storing TABLE data, motion profiles, logging data, etc. Some BASIC commands that provide this type and size of data, for example **SCOPE**, **CAM**, **CAMBOX** etc., require use of TABLE memory to write their results. The size of this memory is 64000 slots with indexes 0 to 63999. The TABLE is accessible for reading and writing too, but the way it is accessed differs for those two operations. Before being read, a particular TABLE memory slot needs to be defined and written first, using the command **TABLE(x, value1, value2,...)** where **x** is the index of the start TABLE memory slot to define, and **value1, value2, ...** are the values written into the TABLE memory at indexes **x, x+1, ...**. Once defined and written, the TABLE memory slot can be read using the **TABLE(x)** command, where **x** is the index of the TABLE memory slot. An attempt to read an undefined TABLE memory slot results in an error reported by the TJ1-MC__. The TABLE memory content is held in the battery powered RAM memory and is preserved during power off. The TABLE memory is also preserved when changing the battery, if this is done quickly.

2.3.3 Data structures and variables

BASIC programs can store numerical data in various types of variables. Some variables have predefined functions, such as the axis parameters and system parameters; other variables are available for the programmer to define as required in programming. The TABLE, global and local variables of the TJ1-MC__ are explained in this section. Furthermore also the use of labels will be specified.

TABLE variables

The TABLE is an array structure that contains a series of numbers. These numbers are used for instance to specify positions in the profile for a **CAM** or **CAMBOX** command. They can also be used to store data for later use, for example to store the parameters used to define a workpiece to be processed.

The TABLE is common to all tasks on the TJ1-MC__. This means that the values written to the TABLE from one task can be read from other tasks. TABLE values can be written and read using the **TABLE** command. The maximum length of the array is 64000 elements, from **TABLE(0)** to **TABLE(63999)**. The TABLE array is initialized up to the highest defined element.

Global variables

The global variables, defined in VR memory, are common to all tasks on the TJ1-MC__. This means that if a program running on task 2 sets VR(25) to a certain value, then any other program running on a different task can read that same value from VR(25). This is very useful for synchronizing two or more tasks, but care must be taken to avoid more than one program writing to the same variable at the same time. The controller has 1024 global variables, VR(0) to VR(1023). The variables are read and written using the **VR** command.



Note

The TABLE and VR data can be accessed from the different running tasks. When using either VR or TABLE variables, make sure to use only one task to write to one particular variable. This to avoid problems of two program tasks writing unexpectedly to one variable.

Local variables

Named variables or local variables can be declared in programs and are local to the task. This means that two or more programs running on different tasks can use the same variable name, but their values can be different. Local variables cannot be read from any task except for the one in which they are declared. Local variables are always cleared when a program is started. The local variables can be cleared by using either the **CLEAR** or the **RESET** command.

A maximum of 255 local variables can be declared. Only the first 16 characters of the name are significant. Undefined local variables will return zero. Local variables cannot be declared on the command line.

Labels

The BASIC programs are executed in descending order through the lines. Labels can be used to alter this execution flow using the BASIC commands **GOTO** and **GOSUB**. To define a label it must appear as the first statement on a line and it must be ended by a colon (:). Labels can be character strings of any length, but only the first 15 characters are significant.

Using variables and labels

Each task has its own local labels and local variables. For example, consider the two programs shown below:

```
start:
  FOR a = 1 to 100
    MOVE(a)
    WAIT IDLE
  NEXT a
GOTO start
```

```
start:
  a=0
  REPEAT
    a = a + 1
    PRINT a
  UNTIL a = 300
  GOTO start
```

These two programs when run simultaneously in different tasks and have their own version of variable **a** and label **start**.

If you need to hold data in common between two or more programs, VR variables should be used. Or alternatively if the large amount of data is to be held, the TABLE memory can be used.

To make a program more readable when using a global VR variable, two approaches can be taken. The first is using a named local variable as a constant in the VR variable. The local constant variable, however, must be declared in each program using the global VR variable. Using this approach, the example below shows how to use VR(3) to hold a length parameter common for several programs:

```
start:
  GOSUB Initial
  VR(length) = x
  ...
  ...
```

```
start:
  GOSUB Initial
  MOVE(VR(length))
  PRINT(VR(length))
  ...
```

```
Initial:
  length = 3
  RETURN
```

```
Initial:
  length = 3
  RETURN
```

The other approach is even more readable and uses the **GLOBAL** command to declare the name as a reference to one of the global VR variables. The name can then be used from within the program containing the **GLOBAL** definition and all other programs. Take care that the program containing the **GLOBAL** definition must be run before the name is used in other programs. The best practice is to define global names in the start-up program. Using this approach, the example above becomes:

```
'The declaration in start-up program
GLOBAL length, 3
```

```
'In other programs executed after the start-up program
start:           start:
    length = x      MOVE(length)
    ...             PRINT(length)
    ...
```

2.3.4 Mathematical specifications

Number format

The TJ1-MC__ has two main formats for numeric values: single precision floating point and single precision integer.

The single precision floating point format is internally a 32 bit value. It has an 8 bit exponent field, a sign bit and a 23 bit fraction field with an implicit 1 as the 24th bit. Floating point numbers have a valid range of $\pm 5.9 \times 10^{-39}$ to $\pm 3.4 \times 10^{38}$.

Integers are essentially floating point numbers with a zero exponent. This implies that the integers are 24 bits wide. The integer range is therefore given from -16,777,216 to 16,777,215. Numeric values outside this range will be floating point.



WARNING

All mathematical calculations are done in floating point format. This implies that for calculations of/with larger values the results may have limited accuracy. The user should be aware of this when developing the motion control application.

Hexadecimal format

The TJ1-MC__ supports assigning and printing hexadecimal values. A hexadecimal number is input by prefixing the number with the \$ character. Valid range is from 0x0 to 0xFFFFF. Example:

```
>> VR(0) = $FF
>> PRINT VR(0)
```

255.0000

A value can be printed in hexadecimal by using the **HEX** function. Negative values result in the 2's complement hexadecimal value (24-bit). Valid range is from -8,388,608 to 16,777,215. Example:

```
>> TABLE(0, -10, 65536)
>> PRINT HEX(TABLE(0)), HEX(TABLE(1))
FFFFF6 10000
```

Positioning

For positioning, the TJ1-MC__ will round up if the fractional encoder edge distance calculated exceeds 0.9. Otherwise the fractional value will be rounded down. The internal measured position and demanded position of the axes, represented by the **MPOS** and **DPOS** axis parameters, have 32-bit counters.

Floating point comparison

The comparison function considers a small difference between values as equal to avoid unexpected comparison results. Therefore any two values for which the difference is less than 1.19×10^{-6} are considered equal.

Precedence

The precedence of the operators is given below:

1. Unary minus, **NOT**
2. ^
3. / *
4. **MOD**
5. + -
6. = <> > >= <= <
7. **AND OR XOR**
8. Left to right

The best way to ensure the precedence of various operators is through the use of parentheses.

2.4 Motion execution

Every task on the TJ1-MC__ has a set of buffers that holds the information from the motion commands given.

2.4.1 Motion generator

The motion generator has a set of two motion buffers for each axis. One buffer called **MTYPE**, holds the Actual Move, which is the move currently executing on the axis. The other buffer called **NTYPE**, holds the Next Move, which is executed after the Actual Move has finished.

See chapter 2.8 "Motion Buffers" in the Trajexia Hardware Reference manual for detailed explanation.

The BASIC programs are separate from the motion generator program, which controls moves for the axes. The motion generator has separate functions for each axis, so each axis is capable of being programmed with its own axis parameters (for example speed, acceleration) and moving independently and simultaneously or they can be linked together using special commands.


When a move command is being processed, the motion generator waits until the move is finished and the buffer for the required axis has become empty, and then loads these buffers with the next move information.



Note

If the task buffers are full, the program execution is paused until buffers are available again. This also applies to the command line task and no commands can be given for that period. Trajexia Tools will disconnect in such a case. The **PMOVE** task parameter will be set to TRUE when the task buffers are full and will be reset to FALSE when the task buffers are available again.

fig. 2



2.4.2 Sequencing

On each servo cycle interrupt (see section 2.6.3), the motion generator examines the **NTYPE** buffers to see if any of them are available. If there are any available then it checks the task buffers to see if there is a move waiting to be loaded. If a move can be loaded, then the data for all the specified axes is loaded from the task buffers into the **NTYPE** buffers and the corresponding task buffers are marked as idle. This process is called sequencing.

2.4.3 Move loading

Once sequencing has been completed, the **MTYPE** buffers are checked to see if any moves can be loaded. If the required **MTYPE** buffers are available, then the move is loaded from the **NTYPE** buffers to the **MTYPE** buffers and the **NTYPE** buffers are marked as idle. This process is called move loading. If there is a valid move in the **MTYPE** buffers, then it is processed. When the move has been completed, the **MTYPE** buffers are marked as idle.

2.5 Command line interface

The command line interface provides a direct interface for the user to execute commands and access parameters on the system.

Use the Terminal Window in Trajexia Tools when the TJ1-MC__ is connected. See section 5.5.4 for details.

The TJ1-MC__ puts the last 10 commands given on the command line in a buffer. Pressing the Up and Down Cursor Key will cycle through the buffer to execute the command again.

2.6 BASIC programs

The TJ1-MC__ can store up to 14 programs in memory, provided the capacity of memory is not exceeded. The TJ1-MC__ supports simple file-handling instructions for managing these program files rather like the DOS filing system on a computer.

The Trajexia Tools software package is used to store and load programs to and from a computer for archiving, printing and editing. It also has several controller monitor and debugging facilities. Refer to chapter 5.

2.6.1 Managing programs

Trajexia Tools automatically creates a project which contains the programs to be used for an application. The programs of the project are kept both in the controller and on the computer. Whenever a program is created or edited, Trajexia Tools edits both copies in order to always have an accurate backup outside the controller at any time. Trajexia Tools checks that the two versions of the project are identical using a cyclic redundancy check. If the two differ, Trajexia Tools allows copying the TJ1-MC__ version to disk or vice versa.

Programs on the computer are stored in ASCII text files. They may therefore be printed, edited and copied using a simple text editor. The source programs are held in the TJ1-MC__ in a tokenised form and as a result, the sizes of the programs will be less on the TJ1-MC__ compared to the same programs on the computer.

Storing programs

Programs in the TJ1-MC__ are held in the battery powered RAM memory and are preserved during power off. This is similar to VR and TABLE memory. The content of the program RAM memory is preserved when the battery is in the TJ1-MC__. The programs are also preserved when changing the battery, if this is done quickly. To preserve programs without the battery for a longer period, the current programs must be copied to the Flash memory of the controller using the **EPROM** command, and read back during power up, which is determined by the **POWER_UP** system parameter.

Program commands

The TJ1-MC__ has a number of BASIC commands to allow creation, manipulation and deletion of programs. Trajexia Tools provides buttons which also perform these operations, so the use of those commands is normally not required in the programs.

Command	Function
SELECT	Selects a program for editing, deleting etc.
NEW	Deletes the current selected program, a specified program or all programs.
DIR	Lists the directory of all programs.
COPY	Duplicates a specified program.
RENAME	Renames a specified program.
DEL	Deletes the current selected program or a specified program.
LIST	Lists the current selected program or a specified program.

2.6.2 Program compilation

The TJ1-MC__ system compiles programs automatically when required. It is not normally required to force the TJ1-MC__ to compile programs, but programs can be compiled under the **Program** menu in Trajexia Tools. The TJ1-MC__ automatically compiles programs at the following times.

- The selected program is compiled before it is executed if it has been edited.
- The selected program is compiled if it has been edited before switching the selected program to another program.
- The selected program is compiled by using the **COMPILE** command.

The program syntax and structure are checked during compilation. If compilation is unsuccessful, a message will be provided and no program code will be generated. A red cross will appear in the Trajexia Tools directory box.

Programs cannot be run when compilation errors occur. The errors should be corrected and the program recompiled.

The compilation process also includes the following:

- Removing comments.
- Compiling numbers into the internal processor format.
- Converting expressions into Reverse Polish Notation format for execution.
- Precalculating variable locations.
- Calculating and embedding loop structure destinations.

WARNING

 As the compiling process requires some free memory, unexpected compiling errors may be occurring when the amount of free memory is not sufficient.

2.6.3 Program execution

The timing of the execution for the different tasks and the refreshing of the I/O of the TJ1-MC__ revolves around the servo cycle period of the system. The servo cycle period is determined by the **SERVO_PERIOD** system parameter. The TJ1-MC__ will either have a servo cycle period of 0.5, 1.0 or 2.0 ms.

I/O refresh

The I/O status of the TJ1-MC__ is refreshed at the beginning of every servo cycle.

- The captured status of the digital inputs is transferred to the **IN** system input variable. Note that this is the status captured in the previous servo cycle.
- The analogue outputs for the speed references are updated.
- The digital outputs are updated conform the status of the **OP** system output variable.
- The status of the digital inputs is captured.

Note that no automatic processing of the I/O signals is taking place, except for registration. This implies that all actions must be programmed in the BASIC programs.

Relevant commands

Trajexia Tools provides several ways of executing, pausing and stopping the programs using buttons on the control panel and the editing windows. The following commands can be given on the command line to control the execution.

Command	Function
RUN	Run the current selected program or a specified program, optionally on a specified task number.
STOP	Stop the current selected program or a specified program.
HALT	Stop all programs on the system.
PROCESS	Displays all running tasks.

The user can explicitly allocate the task priority on which the BASIC program is expected to run. When a user program is run without explicit task allocation, it is assigned the highest available task priority.

Setting programs to run at start-up

Programs can be set to run automatically at different priorities when power is turned on. If required, the computer can be left connected as an operator interface or may be removed and the programs run stand-alone.

Programs are set in Trajexia Tools to run automatically at start-up using the **Set Power Up Mode...** selection under the **Program** menu. This operation sets which program to run automatically and at which priority. This can also be accomplished by the **RUNTYPE BASIC** command. The current status can be seen using the **DIR** command.

For more information on program control, multitasking and cycle times, refer to sections 2.2 and 2.3 of the Trajexia Hardware Reference Manual.

3 BASIC commands

3.1 Categories

This section lists all BASIC commands divided by categories. The categories are:

- Axis commands.
- Axis parameters.
- Communication commands and parameters.
- Constants.
- I/O commands, functions and parameters.
- Mathematical functions and operations.
- Program commands.
- Program control commands.
- Slot parameters and modifiers.
- System commands and functions.
- System parameters.
- Task commands and parameters.

The lists are quick reference guides only. A complete description of the commands is given in alphabetical order in the next section.

3.1.1 Axis commands

Name	Description
ACC	Changes the ACCEL and DECEL at the same time.
ADD_DAC	Sum to the DAC value of one axis to the analogue output of the base axis.
ADDAX	Sets a link to a superimposed axis. All demand position movements for the superimposed axis will be added to any moves that are currently being executed.
B_SPLINE	Expands the profile stored in TABLE memory using the B-Spline mathematical function.
BACKLASH	Allows the backlash compensation to be loaded.

Name	Description
BASE	Used to set the base axis to which the commands and parameters are applied.
CAM	Moves an axis according to values of a movement profile stored in the TABLE variable array.
CAMBOX	Moves an axis according to values of a movement profile stored in the TABLE variable array. The motion is linked to the measured motion of another axis to form a continuously variable software gearbox.
CANCEL	Cancels the move on an axis.
CONNECT	Connects the demand position of an axis to the measured movements of the axis specified for driving_axis to produce an electronic gearbox.
DATUM	Performs one of 7 origin search sequences to position an axis to an absolute position or reset a motion error.
DEFPOS	Defines the current position as a new absolute position.
DISABLE_GROUP	Groups axes together for error disabling.
DRIVE_ALARM	Monitors the current alarm.
DRIVE_CLEAR	Clears the alarm status of the Servo Driver.
DRIVE_READ	Reads the specified parameter of the Servo Driver.
DRIVE_RESET	Resets the Servo Driver.
DRIVE_WRITE	Writes a specific value to the specified parameter of the Servo Driver.
ENCODER_READ	Reads a parameter of the EnDat absolute encoder.
ENCODER_WRITE	Writes to a parameter of the EnDat absolute encoder.
FORWARD	Moves an axis continuously forward at the speed set in the SPEED parameter.
HW_PSWITCH	Sets on and off the hardware switch on output 0 of the TJ1-FL02 when predefined positions are reached.
MECHATROLINK	Initializes MECHATROLINK-II bus and performs various operations on MECHATROLINK-II stations connected to the bus.

Name	Description
MHELICAL	Interpolates 3 orthogonal axes in a helical move.
MOVE	Moves one or more axes at the demand speed, acceleration and deceleration to the position specified as increment from the current position.
MOVEABS	Moves one or more axes at the demand speed, acceleration and deceleration to the position specified as absolute position.
MOVECIRC	Interpolates 2 orthogonal axes in a circular arc.
MOVELINK	Creates a linear move on the base axis linked via a software gearbox to the measured position of a link axis.
MOVEMODIFY	Changes the absolute end position of the current single-axis linear move (MOVE or MOVEABS).
RAPIDSTOP	Cancels the current move on all axes.
REGIST	Captures an axis position when a registration input or the Z mark on the encoder is detected.
REVERSE	Moves an axis continuously in reverse at the speed set in the SPEED parameter.
STEP_RATIO	Sets the ratio for the axis stepper output.

3.1.2 Axis parameters

Name	Description
ACCEL	Contains the axis acceleration rate.
ADDAX_AXIS	Contains the number of the axis to which the base axis is currently linked to by ADDAX .
ATYPE	Contains the axis type.
AXIS_DISPLAY	Selects information that are represented by the LEDs on the front cover of the TJ1-FL02.
AXIS_ENABLE	Enables and disables particular axis independently of other axis.
AXISSTATUS	Contains the axis status.
BACKLASH_DIST	Defines the amount of backlash compensation.

Name	Description
CLOSE_WIN	Defines the end of the window in which a registration mark is expected.
CLUTCH_RATE	Defines the change in connection ratio when using the CONNECT command.
CREEP	Contains the creep speed.
D_GAIN	Contains the derivative control gain.
DAC_SCALE	Sets scale and polarity applied to DAC values.
DATUM_IN	Contains the input number to be used as the origin input.
DECCEL	Contains the axis deceleration rate.
DEMAND_EDGES	Contains the current value of the DPOS axis parameter in encoder edges.
DPOS	Contains the demand position generated by the move commands.
DRIVE_CONTROL	Selects data to be monitored using DRIVE_MONITOR for axes connected via the MECHATROLINK-II bus. For axes connected via the TJ1-FL02, DRIVE_CONTROL sets outputs of the TJ1-FL02.
DRIVE_INPUTS	Holds I/O data of the driver connected to MECHATROLINK-II bus. Data is updated every servo cycle.
DRIVE_MONITOR	Monitors data of the Servo Driver connected to MECHATROLINK-II bus. Data are updated every servo cycle.
DRIVE_STATUS	Contains the current status of the Servo Driver.
ENCODER	Contains a raw copy of the encoder hardware register.
ENCODER_BITS	Sets the number of bits for the absolute encoder connected to TJ1-FL02.
ENCODER_CONTROL	Controls operating mode of the EnDat absolute encoder.
ENCODER_ID	Returns the ID value of the absolute encoder connected to TJ1-FL02.
ENCODER_RATIO	Sets scaling value for incoming encoder counts.
ENCODER_STATUS	Returns the status of the Tamagawa absolute encoder.

Name	Description
ENCODER_TURNS	Returns the multi-turn count of the absolute encoder.
ENDMOVE	Holds the position of the end of the current move.
ERRORMASK	Contains the mask value that determines if MOTION_ERROR occurs depending on the axis status.
FAST_JOG	Contains the input number to be used as the fast jog input.
FASTDEC	Defines ramp to zero deceleration ratio when an axis limit switch or position is reached.
FE	Contains the Following Error.
FE_LATCH	Contains the FE value which caused the axis to put controller in MOTION_ERROR state.
FE_LIMIT	Contains the maximum allowable Following Error.
FE_LIMIT_MODE	Defines how FE influences MOTION_ERROR state.
FE_RANGE	Contains the Following Error warning range limit.
FHOLD_IN	Contains the input number to be used as the feedhold input.
FHSPEED	Contains the feedhold speed.
FS_LIMIT	Contains the absolute position of the forward software limit.
FWD_IN	Contains the input number to be used as a forward limit input.
FWD_JOG	Contains the input number to be used as a jog forward input.
I_GAIN	Contains the integral control gain.
INVERT_STEP	Switches a hardware Inverter into the stepper output circuit.
JOGSPEED	Sets the jog speed.
LINKAX	Contains the axis number of the link axis during any linked move.
MARK	Detects the primary registration event on a registration input.
MARKB	Detects the secondary registration event on a registration input.
MERGE	Is a software switch that can be used to enable or disable the merging of consecutive moves.
MPOS	Is the position of the axis as measured by the encoder.

Name	Description
MSPEED	Represents the change in the measured position in the last servo period.
MTYPE	Contains the type of move currently being executed.
NTYPE	Contains the type of the move in the Next Move buffer.
OFFPOS	Contains an offset that will be applied to the demand position without affecting the move in any other way.
OPEN_WIN	Defines the beginning of the window in which a registration mark is expected.
OUTLIMIT	Contains the limit that restricts the speed reference output from the TJ1-MC__.
OV_GAIN	Contains the output velocity control gain.
P_GAIN	Contains the proportional control gain.
REG_POS	Contains the position at which a registration event occurred.
REG_POSB	Contains the position at which the secondary registration event occurred.
REMAIN	Is the distance remaining to the end of the current move.
REMOTE_ERROR	Returns number of errors on MECHATROLINK-II connection of the Servo Driver.
REP_DIST	Contains or sets the repeat distance.
REP_OPTION	Controls the application of the REP_DIST axis parameter.
REV_IN	Contains the input number to be used as a reverse limit input.
REV_JOG	Contains the input number to be used as a jog reverse input.
RS_LIMIT	Contains the absolute position of the reverse software limit.
S_REF	Contains the speed reference value which is applied when the axis is in open loop.
S_REF_OUT	Contains the speed reference value being applied to the Servo Driver for both open as closed loop.
SERVO	Determines whether the axis runs under servo control or open loop.
SPEED	Contains the demand speed in units/s.

Name	Description
SPEED_SIGN	Configures the voltage range of the analog speed reference output of the TJ1-FL02.
SRAMP	Contains the S-curve factor.
T_REF	Contains the torque reference value which is applied to the servo motor.
TRANS_DPOS	Contains axis demand position at output of frame transformation.
UNITS	Contains the unit conversion factor.
VERIFY	Selects different modes of operation on a stepper output axis.
VFF_GAIN	Contains the speed feed forward control gain.
VP_SPEED	Contains the speed profile speed.

3.1.3 Communication commands and parameters

Name	Description
FINS_COMM	Sends FINS Read Memory and Write Memory to a designated FINS server unit.
HLM_COMMAND	Executes a specific Host Link command to the Slave.
HLM_READ	Reads data from the Host Link Slave to either VR or TABLE variable array.
HLM_STATUS	Represents the status of the last Host Link Master command.
HLM_TIMEOUT	Defines the Host Link Master timeout time.
HLM_WRITE	Writes data to the Host Link Slave from either VR or TABLE variable array.
HLS_NODE	Defines the Slave unit number for the Host Link Slave protocol.
SETCOM	Sets the serial communications.

3.1.4 Constants

Name	Description
FALSE	Equal to the numerical value 0.
OFF	Equal to the numerical value 0.
ON	Equal to the numerical value 1.
PI	Equal to the numerical value 3.1416.
TRUE	Equal to the numerical value -1.

3.1.5 I/O commands, functions and parameters

Name	Description
AIN	Holds the value of the analog channel.
AOUT	Holds the value of the analog channel.
GET	Waits for the arrival of a single character and assigns the ASCII code of the character to variable.
IN	Returns the value of digital inputs.
INDEVICE	Parameter defines the default input device.
INPUT	Waits for a string to be received and assigns the numerical value to variable.
KEY	Returns TRUE or FALSE depending on if character is received.
LINPUT	Waits for a string and puts it in VR variables.
OP	Sets one or more outputs or returns the state of the first 24 outputs.
OUTDEVICE	Defines the default output device.
PRINT	Outputs a series of characters to a serial port.
PSWITCH	Turns on an output when a predefined position is reached, and turns off the output when a second position is reached.
READ_OP	Returns the value of the digital outputs.

3.1.6 Mathematical functions and operands

Name	Description
+ (ADDITION)	Adds two expressions.
- (SUBTRACTION)	Subtracts two expressions.
* (MULTIPLICATION)	Multiplies two expressions.
/ (DIVISION)	Divides two expressions.
^ (POWER)	Takes the power of one expression to the other expression.
= (IS EQUAL TO)	Checks two expressions to see if they are equal.
= (ASSIGNMENT)	Assigns an expression to a variable.
<> (IS NOT EQUAL TO)	Checks two expressions to see if they are different.
> (IS GREATER THAN)	Checks two expressions to see if the expression on the left is greater than the expression on the right.
>= (IS GREATER THAN OR EQUAL TO)	Checks two expressions to see if the expression on the left is greater than or equal to the expression on the right.
< (IS LESS THAN)	Checks two expressions to see if the expression on the left is less than the expression on the right.
<= (IS LESS THAN OR EQUAL TO)	Checks two expressions to see if the expression on the left is less than or equal to the expression on the right.
ABS	Returns the absolute value of an expression.
ACOS	Returns the arc-cosine of an expression.
AND	Performs an AND operation on corresponding bits of the integer parts of two expressions.
ASIN	Returns the arc-sine of an expression.
ATAN	Returns the arc-tangent of an expression.
ATAN2	Returns the arc-tangent of the non-zero complex number made by two expressions.
COS	Returns the cosine of an expression.
EXP	Returns the exponential value of an expression.

Name	Description
FRAC	Returns the fractional part of an expression.
IEEE_IN	Returns floating point number in IEEE format, represented by 4 bytes.
IEEE_OUT	Returns single byte extracted from the floating point number in IEEE format.
INT	Returns the integer part of an expression.
LN	Returns the natural logarithm of an expression.
MOD	Returns the modulus of two expressions.
NOT	Performs a NOT operation on corresponding bits of the integer part of the expression.
OR	Performs an OR operation between corresponding bits of the integer parts of two expressions.
SGN	Returns the sign of an expression.
SIN	Returns the sine of an expression.
SQR	Returns the square root of an expression.
TAN	Returns the tangent of an expression.
XOR	Performs an XOR function between corresponding bits of the integer parts of two expressions.

3.1.7 Program commands

Name	Description
' (COMMENT FIELD)	Enables a line not to be executed.
: (STATEMENT SEPARATOR)	Enables more statements on one line.
AUTORUN	Starts all the programs that have been set to run at start-up.
COMPILE	Compiles the current program.
COPY	Copies an existing program in the motion controller to a new program.

Name	Description
DEL	Deletes a program from the motion controller.
DIR	Displays a list of the programs in the motion controller, their size and their RUNTYPE on the standard output.
EDIT	Allows a program to be modified using a VT100 Terminal.
EPROM	Stores a program in the flash memory.
LIST	Prints the program on the standard output.
NEW	Deletes all lines of the program in the motion controller.
PROCESS	Returns the running status and task number for each current task.
RENAME	Changes the name of a program in the motion controller.
RUN	Executes a program.
RUNTYPE	Determines if a program is run at start-up, and which task it is to run on.
SELECT	Specifies the current program.
STEPLINE	Executes a single line in a program.
STOP	Halts program execution.
TROFF	Suspends a trace at the current line and resumes normal program execution.
TRON	Creates a breakpoint in a program.

3.1.8 Program control commands

Name	Description
FOR..TO..STEP..NEXT	Loop allows a program segment to be repeated with increasing/decreasing variable.
GOSUB..RETURN	Jumps to a subroutine at the line just after label. The program execution returns to the next instruction after a "RETURN" on page 181 is given.
GOTO	Jumps to the line containing the label.

Name	Description
IF..THEN..ELSE..ENDIF	Controls the flow of the program base on the results of the condition.
ON.. GOSUB or ON.. GOTO	Enables a conditional jump to one of several labels.
REPEAT..UNTIL	Loop allows the program segment to be repeated until the condition becomes "TRUE" on page 197.
WHILE..WEND	Loop allows the program segment to be repeated until the condition becomes FALSE .

3.1.9 Slot parameters and modifiers

Name	Description
ALL	Is a modifier that specifies that all items in the controller are concerned.
COMMSTYPE	Contains the type of unit in a controller slot.
FPGA_VERSION	Returns the FPGA version of unit with unit_number in a controller system.
SLOT	Is a modifier that specifies slot number of unit.

3.1.10 System commands and functions

Name	Description
\$ (HEXADECIMAL INPUT)	Assigns a hexadecimal number to a variable.
AXIS	Sets the axis for a command, axis parameter read, or assignment to a particular axis.
BASICERROR	Is used to run a specific routine when an error occurs in a BASIC command.
CAN_CORT	Configures the TJ1-CORT for data exchange, or returns the status of the TJ1-CORT.

Name	Description
CLEAR	Clears all global variables and the local variables on the current task.
CLEAR_BIT	Clears the specified bit of the specified VR variable.
CLEAR_PARAMS	Clears all parameter sand variables stored in flash EPROM to their default values.
CONSTANT	Declares a constant for use in BASIC program.
DATE\$	Prints the current date as a string.
DAY\$	Prints the current day as a string
DEVICENET	Configures the TJ1-DRT (DeviceNet Slave Unit) for data exchange, or returns the data exchange status of the TJ1-DRT.
ETHERNET	Reads and sets various parameters of TJ1-MC__ Ethernet port.
EX	Resets the controller.
FLAG	Sets and reads a bank of 32 bits.
FLAGS	Read and sets FLAGS as a block.
FREE	Returns the amount of available memory.
GLOBAL	Declares a reference to one of VR variables.
HALT	Stops execution of all programs currently running.
INITIALISE	Sets all axes and parameters to their default values.
INVERT_IN	Inverts input channels 0 - 31 in the software.
INVERTER_COMMAND	Reads I/O and clears alarm of the Inverter.
INVERTER_READ	Reads parameter, alarm, speed and torque reference of the Inverter.
INVERTER_WRITE	Writes to parameter, speed and torque reference of the Inverter.
LIST_GLOBAL	Shows all GLOBAL and CONSTANT variables.
LOCK	Prevents the programs from being viewed or modified.
PROFIBUS	Configures the TJ1-PRT (PROFIBUS-DP Slave Unit) to exchange I/O data with the master and returns the status of the TJ1-PRT.

Name	Description
READ_BIT	Returns the value of the specified bit in the specified VR variable.
RESET	Resets all local variables on a task.
SCOPE	Programs the system to automatically store up to 4 parameters every sample period to the TABLE variable array.
SET_BIT	Sets the specified bit in the specified VR variable to one.
TABLE	Writes and reads data to and from the TABLE variable array.
TABLEVALUES	Returns list of values from the TABLE memory.
TIME\$	Prints the current time as a string.
TRIGGER	Starts a previously set SCOPE command.
VR	Writes and reads data to and from the global (VR) variables.
VRSTRING	Combines VR memory values so they can be printed as a string.
WA	Holds program execution for the number of milliseconds specified.
WAIT IDLE	Suspends program execution until the base axis has finished executing its current move and any buffered move.
WAIT LOADED	Suspends program execution until the base axis has no moves buffered ahead other than the currently executing move.
WAIT UNTIL	Repeatedly evaluates the condition until it is TRUE .

3.1.11 System parameters

Name	Description
BATTERY_LOW	Returns the current status of the battery condition.
CHECKSUM	Contains the checksum for the programs in RAM.
COMMSErrorR	Contains all the communications errors that have occurred since the last time that it was initialised.
CONTROL	Contains the type of TJ1-MC__ in the system.

Name	Description
D_ZONE_MAX	Controls the DAC output in conjunction with the Following Error value.
D_ZONE_MIN	Controls the DAC output in conjunction with the Following Error value.
DATE	Sets or returns the current date held by the real time clock.
DAY	Sets or returns the current day.
DISPLAY	Determines I/O channels to be displayed on the front panel LEDs.
ERROR_AXIS	Contains the number of the axis which caused the motion error.
FRAME	Specifies operating frame for frame transformations.
LAST_AXIS	Contains the number of the last axis processed by the system.
MOTION_ERROR	Contains an error flag for axis motion errors.
NAIO	Returns the number of analogue channels connected on the MECHATROLINK-II bus.
NEG_OFFSET	Applies a negative offset to the DAC signal from the servo loop.
NIO	Contains the number of inputs and outputs connected to the system.
POWER_UP	Determines whether programs should be read from flash EEPROM on power up or reset.
POS_OFFSET	Applies a positive offset to the DAC signal from the servo loop.
SCOPE_POS	Contains the current TABLE position at which the SCOPE command is currently storing its first parameter.
SERVO_PERIOD	Sets the servo cycle period of the TJ1-MC__.
SYSTEM_ERROR	Contains the system errors since the last initialization.
TIME	Returns the current time held by the real time clock.
TSIZE	Returns the size of the currently defined Table.
VERSION	Returns the version number of the controller firmware.
WDOG	The software switch that enables Servo Drivers.

3.1.12 Task commands and parameters

Name	Description
ERROR_LINE	Contains the number of the line which caused the last BASIC program error.
PMOVE	Contains the status of the task buffers.
PROC	Lets a process parameter from a particular process to be accessed.
PROC_STATUS	Returns the status of the process specified.
PROCNUMBER	Contains the number of the task in which the currently selected program is running.
RUN_ERROR	Contains the number of the last BASIC error that occurred on the specified task.
TICKS	Contains the current count of the task clock pulses.

3.2 All BASIC commands

3.2.1 + (Addition)

Type	Mathematical function
Syntax	expression1 + expression2
Description	The operator + adds two expressions.
Arguments	<ul style="list-style-type: none"> • expression1 Any valid BASIC expression. • expression2 Any valid BASIC expression.
Example	result = 4 + 3 Assigns the value 7 to the variable result .
See also	N/A

3.2.2 - (Subtraction)

Type	Mathematical function
Syntax	expression1 - expression2
Description	The operator - subtracts expression2 from expression1 .
Arguments	<ul style="list-style-type: none"> • expression1 Any valid BASIC expression. • expression2 Any valid BASIC expression.
Example	result = 10 - 2 Assigns the value 8 to the variable result .
See also	N/A

3.2.3 * (Multiplication)

Type	Mathematical function
Syntax	expression1 * expression2
Description	The operator * multiplies two expressions.
Arguments	<ul style="list-style-type: none"> • expression1 Any valid BASIC expression. • expression2 Any valid BASIC expression.
Example	result = 3 * 7 Assigns the value 21 to the variable result .
See also	N/A

3.2.4 / (Division)

Type	Mathematical function
Syntax	expression1 / expression2
Description	The operator / divides expression1 by expression2 .
Arguments	<ul style="list-style-type: none"> • expression1 Any valid BASIC expression. • expression2 Any valid BASIC expression.
Example	result = 11 / 4 Assigns the value 2.75 to the variable result .
See also	N/A

3.2.5 ^ (Power)

Type	Mathematical function
Syntax	expression1 ^ expression2
Description	The power operator ^ raises expression1 to the power of expression2 . This operation uses floating point algorithms and may give small deviations for integer calculations.
Arguments	<ul style="list-style-type: none"> • expression1 Any valid BASIC expression. • expression2 Any valid BASIC expression.
Example	result = 2^5 Assigns the value 32 to the variable result .
See also	N/A

3.2.6 = (Is equal to)

Type	Mathematical function
Syntax	expression1 = expression2
Description	The operator = returns TRUE if expression1 is equal to expression2 , otherwise it returns FALSE .
Arguments	<ul style="list-style-type: none"> • expression1 Any valid BASIC expression. • expression2 Any valid BASIC expression.
Example	IF a = 10 THEN GOTO label1 If variable a contains a value equal to 10, program execution continues at label label1 . Otherwise, program execution continues with the next statement.
See also	N/A

3.2.7 = (Assignment)

Type	Mathematical function
Syntax	variable = expression
Description	The operator = assigns the value of the expression to the variable.
Arguments	<ul style="list-style-type: none"> • variable A variable name. • expression Any valid BASIC expression.
Example	var = 18 Assigns the value 18 to the variable var .
See also	N/A

3.2.8 <> (Is not equal to)

Type	Mathematical function
Syntax	expression1 <> expression2
Description	The operator <> returns TRUE if expression1 is not equal to expression2 , otherwise it returns FALSE .
Arguments	<ul style="list-style-type: none"> • expression1 Any valid BASIC expression. • expression2 Any valid BASIC expression.
Example	IF a <> 10 THEN GOTO label1 If variable a contains a value not equal to 10, program execution continues at label label1 . Otherwise, program execution continues with the next statement.
See also	N/A

3.2.9 > (Is greater than)

Type	Mathematical function
Syntax	expression1 > expression2
Description	The operator > returns TRUE if expression1 is greater than expression2 , otherwise it returns FALSE .
Arguments	<ul style="list-style-type: none"> • expression1 Any valid BASIC expression. • expression2 Any valid BASIC expression.
Example	IF a > 10 THEN GOTO label1 If variable a contains a value greater than 10, program execution continues at label label1 . Otherwise, program execution continues with the next statement.
See also	N/A

3.2.10 >= (Is greater than or equal to)

Type	Mathematical function
Syntax	expression1 >= expression2
Description	The operator >= returns TRUE if expression1 is greater than or equal to expression2 , otherwise it returns FALSE .
Arguments	<ul style="list-style-type: none"> • expression1 Any valid BASIC expression. • expression2 Any valid BASIC expression.
Example	IF a >=10 THEN GOTO label1 If variable a contains a value greater than or equal to 10, program execution continues at label label1 . Otherwise, program execution continues with the next statement.
See also	N/A

3.2.11 < (Is less than)

Type	Mathematical function
Syntax	expression1 < expression2
Description	The operator < returns TRUE if expression1 is less than expression2 , otherwise it returns FALSE .
Arguments	<ul style="list-style-type: none"> • expression1 Any valid BASIC expression. • expression2 Any valid BASIC expression.
Example	IF a < 10 THEN GOTO label1 If variable a contains a value less than 10, program execution continues at label label1 . Otherwise, program execution continues with the next statement.
See also	N/A

3.2.12 <= (Is less than or equal to)

Type	Mathematical function
Syntax	expression1 <= expression2
Description	The operator <= returns TRUE if expression1 is less than or equal to expression2 , otherwise it returns FALSE .
Arguments	<ul style="list-style-type: none"> • expression1 Any valid BASIC expression. • expression2 Any valid BASIC expression.
Example	IF a <= 10 THEN GOTO label1 If variable a contains a value less than or equal to 10, program execution continues at label label1 . Otherwise, program execution continues with the next statement.
See also	N/A

3.2.13 \$ (Hexadecimal input)

Type	System command
Syntax	\$hex_num
Description	The \$ command makes the number that follows a hexadecimal number.
Arguments	<ul style="list-style-type: none"> • hex_num A hexadecimal number (consisting of the characters 0 - 9 and A - F). hex_num ranges from 0 to FFFFFF.
Example	<pre>>>TABLE(0, \$F, \$ABCD) >>print TABLE(0), TABLE(1) 15.0000 43981.0000</pre>
See also	HEX (PRINT)

3.2.14 ' (Comment field)

Type	Program command
Syntax	'
Description	' marks all that follows it on a line as comment and not program code. Comment is not executed when the program is run. You can use ' at the beginning of a line or after a valid statement.
Arguments	N/A
Example	' This line is not printed <pre>PRINT "Start"</pre>
See also	N/A

3.2.15 : (Statement separator)

Type	Program command
Syntax	:
Description	The statement separator : separates multiple BASIC statements on one line. You can use it on the command line and in programs.
Arguments	N/A
Example	PRINT "THIS LINE": GET low : PRINT "DOES THREE THINGS"
See also	N/A

3.2.16

Type	Special character
Syntax	#
Description	The # symbol is used to specify a communications channel to be used for serial input/output commands. Note: Communications Channels greater than 3 will only be used when running the Trajexia Tools software.
Arguments	N/A
Example	PRINT #1, "RS232" PRINT #2, "RS485"
Example	IF KEY #1 THEN GET #1, k Checks keypad on RS232 port, which represent communication channel 1.
See also	N/A

3.2.17 ABS

Type	Mathematical function
Syntax	ABS(expression)
Description	The ABS function returns the absolute value of an expression.
Arguments	<ul style="list-style-type: none"> • expression Any valid BASIC expression.
Example	IF ABS(A) > 100 THEN PRINT "A is outside range -100 ... 100"
See also	N/A

3.2.18 ACC

Type	Axis command
Syntax	ACC(rate)
Description	Sets the acceleration and deceleration at the same time. This command gives a quick method to set both ACCEL and DECEL . Acceleration and deceleration rates are recommended to be set with the ACCEL and DECEL axis parameters.
Arguments	<ul style="list-style-type: none"> • rate The acceleration/deceleration rate in units/s². You can define the units with the UNITS axis parameter.
Example	ACC(100) Sets ACCEL and DECEL to 100 units/s ² .
See also	ACCEL, DECEL, UNITS

3.2.19 ACCEL

Type	Axis parameter
Syntax	ACCEL = expression
Description	The ACCEL axis parameter contains the axis acceleration rate. The rate is set in units/s ² . The parameter can have any positive value including zero.
Arguments	N/A
Example	BASE(0) ACCEL = 100 ' Set acceleration rate PRINT "Acceleration rate: "; ACCEL; " mm/s/s" ACCEL AXIS(2) = 100 ' Sets acceleration rate for axis (2)
See also	ACCEL, DECEL, UNITS

3.2.20 ACOS

Type	Mathematical function
Syntax	ACOS(expression)
Description	The ACOS function returns the arc-cosine of the expression. The expression value must be between -1 and 1. The result in radians is between 0 and PI. Input values outside the range will return 0.
Arguments	<ul style="list-style-type: none"> • expression Any valid BASIC expression.
Example	>> PRINT ACOS(-1) 3.1416
See also	N/A

3.2.21 ADD_DAC

Type Axis command

Syntax **ADD_DAC(axis)**

Description The **ADD_DAC** command adds the **DAC_OUT** value of **axis** to the **DAC_OUT** value of the base axis. Use **ADD_DAC(-1)** to cancel the sum. **ADD_DAC** works on the default basis axis (set with **BASE**) unless **AXIS** is used to specify a temporary base axis.

Note:


1. Be aware that the control loop gains for both axes need to be determined with care. As different encoders with different resolutions are used, the gains are not identical.
2. Set the **OUTLIMIT** parameter to the same value for both linked axes.
3. This command has no meaning for a MECHATROLINK-II axis in position mode (**ATYPE=40**), because the value of **DAC_OUT** is ignored.

Arguments • **axis**
The axis from which to sum the speed reference output to the base axis.
Set the argument to -1 to cancel the link and return to normal operation.

Example No example.

See also **AXIS, DAC_OUT, OUTLIMIT**

fig. 1




3.2.22 ADDAX

Type	Axis command
Syntax	ADDAX(axis)
Description	<p>The ADDAX command is used to superimpose two or more movements to build up a more complex movement profile.</p> <p>The ADDAX command takes the demand position changes from the superimposed axis as specified by the axis argument and adds them to any movement running on the axis to which the command is issued. The axis specified by the parameter can be any axis and does not have to physically exist in the system.</p> <p>The ADDAX command therefore allows an axis to perform the moves specified on two axes added together. When the axis parameter is set to OFF on an axis with an encoder interface the measured position MPOS is copied into the demanded position DPOS. This allows ADDAX to be used to sum encoder inputs.</p> <p>After the ADDAX command has been issued the link between the two axes remains until broken. Use ADDAX(-1) to cancel the axis link. ADDAX allows an axis to perform the moves specified for 2 axes added together. Combinations of more than two axes can be made by applying ADDAX to the superimposed axis as well.</p> <p>ADDAX works on the default basis axis (set with BASE) unless AXIS is used to specify a temporary base axis.</p> <p>Note: The ADDAX command sums the movements in encoder edge units.</p>
Arguments	<ul style="list-style-type: none">• axis The axis to be set as a superimposed axis. Set the argument to -1 to cancel the link and return to normal operation.

Example **UNITS AXIS(0)=1000**
UNITS AXIS(1)=20
' Superimpose axis 1 on axis 0
ADDAX(1) AXIS(0)
MOVE(1) AXIS(0)
MOVE(2) AXIS(1)
'Axis 0 will move $1*1000+2*20=1040$ edges

fig. 2



Example Pieces are placed randomly onto a belt that moves continuously. Further along the line they are transferred to a second flighted belt. A detection system indicates if a piece is in front of or behind its nominal position, and how far.


```

expected=2000 ' sets expected position
BASE(0)
ADDAX(1)
CONNECT(1,2) ' continuous geared connection to flighted belt
REPEAT
  GOSUB getoffset ' get offset to apply
  MOVE(offset) AXIS(1) ' make correcting move on virtual axis
UNTIL IN(2)=OFF ' repeat until stop signal on input 2
RAPIDSTOP
ADDAX(-1) ' clear ADDAX connection
STOP
getoffset: ' sub routine to register the position of the
  ' piece and calculate the offset
BASE(0)
REGIST(3)
WAIT UNTIL MARK
seenat=REG_POS
offset=expected-seenat
RETURN

```

Axis 0 in this example is connected to the encoder of the second conveyor. A superimposed **MOVE** on axis 1 is used to apply offsets.

fig. 3



Example An X-Y marking machine must mark boxes as they move along a conveyor. Using CONNECT enables the X marking axis to follow the conveyor. A virtual axis is used to program the marking absolute positions; this is then superimposed onto the X axis using ADDAX.


```

ATYPE AXIS(3)=0 'set axis 3 as virtual axis
SERVO AXIS(3)=ON
DEFPOS(0) AXIS(3)
ADDAX (3)AXIS(0) 'connect axis 3 requirement to axis 0
WHILE IN(2)=ON
  REGIST(3) 'registration input detects a box on the conveyor
  WAIT UNTIL MARK OR IN(2)=OFF
  IF MARK THEN
    CONNECT(1,2) AXIS(0)'connect axis 0 to the moving belt
    BASE(3,1) 'set the drawing motion to axis 3 and 1
    'Draw the M
    MOVEABS(1200,0)'move A > B
    MOVEABS(600,1500)'move B > C
    MOVEABS(1200,3000)' move C > D
    MOVEABS(0,0)'move D > E
    WAIT IDLE
    BASE(0)
    CANCEL 'stop axis 0 from following the belt
    WAIT IDLE
    MOVEABS(0) 'move axis 0 to home position
  ENDIF
WEND
CANCEL

```

See also [ADDAX_AXIS](#), [AXIS](#), [OUTLIMIT](#)

fig. 4

**WARNING**

Beware that giving several **ADDAX** commands in a system can create a dangerous loop when for instance one axis is linked to another and vice versa. This may cause instability in the system.

3.2.23 ADDAX_AXIS

Type	Axis parameter (read-only)
Syntax	ADDAX_AXIS
Description	The ADDAX_AXIS axis parameter returns the number of the axis to which the base axis is currently linked to by ADDAX . If the base axis is not linked to any other axis, the ADDAX_AXIS parameter returns -1.
Arguments	N/A
Example	<pre>>> BASE(0) >> ADDAX(2) >> PRINT ADDAX_AXIS 2.0000 >> ADDAX(-1) >> PRINT ADDAX_AXIS -1.0000</pre>
See also	ADDAX, AXIS

3.2.24 AIN

Type	I/O command
Syntax	AIN(analogue_chan)
Description	The AIN reads a value from an analogue input. Analogue input channels are provided by connecting GRT1-ML2 Slice Coupler, Phoenix IL MII BK Slice Coupler, or JEPMC-AN2900 modules on the MECHATROLINK-II bus.
Arguments	analogue_chan. Analogue input channel number 0..31

Example	MOVE(-5000) REPEAT a=AIN(1) IF a<0 THEN a=0 SPEED=a*0.25 UNTIL MTYP=0
Description	<p>The speed of a production line is governed by the rate at which material is fed onto it. The material feed is via a lazy loop arrangement which is fitted with an ultra-sonic height sensing device. The output of the ultra-sonic sensor is in the range 0V to 4V where the output is at 4V when the loop is at its longest.</p> <p>Note: The analogue input value is checked to ensure it is above zero even though it always should be positive. This is to allow for any noise on the incoming signal which could make the value negative and cause an error because a negative speed is not valid for any move type except FORWARD or REVERSE.</p>
See also	N/A

3.2.25 ALL

Type	Slot modifier
Syntax	ALL
Description	The ALL modifier is used with the commands DEL and NEW . It indicates that these commands are applied to all items in the directory structure of the controller.
Arguments	N/A
Example	DEL ALL This deletes all programs and the TABLE memory of the controller.
Example	HALT NEW ALL STORE This creates the memory of the controller.
See also	DEL, NEW .

3.2.26 AND

Type	Mathematical operation
Syntax	expression1 AND expression2
Description	<p>The AND operator performs the logical AND function on the corresponding bits of the integer parts of two valid BASIC expressions.</p> <p>The logical AND function between two bits is defined as follows:</p> <ul style="list-style-type: none"> 0 AND 0 = 0 0 AND 1 = 0 1 AND 0 = 0 1 AND 1 = 1
Arguments	<ul style="list-style-type: none"> • expression1 Any valid BASIC expression. • expression2 Any valid BASIC expression.
Example	<p>VR(0) = 10 AND (2.1*9)</p> <p>The parentheses are evaluated first, but only the integer part of the result, 18, is used for the AND operation. Therefore, this expression is equivalent to the following:</p> <p>VR(0) = 10 AND 18</p> <p>The AND is a bit operator and so the binary action is as follows:</p> <p>01010 AND 10010 = 00010</p> <p>Therefore, VR(0) will contain the value 2.</p>
Example	<p>IF MPOS AXIS(0) > 0 AND MPOS AXIS(1) > 0 THEN GOTO cycle1</p> <p>If measured positions MPOS of both axis 1 and axis 2 are greater than zero, program execution continues at label cycle1. Otherwise, program execution continues with the next statement.</p>
See also	N/A

3.2.27 AOUT

Type	I/O command
Syntax	AOUT(analogue_chan)

Description The **AOUT** command sets the output value of the analogue output channels that are provided by connecting GRT1-ML2 Slice Coupler, Phoenix IL MII BK Slice Coupler, or JEPMC-AN2910 modules on the MECHATROLINK-II bus. The range of the value set is [-32000, 32000] for full output range. The output range depends on the analogue unit used and can be one of the following: [-10V, 10V], [0V, 10V] or [0V, 5V] for voltage and [0mA, 20mA] or [4mA, 20mA] for current output.

Arguments

- **analogue_chan**.
Analogue output channel number 0.31

Example No example.

See also N/A

3.2.28 ASIN

Type	Mathematical function
Syntax	ASIN(expression)
Description	The ASIN function returns the arc-sine of the argument. The argument must have a value between -1 and 1. The result in radians is between -PI/2 and PI/2. Input values outside this range return 0.
Arguments	<ul style="list-style-type: none"> • expression Any valid BASIC expression.
Example	<p>>> PRINT ASIN(-1) -1.5708</p>
See also	N/A

3.2.29 ATAN

Type	Mathematical function
Syntax	ATAN(expression)
Description	The ATAN function returns the arc-tangent of the argument. expression can have any value. The result is in radians and is between -PI/2 and PI/2.

Arguments • **expression**
Any valid BASIC expression.

Example **>> PRINT ATAN(1)**
0.7854

See also N/A

3.2.30 ATAN2

Type Mathematical function

Syntax **ATAN2(expression1, expression2)**

Description The **ATAN2** function returns the arc-tangent of the non-zero complex number (**expression1, expression2**), which is equivalent to the angle between a point with coordinate (**expression1, expression2**) and the x-axis. If **expression2 >= 0**, the result is equal to the value of **ATAN(expression1 / expression2)**. The result in radians will be between -Pi and Pi.

Arguments • **expression1**
Any valid BASIC expression.
• **expression2**
Any valid BASIC expression.

Example **>> PRINT ATAN2(0,1)**
0.0000

See also N/A

3.2.31 ATYPE

Type Axis parameter

Syntax **ATYPE = value**

Description The **ATYPE** axis parameter indicates the axis type for the axis. The valid values depend on TJ1 module the Servo Driver controlling the axis is connected to. See the table below.

AXIS type	ATYPE value	Applicable TJ1 unit
Virtual	0	All
MECHATROLINK-II Position	40	TJ1-ML_(MECHATROLINK-II Master Unit)
MECHATROLINK-II Speed	41	TJ1-ML_
MECHATROLINK-II Torque	42	TJ1-ML_
Flexible axis Stepper Out	43	TJ1-FL02
Flexible axis Servo	44	TJ1-FL02
Flexible axis Encoder Out	45	TJ1-FL02
Flexible axis Absolute Tamagawa	46	TJ1-FL02
Flexible axis Absolute EnDat	47	TJ1-FL02
Flexible axis Absolute SSI	48	TJ1-FL02
MECHATROLINK-II Inverter	49	TJ1-ML_

The **ATYPE** parameters are set by the system at start-up. For axes controlled by the Servo Drivers connected to the system via MECHATROLINK-II bus, the default **ATYPE** value is 41 (MECHATROLINK-II Speed) for Sigma II Servo Drivers, or 40 (MECHATROLINK-II Position) for JUNMA Servo Drivers. For axes controlled by the Servo Drivers connected to the system via the TJ1-FL02, the default **ATYPE** value is 44 (Flexible Axis Servo).

Arguments N/A

Example **ATYPE AXIS(1) = 45**

This command will set axis 1 as Flexible axis encoder output axis.

See also **AXIS**

3.2.32 AUTORUN

Type Program command

Syntax **AUTORUN**

Description The **AUTORUN** command starts all the programs that have been set to run at start-up.

Note: This command should only be used on the Command Line Terminal.

Arguments N/A

Example No example.

See also **RUNTYPE**

3.2.33 AXIS

Type System command

Syntax **AXIS(axis_number)**

Description The **AXIS** modifier sets the axis for a single motion command or a single axis parameter read/write to a particular axis. **AXIS** is effective only for the command or axis parameter operation. If it is required to change the axis used to a particular axis in every subsequent command, use the **BASE** command instead.

Arguments

- **axis_number**
Any valid BASIC expression specifying the axis number.

Example **BASE(0)**
PRINT VP_SPEED AXIS(2)

Example **MOVE(300) AXIS(0)**

Example **REP_DIST AXIS(1) = 100**

See also **BACKLASH**

3.2.34 AXIS_DISPLAY

Type Axis parameter

Syntax **AXIS_DISPLAY = value**

Description The **AXIS_DISPLAY** axis parameter enables different data to be displayed by the LEDs on the front cover of the TJ1-FL02 unit. LEDs affected by this parameter setting are two yellow LEDs showing axis status. The default value of this parameter on start-up for all axes is 0. The valid values are shown in the table below.

AXIS_DISPLAY value	0	1	2	3
A0	REG 0	AUX IN	OUT 0	ENCODER A
A1	REG 1	ENCODER Z	OUT 1	ENCODER B
B0	REG 0	AUX IN	OUT 0	ENCODER A
B1	REG 1	ENCODER Z	OUT 1	ENCODER B

Arguments N/A

Example **AXIS_DISPLAY AXIS(2) = 2**

This command will display status of the outputs OUT 0 and OUT 1 allocated to axis 2.

See also N/A

3.2.35 AXIS_ENABLE

Type Axis parameter

Syntax **AXIS_ENABLE = ON/OFF**

Description The **AXIS_ENABLE** axis parameter is used to enable or disable particular axis independently of others. This parameter can be set ON or OFF for each axis individually. The default value on start-up is ON or all axes. The axis will be enabled if both **AXIS_ENABLE** for that axis is ON and **WDOG** is on. For MECHATROLINK-II axes setting **AXIS_ENABLE** to OFF will disable Servo Driver output to the motor. For Flexible axis Servo axis setting **AXIS_ENABLE** to OFF will force both voltage outputs to 0. For Flexible axis Stepper Out and Encoder Out axes, setting **AXIS_ENABLE** to OFF will block pulses generation on the outputs.

Arguments N/A

Example **AXIS_ENABLE AXIS(3) = OFF**

This command will disable axis 3 independently of other axes in the system.

See also **AXIS, DISABLE_GROUP**

3.2.36 AXISSTATUS

Type Axis parameter (read-only)

Syntax **AXISSTATUS**Description The **AXISSTATUS** axis parameter contains the axis status and is used for the motion error handling of the controller. The axis status consists of status bits, which definitions are shown in the table below.

Bit number	Description	Value	Character (as used in Trajexia Tools)
0	-	1	-
1	Following error warning range	2	w
2	Servo Driver communication error	4	a
3	Servo Driver alarm	8	m
4	in forward limit	16	f
5	In reverse limit	32	r
6	Datuming	64	d
7	Feed hold input	128	h
8	Following error exceeds limit	256	e
9	In forward software limit	512	x
10	In reverse software limit	1024	y
11	Cancelling move	2048	c
12	Encoder out overspeed	4096	o

Arguments N/A

Example **IF (AXISSTATUS AND 16)>0 THEN PRINT "In forward limit"**See also **AXIS, ERRORMASK**

3.2.37 B_SPLINE

Type Axis command

Syntax **B_SPLINE(type, data_in, number_in, data_out, #expand)**

Description Expands an existing profile stored in the TABLE using the B-Spline mathematical function. The expansion factor is configurable and the B_SPLINE stores expanded profile to another area in the TABLE.

This is ideally used where the source **CAM** profile is too coarse and needs to be extrapolated into a greater number of points.

- Arguments
- type**
Reserved for future expansion. Always set this to 1.
 - data_in**
Location in the TABLE where the source profile is stored.
 - number_in**
Number of points in the source profile.
 - data_out**
Location in the TABLE where the expanded profile will be stored.
 - expansion_ratio**
The expansion ratio, i.e., if the source profile is 100 points and **expansion_ratio** is set to 10 the resulting profile will be 1000 point (100 * 10).

Example
**BASE(1)
B_SPLINE(1, 0, 10, 200, 10)**

This command expands a 10 point profile in TABLE locations 0 to 9 to a larger 100 points profile starting at TABLE location 200.

See also N/A

3.2.38 BACKLASH

Type	Axis command
Syntax	BACKLASH(on/off, distance, speed, accel)
Description	<p>The BACKLASH command allows the parameters for the backlash compensation to be loaded. The backlash compensation is achieved as follows:</p> <ul style="list-style-type: none"> • An offset move is applied when the motor demand is in one direction. • The offset move is reversed when the motor demand is in the opposite direction. <p>These moves are superimposed on the command axis movements. The backlash compensation is applied after a change in the direction of the DPOS parameter. The backlash compensation can be seen in the TRANS_DPOS parameter, which is equal to DPOS + backlash compensation.</p>
Arguments	<ul style="list-style-type: none"> • on/off Either ON or OFF. • distance The offset distance, expressed in user units. • speed The speed of the compensation move, expressed in user units. • accel The acceleration or deceleration rate of the compensation move, expressed in user units.
Example	BACKLASH(ON,0.5,10,50) AXIS(0) BACKLASH(ON,0.4,8,50) AXIS(1) This applies backlash compensation on axes 0 and 1.
See also	DPOS, TRANS_DPOS.

3.2.39 BACKLASH_DIST

Type	Axis parameter
Syntax	BACKLASH_DIST

Description	BACKLASH_DIST is the amount of backlash compensation that is applied to the axis when BACKLASH = ON .
Arguments	N/A
Example	IF BACKLASH_DIST>100 THEN OP (10, ON) ' show that backlash compensation reached this value ELSE OP (10, OFF) END IF
See also	BACKLASH

3.2.40 BASE

Type	Axis command
Syntax	BASE BASE(axis_1 [,axis_2 [,axis_3 [,axis_4 [,axis_...]]]]) BA BA(axis_1 [,axis_2 [,axis_3 [,axis_4 [,axis_...]]]])

Description	<p>The BASE command is used to set the default base axis or to set a specified axis sequence group. All subsequent motion commands and axis parameters will apply to the base axis or the specified axis group unless the AXIS command is used to specify a temporary base axis. The base axis or axis group is effective until it is changed again with BASE.</p> <p>Each BASIC process can have its own axis group and each program can set its own axis group independently. Use the PROC modifier to access the parameters for a certain task.</p> <p>The BASE order grouping can be set by explicitly assigning the order of axes. This order is used for interpolation purposes in multi-axes linear and circular moves. The default for the base axis group is (0,1,2,3,4,5,6,7,8,9,10,11,12,13,14,15) at start-up or when a program starts running on a task. The BASE command without any arguments returns the current base order grouping. This should be used</p> <p>Note: If the BASE command does not specify all the axes, the BASE command will "fill in" the remaining values automatically. Firstly it will fill in any remaining axes above the last declared value, then it will fill in any remaining axes in sequence.</p> <p>So BASE(2,6,10) sets the internal array of 16 axes to:</p> <p>2,6,10,11,12,13,14,15,0,1,3,4,5,7,8,9.</p> <p>Note: The BASE command without any arguments should only be used on the Command Line Terminal.</p>
Arguments	<p>The command can take up to 16 arguments.</p> <ul style="list-style-type: none"> • axis_i The number of the axis set as the base axis and any subsequent axes in the group order for multi-axis moves.
Example	<pre>BASE(1) UNITS = 2000 ' Set unit conversion factor for axis 1 SPEED = 100 ' Set speed for axis 1 ACCEL = 5000 ' Set acceleration rate for axis 1 BASE(2) UNITS = 2000 ' Set unit conversion factor for axis 2 SPEED = 125 ' Set speed for axis 2 ACCEL = 10000 ' Set acceleration rate for axis 2</pre> <p>It is possible to program each axis with its own speed, acceleration and other parameters.</p>

Example	BASE(0) MOVE(100,-23.1,1250) In this example, axes 0, 1 and 2 will move to the specified positions at the speed and acceleration set for axis 0. BASE(0) sets the base axis to axis 0, which determines the three axes used by MOVE and the speed and acceleration rate.
Example	>> BASE (0,2,1) On the command line the base group order can be shown by typing BASE .
Example	>> RUN "PROGRAM", 3 >> BASE PROC(3) (0,2,1) Use the PROC modifier to show the base group order of a certain task.
Example	>> BASE(2) >> PRINT BASE 2.0000 Printing BASE will return the current selected base axis.
See also	AXIS

3.2.41 BASICERROR

Type	System command
Syntax	BASICERROR
Description	The BASICERROR command can be used to run a routine when a run-time error occurs in a program. BASICERROR can only be used as part of an ON ... GOSUB or ON ... GOTO command. This command is required to be executed once in the BASIC program. If several commands are used only the one executed last is effective.
Arguments	N/A

Example	<pre>ON BASICERROR GOTO error_routine ... no_error = 1 STOP error_routine: IF no_error = 0 THEN PRINT "The error "; RUN_ERROR[0]; PRINT " occurred in line "; ERROR_LINE[0] ENDIF STOP</pre>	Arguments	<ul style="list-style-type: none"> program_name The name of the program from which you want to remove all break points.
		Example	BREAK_RESET "simpletest" Will remove all break points from program simpletest .
		See also	N/A

If an error occurs in a BASIC program in this example, the error routine will be executed.
The **IF** statement is present to prevent the program going into error routine when it is stopped normally.

See also **ERROR_LINE, ON, RUN_ERROR.**

3.2.42 BATTERY_LOW

Type	System parameter (read-only)
Syntax	BATTERY_LOW
Description	This parameter returns the current state of the battery condition. If BATTERY_LOW=ON then the battery needs to be changed. If BATTERY_LOW=OFF then battery condition is ok.
Arguments	N/A
Example	No example.
See also	N/A

3.2.43 BREAK_RESET

Type	System command
Syntax	BREAK_RESET "program_name"
Description	Used by Trajexia Tools to remove all break points from the specified program.

3.2.44 CAM

Type	Axis command
Syntax	CAM(start_point, end_point, table_multiplier, distance)
Description	<p>The CAM command is used to generate movement of an axis following a position profile which is stored in the TABLE variable array. The TABLE values are absolute positions relative to the starting point and are specified in encoder edges. The TABLE array is specified with the TABLE command. The movement can be defined with any number of points from 3 to the maximum table size available (64000). The TJ1-MC__ moves continuously between the values in the TABLE to allow a number of points to define a smooth profile. Two or more CAM commands can be executed simultaneously using the same or overlapping values in the TABLE array. The TABLE profile is traversed once.</p> <p>CAM requires that the start element in the TABLE array has value zero. The distance argument together with the SPEED and ACCEL parameters determine the speed moving through the TABLE array. Note that in order to follow the CAM profile exactly the ACCEL parameter of the axis must be at least 1000 times larger than the SPEED parameter.</p> <p>CAM works on the default basis axis (set with BASE) unless AXIS is used to specify a temporary base axis.</p>

Arguments

- **start_point**
The address of the first element in the TABLE array to be used.
Being able to specify the start point allows the TABLE array to hold more than one profile and/or other information.
- **end_point**
The address of the end element in the TABLE array.
- **table_multiplier**
The Table multiplier value used to scale the values stored in the TABLE. As the Table values are specified in encoder edges, use this argument to set the values for instance to the unit conversion factor (set by **UNITS** parameter).
- **distance**
A factor given in user units that controls the speed of movement through the Table. The time taken to execute **CAM** depends on the current axis speed and this distance. For example, assume the system is being programmed in mm and the speed is set to 10 mm/s and the acceleration sufficiently high. If a distance of 100 mm is specified, **CAM** will take 10 seconds to execute.
The **SPEED** parameter in the base axis allows modification of the speed of movement when using the **CAM** move.

Note: When the **CAM** command is executing, the **ENDMOVE** parameter is set to the end of the previous move.

Example Motion is required to follow the POSITION equation:
 $t(x) = x^2 * 25 + 10000(1 - \cos(x))$, where x is in degrees. This example table provides a simple oscillation superimposed with a constant speed. To load the table and cycle it continuously the program would be:

```

FOR deg=0 TO 360 STEP 20 'loop to fill in the table
    rad = deg * 2 * PI/360 'convert degrees to radians
    x = deg * 25 + 10000 * (1-COS(rad))
    TABLE(deg/20,x) 'place value of x in table
NEXT deg
WHILE IN(2)=ON 'repeat cam motion while input 2 is on
    CAM(0,18,1,200)
    WAIT IDLE
WEND

```

Note: The subroutine **camtable** loads the data into the cam TABLE, as shown in the figure and in the table below.

fig. 5




TABLE position	Degree	Value
1	0	0
2	20	1103
3	40	3340
4	60	6500
5	80	10263
6	100	14236
7	120	18000
8	140	21160
9	160	23396
10	180	24500
11	200	24396
12	220	23160
13	240	21000


TABLE position	Degree	Value
14	260	18236
15	280	15263
16	300	12500
17	320	10340
18	340	9103
19	360	9000

Example A masked wheel is used to create a stencil for a laser to shine through for use in a printing system for the ten numerical digits. The required digits are transmitted through port 1 serial port to the controller as ASCII text. The encoder used has 4000 edges per revolution and so must move 400 between each position. The cam table goes from 0 to 1, which means that the **CAM** multiplier needs to be a multiple of 400 to move between the positions. The wheel is required to move to the pre-set positions every 0.25 seconds. The speed is set to 10000 edges/second, and we want the profile to be complete in 0.25 seconds. So multiplying the axis speed by the required completion time (10000×0.25) gives the distance parameter equals 2500.

```

GOSUB profile_gen
WHILE IN(2)=ON
  WAIT UNTIL KEY#1 'Waits for character on port 1
  GET#1,k
  IF k>47 AND k<58 THEN 'check for valid ASCII character
    position=(k-48)*400 'convert to absolute position
    multiplier=position-offset 'calculate relative movement
    'check if it is shorter to move in reverse direction
    IF multiplier>2000 THEN
      multiplier=multiplier-4000
    ELSEIF multiplier<-2000 THEN
      multiplier=multiplier+4000
    ENDIF
    CAM(0,200,multiplier,2500) 'set the CAM movement
    WAIT IDLE
    OP(15,ON) 'trigger the laser flash
    WA(20)
    OP(15,OFF)
    offset=(k-48)*400 'calculates current absolute position
  ENDIF
WEND
profile_gen:
  num_p=201
  scale=1.0
  FOR p=0 TO num_p-1
    TABLE(p,(-SIN(PI*2*p/num_p)/(PI*2))+p/num_p)*scale)
  NEXT p
RETURN
```

fig. 6



Example A suction pick and place system must vary its speed depending on the load carried. The mechanism has a load cell which inputs to the controller on the analogue channel (**AIN**).
 The move profile is fixed, but the time taken to complete this move must be varied depending on the **AIN**. The **AIN** value varies from 100 to 800, which must result in a move time of 1 to 8 seconds. If the speed is set to 10000 units per second and the required time is 1 to 8 seconds, then the distance parameter must range from 10000 to 80000. (distance = speed x time).

The return trip can be completed in 0.5 seconds and so the distance value of 5000 is fixed for the return movement. The Multiplier is set to -1 to reverse the motion.

```
GOSUB profile_gen 'loads the cam profile into the table
SPEED=10000:ACCEL=SPEED*1000:DECEL=SPEED*1000
WHILE IN(2)=ON
  OP(15,ON) 'turn on suction
  load=AIN(0) 'capture load value
  distance = 100*load 'calculate the distance parameter
  CAM(0,200,50,distance) 'move 50mm forward in time calculated
  WAIT IDLE
  OP(15,OFF) 'turn off suction
  WA(100)
  CAM(0,200,-50,5000) 'move back to pick up position
WEND
```

```
profile_gen:
  num_p=201
  scale=400 'set scale so that multiplier is in mm
  FOR p=0 TO num_p-1
    TABLE(p,(-SIN(PI*2*p/num_p)/(PI*2))+p/num_p)*scale)
  NEXT p
  RETURN
```

See also **ACCEL, AXIS, CAMBOX, SPEED, TABLE.**

3.2.45 CAMBOX

Type	Axis command
Syntax	CAMBOX(start_point, end_point, table_multiplier, link_distance, link_axis [, link_option [, link_position]])
Description	<p>The CAMBOX command is used to generate movement of an axis following a position profile in the TABLE variable array. The motion is linked to the measured motion of another axis to form a continuously variable software gearbox. The TABLE values are absolute position relative to the starting point and are specified in encoder edges.</p> <p>The TABLE array is specified with the TABLE command. The movement can be defined with any number of points from 3 to the maximum table size available (64000). Being able to specify the start point allows the TABLE array to be used to hold more than one profile and/or other information. The TJ1-MC__ moves continuously between the values in the TABLE to allow a number of points to define a smooth profile. Two or more CAMBOX commands can be executed simultaneously using the same or overlapping values in the TABLE array.</p> <p>The CAMBOX command requires the start element of the TABLE to have value zero. Note also that CAMBOX command allows traversing the TABLE backwards as well as forwards depending on the Master axis direction.</p> <p>The link_option argument can be used to specify different options to start the command and to specify a continuous CAM. For example, if the link_option is set to 4 then the CAMBOX operates like a "physical" CAM.</p> <p>CAMBOX works on the default basis axis (set with BASE) unless AXIS is used to specify a temporary base axis.</p> <p>Note: While CAMBOX is being executed, the ENDMOVE parameter will be set to the end of the previous move. The REMAIN axis parameter will hold the remainder of the distance on the link axis.</p>

Arguments

- **start_point**
The address of the first element in the TABLE array to be used.
- **end_point**
The address of the end element in the TABLE array.
- **table_multiplier**
The Table multiplier value used to scale the values stored in the TABLE. As the TABLE values are specified in encoder edges, use this argument to set the values for instance to the unit conversion factor (set by UNITS parameter).
- **link_distance**
The distance in user units the link axis must move to complete the specified output movement. The link distance must be specified as a positive distance.
- **link_axis**
The axis to link to.
- **link_option**
See the table below.

link_option value	Description
1	Link starts when registration event occurs on link axis.
2	Link starts at an absolute position on link axis (see link_position).
4	CAMBOX repeats automatically and bidirectionally. This option is cancelled by setting bit 1 of REP_OPTION parameter (REP_OPTION = REP_OPTION OR 2).
5	Combination of options 1 and 4.
6	Combination of options 2 and 4.

- **link_position**
The absolute position where **CAMBOX** will start when **link_option** is set to 2.
Note: When the **CAMBOX** command is executing, the **ENDMOVE** parameter is set to the end of the previous move. The **REMAIN** axis parameter holds the remainder of the distance on the link axis.

Example ' Subroutine to generate a SIN shape speed profile
 ' Uses: p is loop counter
 ' num_p is number of points stored in tables pos 0..num_p
 ' scale is distance travelled scale factor
profile_gen:
 num_p=30
 scale=2000
 FOR p=0 TO num_p
 TABLE(p,(-SIN(PI*2*p/num_p)/(PI*2))+p/num_p)*scale)
 NEXT p
RETURN

This graph plots TABLE contents against table array position. This corresponds to motor POSITION against link POSITION when called using **CAMBOX**. The **SPEED** of the motor will correspond to the derivative of the position curve above.

fig. 7





fig. 8



Example A pair of rollers feeds plastic film into a machine. The feed is synchronised to a master encoder and is activated when the master reaches a position held in the variable **start**. This example uses the table points 0...30 generated in the example above:

```


start=1000
FORWARD AXIS(1)
WHILE IN(2)=OFF
  CAMBOX(0,30,800,80,15,2,start)
  WA(10)
  WAIT UNTIL MTYPE=0 OR IN(2)=ON
WEND
CANCEL
CANCEL AXIS(1)
WAIT IDLE

```

The arguments of the **CAMBOX** command are:

- 0 is the start of the profile shape in the TABLE
- 30 is the end of the profile shape in the TABLE
- 800 scales the TABLE values. Each **CAMBOX** motion therefore totals 800*2000 encoder edges steps.
- 80 is the distance on the product conveyor to link the motion to. The units for this parameter are the programmed distance units on the link axis.
- 15 specifies the axis to link to.
- 2 is the link option setting. It means: Start at absolute position on the link axis.
- The variable **start** holds a position. The motion will execute when this position is reached on axis 15.

fig. 9



Example A motor on Axis 0 is required to emulate a rotating mechanical CAM. The position is linked to motion on axis 3. The "shape" of the motion profile is held in TABLE values 1000..1035. The table values represent the mechanical cam but are scaled to range from 0-4000.

```
TABLE(1000,0,0,167,500,999,1665,2664,3330,3497,3497)
TABLE(1010,3164,2914,2830,2831,2997,3164,3596,3830,3996,3996)
TABLE(1020,3830,3497,3330,3164,3164,3164,3330,3467,3467,3164)
TABLE(1030,2831,1998,1166,666,333,0)
```

```
BASE(3)
MOVEABS(130)
WAIT IDLE
```

'start the continuously repeating cambox

```
CAMBOX(1000,1035,1,360,3,4) AXIS(0)
```

FORWARD start camshaft axis

WAIT UNTIL IN(2)=OFF

REP_OPTION = 2 'cancel repeating mode by setting bit 1

WAIT IDLE AXIS(0) waits for cam cycle to finish

CANCEL 'stop camshaft axis

WAIT IDLE

Note: The system software resets bit 1 of REP_OPTION after the repeating mode has been cancelled.

Setting bit 3 (value 8) of the link options parameter enables the **CAMBOX** pattern mode. This mode enables a sequence of scale values to be cycled automatically. This is normally combined with the automatic repeat mode, so the options parameter must be set to 12. This diagram shows a typical repeating pattern which can be automated with the **CAMBOX** pattern mode.


The parameters for this mode are treated differently to the standard **CAMBOX** function:

CAMBOX(start, end, control block pointer, link dist, link axis,options)

The start and end parameters specify the basic shape profile ONLY. The pattern sequence is specified in a separate section of the TABLE memory. There is a new TABLE block defined: The "Control Block". This block of seven TABLE values defines the pattern position, repeat controls etc. The block is fixed at 7 values long.

Therefore in this mode only there are 3 independently positioned TABLE blocks used to define the required motion:

fig. 10



- SHAPE BLOCK: This is directly pointed to by the **CAMBOX** command as in any **CAMBOX**.
- CONTROL BLOCK: This is pointed to by the third **CAMBOX** parameter in this options mode only. It is of fixed length (7 table values). It is important to note that the control block is modified during the **CAMBOX** operation. It must therefore be re-initialised prior to each use.
- PATTERN BLOCK: The start and end of this are pointed to by 2 of the CONTROL BLOCK values. The pattern sequence is a sequence of scale factors for the SHAPE.

The table below gives the CONTROL BLOCK parameters

Note: READ/WRITE values can be written to by the user program during the pattern **CAMBOX** execution.

Value	Parameter	R/W	Description
0	CURRENT POSITION	R	The current position within the TABLE of the pattern sequence. This value should be initialised to the START PATTERN number.
1	FORCE POSITION	R/W	Normally this value is -1. If at the end of a SHAPE the user program has written a value into this TABLE position the pattern will continue at this position. The system software will then write -1 into this position. The value written must be inside the pattern such that the value: CB(2)<=CB(1)<=CB(3)
2	START PATTERN	R	The position in the TABLE of the first pattern value.
3	END PATTERN	R	The position in the TABLE of the final pattern value.
4	REPEAT POSITION	R/W	The current pattern repeat number. Initialise this number to 0. The number will increment when the pattern repeats if the link axis motion is in a positive direction. The number will decrement when the pattern repeats if the link axis motion is in a negative direction. Note that the counter runs starting at zero: 0,1,2,3...

Value	Parameter	R/W	Description
5	REPEAT COUNT	R/W	<p>Required number of pattern repeats. If -1 the pattern repeats endlessly. The number should be positive. When the ABSOLUTE value of CB(4) reaches CB(5) the CAMBOX finishes if CB(6)=-1. The value can be set to 0 to terminate the CAMBOX at the end of the current pattern.</p> <p>The axis the CAMBOX is linked to can run in a positive or negative direction. In the case of a negative direction link the pattern will execute in reverse. In the case where a certain number of pattern repeats is specified with a negative direction link, the first control block will produce one repeat less than expected. This is because the CAMBOX loads a zero link position which immediately goes negative on the next servo cycle triggering a REPEAT COUNT. This effect only occurs when the CAMBOX is loaded, not on transitions from CONTROL BLOCK to CONTROL BLOCK. This effect can easily be compensated for either by increasing the required number of repeats, or setting the initial value of REPEAT POSITION to 1.</p>
6	NEXT CONTROL BLOCK	R/W	If set to -1 the pattern will finish when the required number of repeats are done. Alternatively a new control block pointer can be used to point to a further control block.

Example A quilt stitching machine runs a feed cycle that stitches a plain pattern before it starts a patterned stitch. The plain pattern must run for 1000 cycles. Then, it must run a pattern continuously, until requested to stop at the end of the pattern. The cam profile controls the motion of the needle bar between moves.

The pattern table controls the distance of the move to make the pattern. The same shape is used for the initialisation cycles and the pattern. This shape is held in TABLE values 100..150. The running pattern sequence is held in TABLE values 1000..4999. The initialisation pattern is a single value held in TABLE(160). The initialisation control block is held in TABLE(200)..TABLE(206). The running control block is held in TABLE(300)..TABLE(306).

' Set up Initialisation control block:

TABLE(200,160,-1,160,160,0,1000,300)

' Set up running control block:

TABLE(300,1000,-1,1000,4999,0,-1,-1)

' Run whole lot with single CAMBOX:

' Third parameter is pointer to first control block

CAMBOX(100,150,200,5000,1,20)

WAIT UNTIL IN(7)=OFF


TABLE(305,0) ' Set zero repeats: This will stop at end of pattern

Note: The axis to which the CAMBOX is linked can run in a positive or negative direction. In the case of a negative direction link, the pattern executes in reverse. In the case where a certain number of pattern repeats is specified with a negative direction link, the first control block produces one repeat less than expected. This is because the CAMBOX loads a zero link position which immediately goes negative on the next servo cycle triggering a REPEAT COUNT. This effect only occurs when the CAMBOX is loaded, not on transitions from CONTROL BLOCK to CONTROL BLOCK. This effect can easily be compensated for: either increase the required number of repeats, or set the initial value of REPEAT POSITION to 1.

See also

AXIS, CAM, REP_OPTION, TABLE

fig. 11



3.2.46 CAN_CORT

Type	System command	Description	The CAN_CORT commands where the second argument is 4 through 10 are normally used in a BASIC program that is run at startup. The sequence of the CAN_CORT commands that configure a CANopen network is important.
Syntax	<p>CAN_CORT(unit,4,0) Retrieves the unit status. See the table in section 4.6.2.</p> <p>CAN_CORT(unit,5,bit_rate) Initialises the TJ1-CORT with the desired bit rate.</p> <p>CAN_CORT(unit,6,node_ID,mandatory_flag) Add a slave node to the TJ1-CORT and indicate whether it is permanently available on the network.</p> <p>CAN_CORT(unit,7,PDO_number,area_type,start_address,COB_ID, obj_type, obj_type,...) Configure an RPDO.</p> <p>CAN_CORT(unit,8,PDO_number,area_type,start_address,COB_ID, inhibit_time,event_timer,obj_type, obj_type,...) Configure a TPDO.</p> <p>CAN_CORT(unit,9,node_ID,index,subindex,byte1,byte2,...) Make the TJ1-CORT configure an object in a slave during the CANopen network initialization.</p> <p>CAN_CORT(unit,10) Start the CANopen network and map the Trajexia memory to RPDOs and TPDOs.</p> <p>CAN_CORT(unit,11,mode) Set the CANopen network to pre-operational or operational state.</p> <p>CAN_CORT(unit,12,node_ID,index,subindex,VR_address) Reads the value of a CANopen node object using an SDO (Service Data Object) command into the VR array. Each byte of the returned value occupies one VR address.</p> <p>CAN_CORT(unit,13,node_ID,index,subindex,VR_address,data_len) Write a value of a CANopen node object using an SDO command using the VR array as source. Each VR address is interpreted as one byte of the value that is written.</p> <p>CAN_CORT(unit,14,node_ID,VR_address) Reads the EMCY (emergency) message from a node into the VR array. Each byte of the eight bytes occupies one VR address.</p>	Arguments	<ul style="list-style-type: none"> • unit The sequence number of the unit. • bit_rate The bit rate on the CAN bus. Valid values are 2 (500 Kbps), 3 (250 Kbps), 4 (125 Kbps), 5 (50 Kbps) and 6 (20 Kbps). • node_ID The CANopen node on the CAN bus. • mandatory_flag The mandatory flag of the node. <ul style="list-style-type: none"> - 0 = optional, no error occurs when the node is not in the network. - 1= mandatory, an error occurs when the node is not in the network. • PDO_number Identification of an individual PDO. PDO_number can range from 0 to 7. • area_type The memory area in Trajexia: 1 = VR, 2 = TABLE, 3 = Digital I/O, 4 = Analog I/O. • start_address The array index in the VR, TABLE, IN, OP, AIN or AOUT array. • COB_ID The COB (Controller Object Identification) ID used to identify a PDO in a CANopen network. • obj_type The CANopen object type. Valid values are: 2 = INT8, 3 = INT16, 4 = INT32, 5 = UINT8, 6 = UINT16, 7 = UINT32. • inhibit_time The minimum time in 0.1 ms units between two consecutive transmissions of a TPDO. • event_timer The maximum time in ms units that is observed between two consecutive transmissions of a TPDO. If this value is 0, the time is unlimited. The TPDO is sent only when the contents changes. • index The index of the addressed CANopen object. • subindex The subindex within the addressed CANopen object.

- **mode**
The CANopen network operation mode. 0 = pre-operational, 1 = operational.
- **VR_address**
The index in the VR array.
- **data_len**
The amount of bytes to transfer.

Example No example.

See also N/A

3.2.47 CANCEL

Type Axis command

Syntax **CANCEL[(1)]**
CA[(1)]

Description The **CANCEL** command cancels the move on an axis or an interpolating axis group. Speed-profiled moves (**FORWARD**, **REVERSE**, **MOVE**, **MOVEABS**, **MOVECIRC**, **MHELICAL** and **MOVEMODIFY**) will be decelerated at the deceleration rate as set by the **DECCEL** parameter and then stopped. Other moves will be immediately stopped.
 The **CANCEL** command cancels the contents of the current move buffer (**MTYPE**). The command **CANCEL(1)** cancels the contents of the next move buffer (**NTYPE**) without affecting the current move in the **MTYPE** buffer.
CANCEL works on the default basis axis (set with **BASE**) unless **AXIS** is used to specify a temporary base axis.

Note:


- **CANCEL** cancels only the presently executing move. If further moves are buffered they will then be loaded.
- During the deceleration of the current move additional **CANCELs** will be ignored.
- **CANCEL(1)** cancels only the presently buffered move. Any moves stored in the task buffers indicated by the **PMOVE** variable can be loaded into the buffer as soon as the buffered move is cancelled.

Arguments N/A

Example **FORWARD**
WA(10000)
CANCEL ' Stop movement after 10 seconds

Example **MOVE(1000)**
MOVEABS(3000)
CANCEL ' Cancel the move to 3000 and move to 4000 instead.
MOVEABS(4000)
Note that the command **MOVEMODIFY** is a better solution for modifying end points of moves in this case.

fig. 12




Example Two axes are connected with a ratio of 1:2. Axis 0 is cancelled after 1 second, then axis 1 is cancelled when the speed drops to a specified level. After the first cancel axis 1 decelerates at the **DECCEL** rate. When the **CONNECT** of axis 1 is cancelled, axis 1 stops instantly.

```
BASE(0)
SPEED=10000
FORWARD
CONNECT(0.5,0) AXIS(1)
WA(1000)
CANCEL
WAIT UNTIL VP_SPEED<=7500
CANCEL AXIS(1)
```

See also **AXIS, MTYPE, NTYPE, PMOVE, RAPIDSTOP**

fig. 13



3.2.48 CHECKSUM

Type	System parameter (read-only)
Syntax	CHECKSUM
Description	The CHECKSUM parameter contains the checksum for the programs in RAM. At start-up, the checksum is recalculated and compared with the previously held value. If the checksum is incorrect the program will not run.
Arguments	N/A
Example	No example.
See also	N/A

3.2.49 CHR

Type	I/O command
Syntax	CHR(x)
Description	The CHR command is used to send individual ASCII characters which are referred to by number. PRINT CHR(x) ; is equivalent to PUT(x) in some other versions of BASIC.
Arguments	<ul style="list-style-type: none"> • x A BASIC expression.
Example	>>PRINT CHR(65); A
See also	N/A

3.2.50 CLEAR

Type	System command
Syntax	CLEAR

Description	The CLEAR command resets all global VR variables to 0 and sets local variables on the process on which the command is run to 0. When you use it in a program it resets all local variables defined to 0.
Arguments	N/A
Example	<pre>>>VR(0)=22: VR(20)=44.3158: VR(300)=-12 >>PRINT VR(0), VR(20), VR(300) 22.0000 44.3158 -12.0000 >>CLEAR >>PRINT VR(0), VR(20), VR(300) 0.0000 0.0000 0.0000</pre>
See also	<ul style="list-style-type: none"> • RESET, VR

3.2.51 CLEAR_BIT

Type	System command
Syntax	CLEAR_BIT(bit_number, vr_number)
Description	The CLEAR_BIT command resets the specified bit in the specified VR variable. Other bits in the variable keep their values.
Arguments	<ul style="list-style-type: none"> • bit_number The number of the bit to be reset. Range: 0 - 23. • vr_number The number of the VR variable for which the bit will be reset. Range: 0 - 1023.
Example	<pre>>>PRINT VR(17) 112.0000 >>CLEAR_BIT(5, 17) >>PRINT VR(17) 80.0000</pre>
See also	READ_BIT, SET_BIT, VR.

3.2.52 CLEAR_PARAMS

Type	System command
------	----------------

Syntax	CLEAR_PARAMS	Description	The CLUTCH_RATE axis parameter defines the change in connection ratio when using the CONNECT command. The rate is defined as amount of ratio per second. The default value is set to a high value (1000000) in order to ensure compatibility with previous TJ1-MC_ units. Note: The operation using CLUTCH_RATE is not deterministic in position. If required, use the MOVELINK command instead to avoid unnecessary phase difference between base axis and linked axis.
Description	Clears all variables and parameters stored in flash EPROM to their default values. The CLEAR_PARAM will erase (set to 0) all the VR's stored using FLASHVR command. This command cannot be performed if the controller is locked.	Arguments	N/A
Arguments	N/A	Example	No example.
Example		See also	N/A

3.2.53 CLOSE_WIN

Type	Axis parameter
Syntax	CLOSE_WIN CW
Description	The CLOSE_WIN axis parameter defines the end of the window inside or outside which a registration mark is expected. The value is in user units.
Arguments	N/A
Example	CLOSE_WIN=10
See also	AXIS, OPEN_WIN, REGIST, UNITS.

3.2.54 CLUTCH_RATE

Type	Axis parameter
Syntax	CLUTCH_RATE

Arguments	N/A
Example	CLUTCH_RATE = 4
See also	AXIS, CONNECT, MOVELINK.

3.2.55 COMMSERROR

Type	System parameter (read-only)
Syntax	COMMSERROR
Description	The COMMSERROR parameter contains the communication errors that have occurred since the last time that it was initialized. The bits in COMMSERROR are given in the table below.

Bit	Description	Error location
8	Port 1 Rx data ready	Serial port 1
9	Port 1 Rx Overrun	Serial port 1
10	Port 1 Parity Error	Serial port 1
11	Port 1 Rx Frame Error	Serial port 1
12	Port 2 Rx data ready	Serial port 2
13	Port 2 Rx Overrun	Serial port 2
14	Port 2 Parity Error	Serial port 2
15	Port 2 Rx Frame Error	Serial port 2

3.2.57 COMPILE

Arguments N/A

Example No example.

See also N/A

Type Program command

Syntax **COMPILE**

Description The **COMPILE** command forces the compilation of the currently selected program to intermediate code. Programs are compiled automatically by the system software prior to program execution or when another program is selected. This command is not therefore normally required.

Arguments N/A

Example No example.

See also N/A

3.2.56 COMMSTYPE

Type Slot parameter

Syntax **COMMSTYPE SLOT(unit_number)**

Description This parameter returns the type of unit in a controller unit. The table below lists the return values.

Return value	Description
0	Unused unit
31	TJ1-ML__
33	TJ1-FL02
34	TJ1-PRT
35	TJ1-DRT
38	TJ1-CORT

Arguments • **unit_number**


Unit numbers are 0 to 6, with 0 being the unit immediately to the right of the TJ1-MC__.

Example No example.

See also N/A

3.2.58 CONNECT

Type	Axis command
Syntax	CONNECT(ratio, driving_axis) CO(ratio, driving_axis)
Description	<p>The CONNECT command connects the demand position of the base axis to the measured movements of the axis specified by driving_axis to achieve an electronic gearbox.</p> <p>The ratio can be changed at any time by executing another CONNECT command on the same axis. To change the driving axis the CONNECT command needs to be cancelled first. CONNECT with different driving axis will be ignored. The CONNECT command can be cancelled with a CANCEL or RAPIDSTOP command. The CLUTCH_RATE axis parameter can be used to set a specified connection change rate.</p> <p>CONNECT works on the default basis axis (set with BASE) unless AXIS is used to specify a temporary base axis.</p>
Arguments	<ul style="list-style-type: none"> • ratio The connection ratio of the gearbox. The ratio is specified as the encoder edge ratio (not units). It holds the number of edges the base axis is required to move per edge increment of the driving axis. The ratio value can be either positive or negative and has sixteen bit fractional resolution. • driving_axis The Master axis which will drive the base axis. Note: To achieve an exact connection of fractional ratio's of values such as 1024/3072 the MOVELINK command can be used with the continuous repeat link option set to ON.
Example	<p>In a press feed, a roller is required to rotate at a speed that is equal to one quarter of the measured rate from an encoder installed on the incoming conveyor. The roller is wired to the master axis 0. The reference encoder is connected to axis 1.</p> <pre>BASE(0) SERVO=ON CONNECT(0.25,1)</pre>




Example A machine has an automatic feed on axis 1 that must move at a set ratio to axis 0. This ratio is selected using inputs 0-2 to select a particular "gear". This ratio can be updated every 100 ms. Combinations of inputs select the intermediate gear ratios. For example, 1 ON and 2 ON gives a ratio of 6:1.

```

BASE(1)
FORWARD AXIS(0)
WHILE IN(3)=ON
  WA(100)
  gear = IN(0,2)
  CONNECT(gear,0)
WEND
RAPIDSTOP cancel the FORWARD and the CONNECT

```

fig. 15



Example Axis 0 is required to run a continuous forward. Axis 1 must connect to axis 0. If **CONNECT** is called, it results in a step change. Therefore, **CLUTCH_RATE** is used, together with an initial and final connect ratio of zero, to get the required motion.


```

FORWARD AXIS(0)
BASE(1)
CONNECT(0,0) 'set intitial ratio to zero
CLUTCH_RATE=0.5 'set clutch rate
CONNECT(2,0) 'apply the required connect ratio
WA(8000)
CONNECT(0,0) 'apply zero ratio to disconnect
WA(4000) 'wait for deceleration to complete
CANCEL 'cancel connect

```

See also **AXIS, CANCEL, CLUTCH_RATE, CONNECT, RAPIDSTOP.**

fig. 16



3.2.59 CONSTANT

Type	System command
Syntax	CONSTANT "name", value
Description	<p>Declares the name as a constant for use both within the program containing the CONSTANT definition and all other programs in the Trajexia Tools project.</p> <p>Note: The program containing the CONSTANT definition must be run before the name is used in other programs. In addition, only that program should be running at the time the CONSTANT is executed, otherwise the program error will appear and the program will stop when trying to execute this command. For fast startup the program should also be the only process running at power-up.</p> <p>When the CONSTANT is declared, the declaration remains active until the next TJ1-MC__ reset by switching the power off and back on, or by executing the EX command.</p> <p>A maximum of 128 CONSTANTS can be declared.</p>
Arguments	<ul style="list-style-type: none"> • name Any user-defined name containing lower case alpha, numerical or underscore characters. • value The value assigned to name.
Example	<pre>CONSTANT "nak", \$15 CONSTANT "start_button", 5 IF IN(start_button)=ON THEN OP(led1, ON) IF key_char=nak THEN GOSUB no_ack_received</pre>
See also	N/A

3.2.60 CONTROL

Type	System parameter (read-only)
Syntax	CONTROL

Description The **CONTROL** parameter returns the type of TJ1-MC__ in the system. The value of this system parameter for the TJ1-MC16 is 262, and for the TJ1-MC04 the value is 263.

Note: When the Motion Controller is locked, 1000 is added to above values, so e.g. a locked TJ1-MC16 will return 1262.

Arguments N/A

Example No example.

See also N/A

3.2.61 COPY

Type	Program command
Syntax	COPY program_name new_program_name
Description	<p>The COPY command copies an existing program in the controller to a new program with the specified name. The program name can be specified without quotes.</p> <p>Note: This command is implemented for the Command Line Terminal. Within Trajexia Tools users can select the command from the Program menu.</p>
Arguments	<ul style="list-style-type: none"> • program_name Name of the program to be copied. • new_program_name Name to use for the new program.
Example	>> COPY "prog" "newprog"
See also	DEL, NEW, RENAME .

3.2.62 COS

Type	Mathematical function
Syntax	COS(expression)

Description	The COS function returns the cosine of the expression. Input values are in radians and may have any value. The result value will be in the range from -1 to 1.
Arguments	<ul style="list-style-type: none"> • expression Any valid BASIC expression.
Example	>> PRINT COS(0) 1.0000
See also	N/A

3.2.63 CREEP

Type	Axis parameter
Syntax	CREEP
Description	<p>The CREEP axis parameter contains the creep speed for the axis. The creep speed is used for the slow part of an origin search sequence. CREEP can have any positive value, including 0.</p> <p>The creep speed is entered in units/sec with the unit conversion factor UNITS. For example, if the unit conversion factor is set to the number of encoder edges/inch, the speed is set in inches/sec.</p>
Arguments	N/A
Example	BASE(2) CREEP=10 SPEED=500 DATUM(4) CREEP AXIS(1)=10 SPEED AXIS(1)=500 DATUM(4) AXIS(1)
See also	AXIS, DATUM, UNITS.

3.2.64 D_GAIN

Type	Axis parameter
Syntax	D_GAIN
Description	<p>The D_GAIN axis parameter contains the derivative gain for the axis. The derivative output contribution is calculated by multiplying the change in Following Error with D_GAIN. The default value is 0.</p> <p>Add the derivative gain to a system to produce a smoother response and to allow the use of a higher proportional gain that could not be used otherwise. High values can cause oscillation.</p> <p>Note: The servo gain must only be changed when the SERVO is off.</p> <p>Note: Servo gains have no affect on stepper output axis, ATYPE=46.</p>
Arguments	N/A
Example	D_GAIN=0.25
See also	<ul style="list-style-type: none"> • AXIS, I_GAIN, OV_GAIN, P_GAIN, VFF_GAIN.

3.2.65 D_ZONE_MAX

Type	System parameter
Syntax	D_ZONE_MAX=value
Description	<p>This parameter works in conjunction with D_ZONE_MIN to clamp the DAC output to zero when the demand movement is complete and the magnitude of the Following Error is less than the D_ZONE_MIN value. The servo loop will be reactivated when either the Following Error rises above the D_ZONE_MAX value, or a fresh movement is started.</p>
Arguments	N/A
Example	D_ZONE_MIN=3 D_ZONE_MAX=10
	<p>With these 2 parameters set as above, the DAC output will be clamped at zero when the movement is complete and the Following Error falls below 3. When a movement is restarted or if the Following Error rises above a value of 10, the servo loop will be reactivated.</p>

See also **D_ZONE_MIN.**

3.2.66 D_ZONE_MIN

Type System parameter

Syntax **D_ZONE_MIN=value**

Description This parameter works in conjunction with **D_ZONE_MAX** to clamp the DAC output to zero when the demand movement is complete and the magnitude of the Following Error is less than the **D_ZONE_MIN** value. The servo loop will be reactivated when either the Following Error rises above the **D_ZONE_MAX** value, or a fresh movement is started.

Arguments N/A

Example **D_ZONE_MIN=3**
D_ZONE_MAX=10

With these 2 parameters set as above, the DAC output will be clamped at zero when the movement is complete and the Following Error falls below 3. When a movement is restarted or if the Following Error rises above a value of 10, the servo loop will be reactivated.

See also **D_ZONE_MAX.**

3.2.67 DAC

See **S_REF.**

3.2.68 DAC_OUT

See **S_REF_OUT.**

3.2.69 DAC_SCALE

Type Axis parameter

Syntax **DAC_SCALE**

Description The **DAC_SCALE** axis parameter is an integer multiplier which is applied between the servo control loop output and the Digital to Analog Converter which output is supplied to the Servo Driver. Its value is set to 16 on axes with a 16 bit Digital to Analog Converter, which are Flex axis types. This scales the values applied to the higher resolution **DAC** so that the gains required on the axis are similar to those required on the other controllers.

DAC_SCALE may be set negative (-16) to reverse the polarity of the DAC output signal. This is useful in case if e.g. absolute SSI encoder used has no capability of changing default CW/CCW rotation direction and the default direction is opposite to the one of the Servo Driver used.

Note: When the SERVO is OFF for a given axis, the magnitude of **DAC_SCALE** is not important as the voltage applied is controlled by the **DAC** parameter. The polarity is still reversed however by **DAC_SCALE**.

Note: The default **DAC_SCALE** value for MECHATROLINK-II axis types is 1.

Arguments N/A

Example **DAC_SCALE AXIS(3)=-16**

See also **DAC, S_REF.**

3.2.70 DATE

Type System parameter

Syntax **DATE**

Description Returns or sets the current date held by the Trajexia's real time clock. The number may be entered in DD:MM:YY or DD:MM:YYYY format.

Arguments N/A

Example **DATE=20:10:05**

or

DATE=20:10:2005

Example **>>PRINT DATE**

36956

This prints the number representing the current day. This number is the number of days since 1st January 1900, with 1 Jan. 1900 represented as 1.

See also N/A

3.2.71 DATE\$

Type System command

Syntax **DATE\$**

Description Prints the current date DD/MM/YY as a string to the communication port. A 2-digit year description is given.

Arguments N/A

Example **PRINT #1, DATE\$**

This will print the date in format for example: 20/10/05

See also N/A

3.2.72 DATUM

Type Axis command

Syntax **DATUM(sequence)**Description The **DATUM** command performs one of 6 origin search sequences to position an axis to an absolute position and also reset the error bits in **AXISSTATUS** axis parameter.

DATUM uses both the creep and demand speed for the origin search. The creep speed in the sequences is set with the **CREEP** axis parameter and the demand speed is set with the **SPEED** axis parameter. The datum switch input number, used for sequences 3 to 6, is set by the **DATUM_IN** parameter.

DATUM works on the default basis axis (set with **BASE**) unless **AXIS** is used to specify a temporary base axis.

Note: The origin input set with the **DATUM_IN** parameter is active low, i.e., the origin switch is set when the input is OFF. The feedhold, reverse jog, forward jog, forward and reverse limit inputs are also active low. Active low inputs are used to enable fail-safe wiring.

Arguments

- **sequence**

See the table below.

sequence value	Description
0	<p>The DATUM(0) command will clear the motion error. The currently measured position is set as the demand position (this is especially useful on stepper axes with position verification). DATUM(0) also clears the Following Error that exceeded the FE_LIMIT condition in the AXISSTATUS register for ALL axes.</p> <p>It sets these bits in AXXISSTATUS to zero:</p> <ul style="list-style-type: none"> Bit 1 : Following Error Warning. Bit 2 : Remote Driver Comms Error. Bit 3 : Remote Driver Error. Bit 8 : Following Error Limit Exceeded. Bit 11 : Cancelling Move. <p>Note that the status can not be cleared if the cause of the problem is still present. DATUM(0) must only be used after the WDOG is set to OFF, otherwise there will be unpredictable errors on the motion.</p>
1	The axis moves at creep speed forward until the Z marker is encountered. The demand position is then reset to 0 and the measured position corrected so as to maintain the Following Error.
2	The axis moves at creep speed in reverse until the Z marker is encountered. The demand position is then reset to 0 and the measured position corrected so as to maintain the Following Error.
3	The axis moves at the demand speed forward until the datum switch is reached. The axis then moves reverse at creep speed until the datum switch is reset. The demand position is then reset to 0 and the measured position corrected so as to maintain the Following Error.
4	The axis moves at the demand speed in reverse until the datum switch is reached. The axis then moves forward at creep speed until the datum switch is reset. The demand position is then reset to 0 and the measured position corrected so as to maintain the Following Error.
5	The axis moves at demand speed forward until the datum switch is reached. The axis then reverses at creep speed until the datum switch is reset. The axis continues in reverse at creep speed until the Z marker of the encoder is encountered. The demand position is then reset to 0 and the measured position corrected so as to maintain the Following Error.

sequence value	Description
6	The axis moves at demand speed reverse until the datum switch is reached. The axis then moves forward at creep speed until the datum switch is reset. The axis continues forward at creep speed until the Z marker of the encoder is encountered. The demand position is then reset to 0 and the measured position corrected so as to maintain the Following Error.

Example A production line must stop if something blocks the product belt, which causes a motion error. The obstacle must be removed, and a reset button must be pressed to restart the line.


```

FORWARD 'start production line
WHILE IN(2)=ON
  IF MOTION_ERROR=0 THEN
    OP(8,ON) 'green light on; line is in motion
  ELSE
    OP(8, OFF)
    GOSUB error_correct
  ENDIF
WEND
CANCEL
STOP

error_correct:
REPEAT
  OP(10,ON)
  WA(250)
  OP(10,OFF) 'flash red light to show crash
  WA(250)
UNTIL IN(1)=OFF
DATUM(0) 'reset axis status errors
SERVO=ON 'turn the servo back on
WDOG=ON 'turn on the watchdog
OP(9,ON) 'sound siren that line will restart
WA(1000)
OP(9,OFF)
FORWARD 'restart motion
RETURN

```


fig. 17



Example The position of an axis must be defined by the Z marker. This position must be set to zero. Then the axis must move to this position. Using the datum 1 the zero point is set on the Z mark. But the axis starts to decelerate at this point, and therefore it stops after the mark. A move is used to bring it back to the Z position.

```


SERVO=ON
WDOG=ON
CREEP=1000 'set the search speed
SPEED=5000 'set the return speed
DATUM(1) 'register on Z mark and sets this to datum
WAIT IDLE
MOVEABS (0) 'moves to datum position
  
```



Example A machine must return to its home position defined by the limit switch which is found at the rear of the move before operation. This can be achieved through using **DATUM(4)** which moves in reverse to find the switch.

```

SERVO=ON
WDOG=ON
REV_IN=-1 'temporarily turn off the limit switch function
DATUM_IN=5 'sets input 5 for registration
SPEED=5000 'set speed, for quick location of limit switch
CREEP=500 'set creep speed for slow move to find edge of switch
DATUM(4) 'find edge at creep speed and stop
WAIT IDLE
DATUM_IN=-1
REV_IN=5 'restore input 5 as a limit switch again
  
```



Example A machine similar to the machine in the example above must locate a home switch, which is at the forward end of the move. The machine then moves backwards to the next Z marker, and set this Z marker as the datum. This is done with **DATUM(5)**, which moves forward at **SPEED** to locate the switch, then reverses at **CREEP** to the Z marker. If required, a move is made to the datum Z marker.

SERVO=ON

WDOG=ON

DATUM_IN=7 'sets input 7 as home switch

SPEED=5000 'set speed, for quick location of switch


CREEP=500 'set creep speed for slow move to find edge of switch

DATUM(5) 'start the homing sequence

WAIT IDLE

See also **ACCEL, AXIS, AXISSTATUS, CREEP, DATUM_IN, DECEL, MOTION_ERROR, SPEED.**

fig. 20



Note

The current Trajexia firmware version (1.6652) does not properly support this command for Sigma-V Servo Drivers.

3.2.73 DATUM_IN

See also N/A

Type	Axis parameter
Syntax	DATUM_IN DAT_IN
Description	<p>The DATUM_IN axis parameter contains the input number to be used as the datum switch input for the DATUM command. The valid input range is given by 0 to 31. Values 0 to 15 represent physically present inputs of TJ1-MC__ I/O connector and are common for all axes.</p> <p>Values 16 to 31 are mapped directly to driver inputs that are present on the CN1 connector. They are unique for each axis. It depends on the type of Servo Driver which Servo Driver inputs are mapped into inputs 16 to 31. For more information on Servo Driver I/O mapping into the Trajexia I/O space, refer to section 6.1.4.</p> <p>Note: The origin input is active low, i.e., the origin switch is set when the input is OFF. The feedhold, reverse jog, forward jog, forward and reverse limit inputs are also active low. Active low inputs are used to enable fail-safe wiring.</p>
Arguments	N/A
Example	DATUM_IN AXIS(0)=5
See also	AXIS , DATUM .

3.2.74 DAY

Type	System parameter
Syntax	DAY
Description	Returns the current day as a number 0..6, Sunday is 0. DAY can be set by assignment.
Arguments	N/A
Example	>>DAY=3 >>? DAY 3.0000

3.2.75 DAY\$

Type	System command
Syntax	DAY\$
Description	Prints the current day as a string.
Arguments	N/A
Example	>>DAY=3 >>? DAY\$ Wednesday
See also	N/A

3.2.76 DECEL

Type	Axis parameter
Syntax	DECEL
Description	The DECEL axis parameter contains the axis deceleration rate. The rate is set in units/s ² . The parameter can have any positive value including 0.
Arguments	N/A
Example	DECEL = 100 ' Set deceleration rate PRINT " Deceleration rate is ";DECEL;" mm/s/s"
See also	ACCEL , AXIS , UNITS .

3.2.77 DEFPOS

Type	Axis command
Syntax	DEFPOS(pos_1 [, pos_2 [, pos_3 [, pos_4 [, ...]]]]) DP(pos_1 [, pos_2 [, pos_3 [, pos_4 [, ...]]]])
Description	<p>The DEFPOS command defines the current demand position (DPOS) as a new absolute position. The measured position (MPOS) will be changed accordingly in order to keep the Following Error. DEFPOS is typically used after an origin search sequence (see DATUM command), as this sets the current position to 0. DEFPOS can be used at any time.</p> <p>As an alternative also the OFFPOS axis parameter can be used. This parameter can be used to perform a relative adjustment of the current position.</p> <p>DEFPOS works on the default basis axis or axis sequence group (set with BASE) unless AXIS is used to specify a temporary base axis.</p> <p>Note: The changes to the axis position made using DEFPOS or OFFPOS are made on the next servo update. This can potentially cause problems when a move is initiated in the same servo period as the DEFPOS or OFFPOS.</p> <p>The following example shows how the OFFPOS parameter can be used to avoid this problem. DEFPOS commands are internally converted into OFFPOS position offsets, which provides an easy way to avoid the problem by programming as follows:</p> <p>DEFPOS(100): WAIT UNTIL OFFPOS = 0: MOVEABS(0)</p>
Arguments	<p>The command can take up to 16 arguments.</p> <ul style="list-style-type: none">• pos_i The absolute position for (base+i) axis in user units. Refer to the BASE command for the grouping of the axes.

Example After 2 axes returned to their homing positions, it is required to change the **DPOS** values so that the home positions are not zero, but some defined positions instead.

**DATUM(5) AXIS(1) ' home both axes. At the end of the DATUM
DATUM(4) AXIS(3) ' procedure, the positions are 0,0.**


WAIT IDLE AXIS(1)

WAIT IDLE AXIS(3)

BASE(1,3) ' set up the BASE array

DEFPOS(-10,-35) ' define positions of the axes to be -10 and -35


fig. 21



Example Set the axis position to 10, then start an absolute move, but make sure the axis has updated the position before loading the **MOVEABS**.

```
DEFPOS(10.0)
WAIT UNTIL OFFPOS=0
' Makes sure that DEFPOS is complete before next line
MOVEABS(25.03)
```

fig. 22



Example From the Command Line of the Terminal window, quickly set the **DPOS** values of the first four axes to 0.

```
>>BASE(0)
>>DP(0,0,0,0)
```

See also **AXIS, DATUM, DPOS, OFFPOS, MPOS, UNITS**.

fig. 23

AXIS	0	1	2	3
DPOS	12	168	37	21

BEFORE

AXIS	0	1	2	3
DPOS	0	0	0	0

AFTER

3.2.78 DEL

Type	Program command
Syntax	DEL [program_name] RM [program_name]
Description	The DEL command deletes a program from the controller. DEL without a program name can be used to delete the currently selected program (using SELECT). The program name can also be specified without quotes. DEL ALL will delete all programs. DEL can also be used to delete the Table: DEL "TABLE" . The name " TABLE " must be in quotes. Note: This command is implemented for the Command Line Terminal. Within Trajexia Tools users can select the command from the Program menu.
Arguments	<ul style="list-style-type: none"> program_name Name of the program to be deleted.
Example	>> DEL oldprog
See also	COPY, NEW, RENAME, SELECT, TABLE.

3.2.79 DEMAND_EDGES

Type	Axis parameter (read-only)
Syntax	DEMAND_EDGES
Description	The DEMAND_EDGES axis parameter contains the current value of the DPOS axis parameter in encoder edge units.
Arguments	N/A
Example	No example.
See also	AXIS, DPOS.

3.2.80 DEVICENET

Type	System command
Syntax	DEVICENET(unit_number, 2, 1, VR_start_outputs, no_outputs, VR_start_inputs, no_inputs) DEVICENET(unit_number, 4, 0)
Description	DEVICENET function 2 configures the TJ1-DRT for data exchange with the DeviceNet master unit and defines areas in the VR memory where I/O exchange takes place. DEVICENET function 4 returns the data exchange status of the TJ1-DRT. Refer to the table below for the description of the bits in the data exchange status word.

Bit	Value	Description
0	0	Command DEVICENET (unit_number, 2, ...) not executed yet
	1	Command DEVICENET (unit_number, 2, ...) executed without error
1	0	No DeviceNet I/O connection
	1	DeviceNet I/O connection running
2	0	VR variables in the output data range have been updated
	1	VR variables in the output data range have not been updated yet
3	0	DeviceNet I/O connection size matches the DEVICENET (unit_number, 2,...) command
	1	DeviceNet I/O connection size does not match the DEVICENET(unit_number, 2,...) command
4-7	0	Always zero
8	0	Network power OK
	1	Network power failure
9	0	No BUSOFF occurred
	1	BUSOFF occurred

Bit	Value	Description
10	0	No node address duplication error
	1	Node address duplication error

Example No example.

See also **FREE, POWER_UP, PROCESS, RUNTYPE, SELECT.**

- Arguments
- **unit_number**
Specifies the unit number of the TJ1-DRT in the Trajexia system.
 - **VR_start_outputs**
The starting address in VR memory of the controller where the output data from the DeviceNet master is located.
 - **no_outputs**
The number of output words from the DeviceNet master in VR memory.
 - **VR_start_inputs**
The starting address in VR memory of the controller where the input data for the DeviceNet master is located.
 - **no_inputs**
The number of input words to the DeviceNet master in VR memory.

Example **DEVICENET (0,2,1,10,16,150,31)**
In this example, the TJ1-DRT is configured to exchange data with DeviceNet master with 16 output words (received from the master) located at VR(10) to VR(25), and 31 input words (sent to the master) located at VR(150) to VR(180).

See also N/A

3.2.81 DIR

Type	Program command
Syntax	DIR LS
Description	The DIR command shows a list of the programs held in the controller, the memory size and the RUNTYPE . DIR also shows the available memory size, power up mode and current selected program of the controller. Note: This command is implemented for the Command Line Terminal only.
Arguments	N/A

3.2.82 DISABLE_GROUP

Type	Axis command
Syntax	DISABLE_GROUP(-1) DISABLE_GROUP(axis_1 [, axis_2 [, ...]])
Description	The AXIS_ENABLE is used to create a group of axes which will be disabled if there is a motion error in any or more axes in the group. After the group is made, when an error occurs on one they will all have their AXIS_ENABLE set OFF and SERVO set OFF. Multiple groups can be made, although an axis cannot belong to more than one group. All groupings can be cleared using DISABLE_GROUP(-1) . Note: For use with MECHATROLINK-II only..
Arguments	<ul style="list-style-type: none">• axis_i A BASIC expression that evaluates to an axis number.
Example	A machine has 2 functionally separate parts, which have their own emergency stop and operator protection guarding. If there is an error on one part of the machine, the other part can continue to run while the cause of the error is removed and the axis group restarted. For this, 2 separate axis groupings must be set up. DISABLE_GROUP(-1) ' remove any previous axis groupings DISABLE_GROUP(0,1,2,6) ' group axes 0 to 2 and 6 DISABLE_GROUP(3,4,5,7) ' group axes 3 to 5 and 7 WDOG=ON ' turn on the enable relay and the remote drive enable FOR ax=0 TO 7 AXIS_ENABLE AXIS(ax)=ON ' enable the 8 axes SERVO AXIS(ax)=ON ' start position loop servo for each axis NEXT ax


fig. 24

Example Two conveyors operated by the same Motion Coordinator are required to run independently, to make sure that the second conveyor does not stop if the first conveyor is blocked.

```

DISABLE_GROUP(0) 'put axis 0 in its own group
DISABLE_GROUP(1) 'put axis 1 in another group
GOSUB group_enable0
GOSUB group_enable1
WDOG=ON
FORWARD AXIS(0)
FORWARD AXIS(1)
WHILE TRUE
  IF AXIS_ENABLE AXIS(0)=0 THEN
    PRINT "motion error axis 0"
    reset_0_flag=1
  ENDIF
  IF AXIS_ENABLE AXIS(1)=0 THEN
    PRINT "motion error axis 1"
    reset_1_flag=1
  ENDIF
  IF reset_0_flag=1 AND IN(0)=ON THEN
    GOSUB group_enable0
    FORWARD AXIS(0)
    reset_0_flag=0
  ENDIF
  IF reset_1_flag=1 AND IN(1)=ON THEN
    GOSUB group_enable1
    FORWARD AXIS(1)
    reset_1_flag=0
  ENDIF
WEND
group_enable0:
  BASE(0)
  DATUM(0) ' clear motion error on axis 0
  WA(10)
  AXIS_ENABLE=ON
RETURN
group_enable1:
  BASE(1)

```



DATUM(0) ' clear motion error on axis 0

WA(10)

AXIS_ENABLE=ON

SERVO=ON

RETURN

Example One group of axes in a machine must be reset if a motion error occurs, without affecting the remaining axes. This must be done manually by clearing the cause of the error, pressing a button to clear the error flags of the controllers and re-enabling the motion.

DISABLE_GROUP(-1) 'remove any previous axis groupings

DISABLE_GROUP(0,1,2) 'group axes 0 to 2

GOSUB group_enable 'enable the axes and clear errors

WDOG=ON

SPEED=1000

FORWARD

WHILE IN(2)=ON

check axis 0, but all axes in the group will disable together

IF AXIS_ENABLE =0 THEN

PRINT "Motion error in group 0"

PRINT "Press input 0 to reset"

IF IN(0)=0 THEN 'checks if reset button is pressed

GOSUB group_enable 'clear errors and enable axis

FORWARD 'restarts the motion

ENDIF

ENDIF

WEND

STOP 'stop program running into sub routine

group_enable: 'Clear group errors and enable axes

DATUM(0) 'clear any motion errors

WA(10)

FOR axis_no=0 TO 2

AXIS_ENABLE AXIS(axis_no)=ON 'enable axes

SERVO AXIS(axis_no)=ON 'start position loop servo

NEXT axis_no

RETURN

See also N/A

3.2.83 DISPLAY

Type System parameter

Syntax **DISPLAY=value**

Description Determines the I/O channels to be displayed on the front panel LEDs. The **DISPLAY** parameter may be used to select which bank of I/O should be displayed. The parameter default value is 0. The values are in the table below.

value	Description
0	Inputs 0 to 7 (default)
1	Inputs 8 to 15
2	Inputs 16 to 23
3	Inputs 24 to 31
4	Outputs 0 to 7 (not used on Trajexia)
5	Outputs 8 to 15
6	Outputs 16 to 23
7	Outputs 24 to 31

Arguments N/A

Example **DISPLAY=5**

Shows outputs 8-15.

See also N/A

3.2.84 DPOS

Type Axis parameter (read-only)

Syntax **DPOS**

Description	<p>The DPOS axis parameter contains the demand position in user units, which is generated by the move commands in servo control. When the controller is in open loop (SERVO=OFF), the measured position (MPOS) will be copied to the DPOS in order to maintain a 0 Following Error.</p> <p>The range of the demand position is controlled with the REP_DIST and REP_OPTION axis parameters. The value can be adjusted without doing a move by using the DEFPOS command or OFFPOS axis parameter. DPOS is reset to 0 at start-up or controller reset.</p>	Example	<pre>IF NOT DRIVE_ALARM(10) AXIS(2)THEN PRINT "Failed to readalarm for Servo Driver" ELSE IF VR(10) = 0 THEN PRINT "ServoDriver healthy" ELSE PRINT "Servoalarm code: "; VR(10) ENDIF ENDIF</pre>
Arguments	N/A		
Example	<pre>>> PRINT DPOS AXIS(0) 34.000</pre> <p>The above line will return the demand position in user units.</p>	See also	<p>This example reads an alarm of the Servo Driver driving axis 2 and present that information to the user.</p>
See also	AXIS, DPOS, DEFPOS, DEMAND_EDGES, FE, MPOS, REP_DIST, REP_OPTION, OFFPOS, UNITS.		

3.2.85 DRIVE_ALARM

Type	Axis command
Syntax	DRIVE_ALARM(VR)
Description	<p>The DRIVE_ALARM function reads the current alarm of the Servo Driver that is connected to the Trajexia system via MECHATROLINK-II. Upon successful execution, the command returns -1 and stores the value in the VR memory location specified by the VR parameter. If the command cannot be executed, the value 0 is returned. The command is executed on the driver for the base axis set by BASE. The base axis can be changed with the AXIS modifier, as with all the other axis commands and parameters.</p> <p>This command waits for the response from the axis. The execution of the command can be slow and variable in time. If you require a quick response do not use this command.</p>
Arguments	<ul style="list-style-type: none"> • VR The alarm value is stored on the VR address on successful execution.

Type	Axis command
Syntax	DRIVE_CLEAR
Description	<p>The DRIVE_CLEAR command clears the alarm status of the Servo Driver connected via the MECHATROLINK-II bus. This command is not capable of clearing all the possible alarm states. Some alarms can only be cancelled by turning off the power supply (both the TJ1-MC__ and the Servo Driver), and then turning it on again. Also, an alarm will not be cleared if the cause of the alarm is still present. The command is executed on the driver for the base axis set by BASE. The base axis can be changed with the AXIS modifier, as with all the other axis commands and parameters.</p>
Arguments	N/A

Example	No example.
See also	DRIVE_STATUS .



Caution

Be sure that no Parameter Unit or Personal Computer Software is connected to the Servo Driver when executing this command. Otherwise the program task will be paused until the connection of the other device to the Servo Driver is removed.

3.2.87 DRIVE_CONTROL

See also N/A

Type	Axis parameter
Syntax	DRIVE_CONTROL
Description	When applied to an axis driven by the Servo Driver connected to the system via the MECHATROLINK-II bus, this parameter selects the data to be monitored by DRIVE_MONITOR according to the table below.
Code Description	
2	Following error (this is the real FE when ATYPE=40 is used)
8	Feedback speed (With ATYPE=41 Units=Max Speed/4000000H, with other ATYPE Units= reference units/s)
9	Command speed (units same as in Feedback Speed)
10	Target speed (units same as in Feedback Speed)
11	Torque (Force) reference (With ATYPE=42 Units=Max Torque/4000000H, with other ATYPE Units= % over nominal Torque)
14	Monitor selected with Pn813.0 Useful to monitor servo monitors (Unxxx)
15	Monitor selected with Pn813.1 Useful to monitor servo monitors (Unxxx)
When applied to an axis driven by the Servo Driver connected to the system via the TJ1-FL02, this parameter sets outputs of the TJ1-FL02. Set bit 8 of this parameter to switch on OUT 0 for an axis. Set bit 9 of this parameter to switch on OUT 1 for an axis. Keep in mind that the same outputs are used by the HW_PSWITCH command. The command is executed on the driver for the base axis set by BASE. The base axis can be changed with the AXIS modifier, as with all the other axis commands and parameters.	
Arguments	N/A
Example	DRIVE_CONTROL AXIS(2) = 256 In this example, OUT 0 is switched on for axis 2, connected using the TJ1-FL02.

3.2.88 DRIVE_INPUTS

Type	Axis parameter
Syntax	DRIVE_INPUTS
Description	This parameter monitors the status of the inputs of the Servo Driver connected via the MECHATROLINK-II bus. The parameter value is updated each SERVO_PERIOD cycle. It is a bit-wise word with the bits as listed in the table below.

Bit number	Servo Driver input signal			Description
	Sigma-II	Sigma-V	Junma	
0	P_OT	P_OT	P_OT	Forward limit switch
1	N_OT	N_OT	N_OT	Reverse limit switch
2	DEC	DEC	/DEC	Zero point return deceleration
3	PA	PA	Not used	Encoder A phase signal
4	PB	PB	Not used	Encoder B phase signal
5	PC	PC	Not used	Encoder C phase signal
6	EXT1	EXT1	/EXT1	First external latch signal
7	EXT2	EXT2	Not used	Second external latch signal
8	EXT3	EXT3	Not used	Third external latch signal
9	BRK	BRK	/BRK	Brake output
10	Reserved	HBB	E-STP	Emergency stop switch
11	Reserved	Reserved	Not used	
12	IO12	IO12	Not used	Not used
13	IO13	IO13	Not used	Not used
14	IO14	IO14	Not used	Not used

Bit number	Servo Driver input signal			Description
	Sigma-II	Sigma-V	Junma	
15	IO15	IO15	Not used	Not used

The recommended setting is: Pn81E=4321 & Pn511=654x. Refer to section 6.1.4 for more information about mapping Servo Driver inputs and outputs. The command is executed on the driver for the base axis set by **BASE**. The base axis can be changed with the **AXIS** modifier, as with all the other axis commands and parameters.

Arguments N/A

Example No example.

See also N/A

3.2.89 DRIVE_MONITOR

Type Axis parameter

Syntax **DRIVE_MONITOR**

Description This parameter contains the monitored data of the Servo Driver connected to the system via the MECHATROLINK-II bus. The data to be monitored is selected using **DRIVE_CONTROL** and can be displayed in the Trajexia Tools scope or used inside a program. The monitored data is updated each **SERVO_PERIOD**. The command is executed on the driver for the base axis set by **BASE**. The base axis can be changed with the **AXIS** modifier, as with all the other axis commands and parameters.

Arguments N/A

Example No example.

See also N/A

3.2.90 DRIVE_READ

Type Axis command

Syntax **DRIVE_READ(parameter, size, VR)**

Description The **DRIVE_READ** function reads the specified parameter of the Servo Driver connected to the Trajexia system via the MECHATROLINK-II bus. Upon successful execution, this command returns -1 and puts the read value in the VR memory location specified by the VR parameter. If the command cannot be executed, the value 0 is returned. The command is executed on the driver for the base axis set with **BASE**. It can be changed using the **AXIS** modifier, like with all the other axis commands and parameters.

Note: This command waits for the response of the axis, therefore its execution is slow and the time variable. Do not use this command together with other commands that require quick execution.

Note: Executing a **DRIVE_READ** will temporarily disable the Servo Driver Front Panel display.

Note: **DRIVE_READ** returns -1 on success. It also returns -1 with no parameter read if the parameter number does not exist or has the wrong size.

Arguments

- parameter**

The number of the parameter to be read. Note that the parameter numbers are hexadecimal. The format of the data can be found in the Servo Driver manual.

- size**

Size of the parameter is specified in bytes. For most parameters the size is normally 2 bytes. Some special parameters may be 4 bytes long. Sizes for each parameter can be found in the Servo Driver manual.

- VR**

The VR address where the read parameter is stored upon successful execution.

Example

```
IF DRIVE_READ($100,2,1) THEN
  PRINT "The Speed loop gain is: ";VR(1)
ELSE
  PRINT "The speed loop gain could not be read"
ENDIF
```

See also

DRIVE_WRITE, HEX, \$ (HEXADECIMAL INPUT).

**Caution**

Be sure that no Parameter Unit or Personal Computer Software is connected to the Servo Driver when executing this command. Otherwise the program task will be paused until the connection of the other device to the Servo Driver is removed.

3.2.91 DRIVE_RESET

Type Axis command

Syntax **DRIVE_RESET**

Description The **DRIVE_RESET** command resets the Servo Driver connected via the MECHATROLINK-II bus. The command is executed on the driver for the base axis set by BASE. The base axis can be changed with the AXIS modifier, as with all the other axis commands and parameters.

Arguments N/A

Example No example.

See also N/A

**Caution**

Be sure that no Parameter Unit or Personal Computer Software is connected to the Servo Driver when executing this command. Otherwise the program task will be paused until the connection of the other device to the Servo Driver is removed.

3.2.92 DRIVE_STATUS

Type Axis parameter (read-only)

Syntax **DRIVE_STATUS**

Description For MECHATROLINK-II axes, this parameter is set from the STATUS field in the MECHATROLINK-II communication frame and is updated every servo period. Those bits can be seen in the Intelligent drives configuration window in Trajexia Tools, and can be used in programs. The explanation of each bit is given in the table below. (Note: Only bits relevant to MECHATROLINK-II axes are listed.) For the detailed explanation for these status bits, see the MECHATROLINK-II manual.

Bit	Description (MECHATROLINK-II)
0	Alarm
1	Warning
2	Ready
3	Servo on
4	Power on
5	Machine Lock
6	Home Position
7	At Position/Speed
8	Output Completed
9	Torque Limit
10	Latch Completed
11	In Range/Speed Limit

For Flexible Axis axes, this parameter holds the status of registration and auxiliary inputs, as well as registration selection. The explanation of each bit is given in the second table below. (Note: Only bits relevant to Flexible axis are listed.)

Bit	Description (Flexible Axis)
0	MARK

Bit	Description (Flexible Axis)
1	MARKB
2	REG 0 selected current value
3	REG 1 selected current value
4	AUX IN current value
5	REG 0 current value
6	REG 1 current value

Arguments N/A

Example **PRINT DRIVE_STATUS AXIS(4)**This command will print the current value of **DRIVE_STATUS** for axis(4).Example **BASE(3)**

```
ATYPE = 44
IF (DRIVE_STATUS AND 32)= 32 THEN
    PRINT "REG 0 input is ON for axis(3)"
ENDIF
```

See also **AXIS, MARK, MARKB, REGIST.**

3.2.93 DRIVE_WRITE

Type Axis command

Syntax **DRIVE_WRITE(parameter, size, value [,mode])**

Description The **DRIVE_WRITE** function writes to the specified parameter of the Servo Driver via the MECHATROLINK-II bus. Upon successful execution, this command returns -1. If the command cannot be executed, the value 0 is returned. The command is executed on the driver for the base axis set with **BASE**. It can be changed using the **AXIS** modifier, as with all other axis commands and parameters. For some parameters to be written the driver needs to be powered off and on again. The **DRIVE_RESET** command can be used for that purpose.

Note: This command waits for the response of the axis so, its execution is slow and the time variable. Do not use this command together with other commands that require quick execution.

Note: Executing a **DRIVE_WRITE** will temporarily disable the Servo Driver Front Panel display.

Note: **DRIVE_WRITE** returns -1 on success. It also returns -1 with no parameter read if the parameter number does not exist or has the wrong size.

Arguments

- **parameter**

The number of the parameter to write to. Note that the parameter numbers are hexadecimal. The format of the data can be found in the Refer to the Servo Driver manual for the format of the data.

- **size**

Size of the parameter is specified in bytes. For most parameters the size is normally 2 bytes. Some special parameters may be 4 bytes long. Sizes for each parameter can be found in the Servo Driver manual.

- **value**

The value to be written into driver parameter.

- **mode**

The write mode. Possible values: 0 (or omitted) - write and store in RAM; 1 - write and store in EPROM.

Example

```
IF DRIVE_WRITE($100,2,90) THEN
```

```
    PRINT "The new speed loop gain is: 90"
```

```
ELSE
```

```
    PRINT "The speed loop gain could not be written in RAM"
```

```
ENDIF
```

See also

- **DRIVE_READ, DRIVE_RESET, \$ (HEXADECIMAL INPUT)**

**Caution**

Be sure that no Parameter Unit or Personal Computer Software is connected to the Servo Driver when executing this command. Otherwise the program task will be paused until the connection of the other device to the Servo Driver is removed.

3.2.94 EDIT

Type	Program command
Syntax	EDIT [line_number] ED [line_number]
Description	The EDIT command starts the built in screen editor allowing a program in the controller to be modified using a Command Line Terminal. The currently selected program will be edited. The editor commands are as follows: <ul style="list-style-type: none">• Quit Editor: [CTRL] K and D• Delete Line: [CTRL] Y This command is implemented for a Command Line Terminal. Within Trajexia Tools, users can select the command from the Program menu.
Arguments	• line_number The number of the line at which to start editing.
Example	No example.
See also	SELECT.

3.2.95 ELSE

See **IF..THEN..ELSE..ENDIF.**

3.2.96 ELSEIF

See **IF..THEN..ELSE..ENDIF.**

3.2.97 ENCODER

Type	Axis parameter (read-only)
Syntax	ENCODER
Description	The ENCODER axis parameter contains a raw copy of the encoder hardware register or the raw data received from the drive via MECHATROLINK-II. On axes with absolute encoders, the ENCODER parameter contains a value using a number of bits programmed with ENCODER_BITS . The MPOS axis parameter contains the measured position calculated from the ENCODER value automatically, allowing for overflows and offsets.
Arguments	N/A
Example	No example.
See also	AXIS, MPOS.

3.2.98 ENCODER_BITS

Type	Axis parameter
Syntax	ENCODER_BITS = value
Description	This axis parameter configures the interface for the number of encoder bits for Flexible axis SSI and EnDat absolute encoder axes. The parameter is applicable only to axes of ATYPE values 47 and 48. When applied to Flexible axis EnDat absolute encoder axis, bits 0 - 7 of the parameter should be set to the total number of encoder bits. Bits 8 - 14 should be set to the number of multi-turn bits to be used. When applied to Flexible axis SSI absolute encoder axis, bits 0 - 5 of the parameter should be set to the number of encoder bits. Bit 6 should be 1 for binary operation, or 0 for Gray code. For SSI encoders of the "Balluff" brand bits 8..10 allow an additional hardware shift to be specified. Normally bits 8..10 are 0. Note: If using Flexible axis absolute encoder axis, it is essential to set this parameter for the axis before setting the ATYPE .
Arguments	N/A

Example	ENCODER_BITS = 25 + (256 * 12) ATYPE = 47	Description	This parameter returns the ID value of an absolute encoder for the axis. This parameter is applicable only to Flexible axis absolute Tamagawa axis with ATYPE value 46.
	In this example a 25 bit EnDat encoder is used, that has 12 bits for multi-turn value and 13 bits per one revolution.		It returns ENID parameter from the encoder, which is set to 17. For more information see Tamagawa absolute encoder interface specification.
Example	ENCODER_BITS = 12 + (64 * 1) ATYPE = 48		If applied to axis of ATYPE value other than 46, this parameter returns 0.
	In this example a 12 bit (4096 positions per revolution) SSI encoder is used, with binary output type.	Arguments	N/A
See also	AXIS.	Example	>>PRINT ENCODER_ID AXIS (1) 17.0000
			This command will print absolute encoder ID value for axis 1.
		See also	AXIS, ENCODER, ENCODER_BITS.

3.2.99 ENCODER_CONTROL

Type	Axis parameter
Syntax	ENCODER_CONTROL = value
Description	The ENCODER_CONTROL parameter is applicable only to Flexible axis absolute EnDat axis with ATYPE value 47. The parameter controls the mode in which EnDat encoder return its position. The encoder can be set to either cyclically return its position, or it can be set to a parameter read/write mode. The default after initialization is cyclic position return mode. For more information see EnDat absolute encoder interface specification.
Arguments	N/A
Example	ENCODER_CONTROL AXIS(1) = 0 This command sets cyclic position return mode.
Example	ENCODER_CONTROL AXIS(1) = 1 This command sets parameter read/write mode.
See also	AXIS, ENCODER, ENCODER_BITS.

3.2.100 ENCODER_ID

Type	Axis parameter (read-only)
Syntax	ENCODER_ID

3.2.101 ENCODER_RATIO

Type	Axis parameter
Syntax	ENCODER_RATIO(denominator, numerator)
Description	This command allows the incoming encoder count to be scaled by a non integer number, using the equation: MPOS = (numerator / denominator) x encoder_edges_input Unlike the UNITS parameters, ENCODER_RATIO affects commands like MOVECIRC and CAMBOX , since it affects the number of encoder edges within the servo loop at the low level. It is necessary to change the position loop gains after changing encoder ratio in order to maintain performance and stability. Note: Large ratios should be avoided as they will lead to either loss of resolution or much reduced smoothness in the motion. The actual physical encoder count is the basic resolution of the axis and the use of this command may reduce the ability of the Motion Controller to accurately achieve all positions. Note: ENCODER_RATIO does not replace UNITS . Only use ENCODER_RATIO where absolutely necessary. For all other axis scaling use UNITS .

Arguments	<ul style="list-style-type: none"> denominator A number between 0 and 16777215 that is used to define the denominator in the above equation. numerator A number between 0 and 16777215 that is used to define the numerator in the above equation.
Example	<pre>' 7200 is the closest to the encoder resolution that can be devided by an ' integer to give degrees. (7200/20=360) ENCODER_RATIO(8192,7200) UNITS=20 ' axis calibrated in degrees, resolution is 0.05 deg.</pre> <p>A rotary table has a servo motor connected directly to its centre of rotation. An encoder is mounted to the rear of the servo motor and returns a value of 8192 counts per revolution. The application requires the table to be calibrated in degrees, but so that one degree is an integer number of counts.</p>
See also	N/A

3.2.102 ENCODER_READ

Type	Axis command
Syntax	ENCODER_READ(address)
Description	The ENCODER_READ command is applicable only to Flexible axis absolute EnDat axis with ATYPE value 47. The parameter returns a 16-bit encoder parameter stored at specified address. Bits 8 -15 of the address are the EnDat MRS field settings and bits 0 - 7 are the offset within the EnDat MRS block. If a CRC error occurs, this command will return -1. For more information see EnDat absolute encoder interface specification.
Arguments	<ul style="list-style-type: none"> address Specifies the EnDat MRS field to read.
Example	<pre>VR(100) = ENCODER_READ(\$A10D) AXIS(7)</pre> <p>This command will read the number of encoder bits and put that value in VR(10) memory location.</p>
See also	AXIS, ENCODER, ENCODER_BITS.

3.2.103 ENCODER_STATUS

Type	Axis parameter (read-only).
Syntax	ENCODER_STATUS
Description	<p>This parameter returns the status of the absolute encoder. This parameter is applicable only to Flexible axis absolute Tamagawa axis with ATYPE value 46. It returns both the status field SF and the ALMC encoder error field. The SF field is in bits 0 - 7, while the ALMC filed is in bits 8 - 15. For more information see Tamagawa absolute encoder interface specification.</p> <p>If applied to axis of ATYPE value other than 46, this parameter returns 0.</p>
Arguments	N/A
Example	<pre>PRINT (ENCODER_STATUS AXIS (1) AND 255)</pre> <p>This command will print SF field of the Tamagawa absolute encoder for axis 1.</p>
See also	AXIS, ENCODER, ENCODER_BITS.

3.2.104 ENCODER_TURNS

Type	Axis parameter (read-only)
Syntax	ENCODER_TURNS
Description	<p>The ENCODER_TURNS parameter returns the number of multi-turn count from the encoder.</p> <p>This is applicable only to Flexible axis absolute Tamagawa axis with ATYPE value 46 and Flexible axis absolute EnDat axis with ATYPE value 47.</p> <p>The multi-turn data is not automatically applied to the axis MPOS parameter after initialization. The application programmer must apply this from the program using OFFPOS or DEFPOS commands as required.</p> <p>If applied to axis of ATYPE value other than 46 or 47, the parameter returns 0.</p>
Arguments	N/A
Example	<pre>PRINT ENCODER_TURNS AXIS (1)</pre> <p>This command will print absolute encoder multi-turn counts for axis 1.</p>
See also	AXIS, ENCODER, ENCODER_BITS.

3.2.105 ENCODER_WRITE

Type	Axis command
Syntax	ENCODER_WRITE(address, value)
Description	The ENCODER_WRITE command is applicable only to Flexible axis absolute EnDat axis with ATYPE value 47. The command writes to an encoder parameter specified by the address. Bits 8 -15 of the address are the EnDat MRS field settings and bits 0 - 7 are the offset within the EnDat MRS block. If a CRC error occurs, this command will return 0. Writing to address 0 performs an encoder reset function. For more information see EnDat absolute encoder interface specification. In order to successfully write an encoder parameter with this command, the ENCODER_CONTROL parameter must be set to 1, encoder parameter read/write mode.
Arguments	<ul style="list-style-type: none"> • address Specifies the EnDat MRS field to write to. • value Any valid BASIC expression.
Example	No example.
See also	AXIS, ENCODER, ENCODER_BITS, ENCODER_CONTROL.

3.2.106 ENDIF

See **IF..THEN..ELSE..ENDIF.**

3.2.107 ENDMOVE

Type	Axis parameter
Syntax	ENDMOVE

Description	The ENDMOVE axis parameter holds the position of the end of the current move in user units. If the SERVO axis parameter is ON, the ENDMOVE parameter can be written to produce a step change in the demand position (DPOS). Note: As the measured position is not changed initially, the Following Error limit (FE_LIMIT) should be considered when writing to ENDMOVE to produce a step change. If the change of demanded position is too big, the limit will be exceeded.
Arguments	N/A
Example	No example.
See also	AXIS, DPOS, FE_LIMIT, UNITS.

3.2.108 EPROM

Type	Program command
Syntax	EPROM
Description	The EPROM command stores the BASIC programs in the TJ1-MC__ battery backed up RAM memory in the flash EEPROM memory. Whether the programs stored in the flash EEPROM memory are copied to RAM at start-up is controlled by the POWER_UP system parameter. Note: Trajexia Tools offers this command as a button on the control panel. Also pop-up screens will prompt to write the program data into flash memory.
Arguments	N/A
Example	No example.
See also	POWER_UP, RUNTYPE.

3.2.109 ERROR_AXIS

Type	System parameter (read-only)
Syntax	ERROR_AXIS

Description	The ERROR_AXIS axis parameter contains the number of the axis which has caused the motion error.
	A motion error occurs when the AXISSTATUS state for one of the axes matches the ERRORMASK setting. In this case the enable switch (WDOG) will be turned off, the MOTION_ERROR parameter will have value different than 0 and the ERROR_AXIS parameter will contain the number of the first axis to have the error.
Arguments	N/A
Example	No example.
See also	AXISSTATUS, ERRORMASK, MOTION_ERROR, WDOG.

3.2.110 ERROR_LINE

Type	Task parameter (read-only)
Syntax	ERROR_LINE
Description	The ERROR_LINE parameter contains the number of the line which caused the last BASIC run-time error in the program task. This value is only valid when the BASICERROR parameter is TRUE . Each task has its own ERROR_LINE parameter. Use the PROC modifier to access the parameter for a certain task. Without PROC , the current task will be assumed.
Arguments	N/A
Example	>> PRINT ERROR_LINE PROC(4) 23.0000
See also	BASICERROR, PROC, RUN_ERROR.

3.2.111 ERRORMASK

Type	Axis parameter
Syntax	ERRORMASK

Description	The ERRORMASK axis parameter contains a mask value that is ANDed bit by bit with the AXISSTATUS axis parameter on every servo cycle to determine if a motion error has occurred. If the result of the AND operation is not zero, the motion error has occurred. When a motion error occurs the enable switch (WDOG) will be turned off, the MOTION_ERROR parameter will have value different than 0 and the ERROR_AXIS parameter will contain the number of the first axis to have the error. Check the AXISVALUES parameter for the status bit allocations. The default setting of ERRORMASK is 268.
Arguments	N/A
Example	No example.
See also	AXIS, AXISSTATUS, MOTION_ERROR, WDOG.



Caution

It is up to the user to define in which cases a motion error is generated. For safe operation it is strongly recommended to generate a motion error when the Following Error has exceeded its limit in all cases. This is done by setting bit 8 of **ERRORMASK**

3.2.112 ETHERNET

Type	System command
Syntax	ETHERNET(function, unit_number, parameter [,values])
Description	The command ETHERNET is used to read and set certain functions of Ethernet communications. The ETHERNET command should be entered on the command line of the terminal window of Trajexia Tools in disconnected mode. Note: The commands with parameters 4,5,7,9,10 and 12 take effect immediately after execution. The commands with parameters 0,2,3 and 8 require a power cycle to Trajexia to enable the new parameters.

Arguments	<ul style="list-style-type: none"> function 0 = Read, 1 = Write. unit_number -1. parameter 0 = IP Address 1 = Addressing mode: Static (1) or Dynamic (0) (Only static addressing is supported) 2 = Subnet Mask 3 = MAC address 4 = Default Port Number (initialised to 23), see also section 4.2.3. 5 = Token Port Number (initialised to 3240) 7 = ModbusTCP mode: Integer (0) or IEEE floating point (1) 8 = Default Gateway 9 = Data configuration: VR variables (0) or TABLE (1) 10 = ModbusTCP Port Number (initialised to 502) 11 = ARP cache (read-only). 12 = Default FINS Port Number (initialised to 9600), see also section 4.2.4. values The required parameter for a write. 	See also	N/A
Example	ETHERNET(1,-1,0,192,200,185,2) Set the Trajexia IP address to 192.200.185.2.	Type	Mathematical function
See also	N/A	Syntax	EXP(expression)
		Description	The EXP function returns the exponential value of the expression.
		Arguments	<ul style="list-style-type: none"> expression Any valid BASIC expression.
		Example	>>PRINT EXP(1.0) 2.7183
		See also	N/A
3.2.113 EX		3.2.115 FALSE	
Type	System command	Type	Constant (read-only)
Syntax	EX[(option)]	Syntax	FALSE
Description	Resets the controller as if it were being powered up again. There are two types of reset performed by the EX command. EX without the argument, or EX(0) does the software reset of the controller. EX(1) does the hardware reset of the controller	Description	The FALSE constant returns the numerical value 0.
Arguments	N/A	Arguments	N/A
Example	No example.	Example	test: res = IN(0) OR IN(2) IF res = FALSE THEN PRINT "Inputs are off" ENDIF
		See also	N/A
3.2.116 FAST_JOG			
Type	Axis parameter		

Syntax	FAST_JOG
Description	<p>The FAST_JOG axis parameter contains the input number to be used as the fast jog input. The number can be from 0 to 31. As default the parameter is set to -1, no input is used for the fast jog.</p> <p>The fast jog input controls the jog speed between two speeds. If the fast jog input is set, the speed as given by the SPEED axis parameter will be used for jogging. If the input is not set, the speed given by the JOGSPEED axis parameter will be used.</p> <p>Note: This input is active low.</p>
Arguments	N/A
Example	No example.
See also	AXIS, FWD_JOG, JOGSPEED, REV_JOG, SPEED.

3.2.117 FASTDEC

Type	Axis parameter
Syntax	FASTDEC
Description	The FASTDEC axis parameter contains fast deceleration ration. Its default value is zero. If a non-zero FASTDEC is specified, the axis will ramp to zero at this deceleration rate when an axis limit switch or position is reached.
Arguments	N/A
Example	No example.
See also	N/A

3.2.118 FE

Type	Axis parameter (read-only)
Syntax	FE

Description	The FE axis parameter contains the position error in user units. This is calculated by the demand position (DPOS axis parameter) minus the measured position (MPOS axis parameter). The value of the Following Error can be checked by using the axis parameters FE_LIMIT and FE_RANGE .
Arguments	N/A
Example	No example.
See also	AXIS, DPOS, FE_LIMIT, FE_RANGE, MPOS, UNITS.

3.2.119 FE_LATCH

Type	Axis parameter (read-only)
Syntax	FE_LATCH
Description	Contains the initial FE value which caused the axis to put the controller into MOTION_ERROR . This value is only set when the FE exceeds the FE_LIMIT and the SERVO parameter has been set to OFF. FE_LATCH is reset to 0 when the SERVO parameter of the axis is set back to ON.
Arguments	N/A
Example	No example.
See also	N/A

3.2.120 FE_LIMIT

Type	Axis parameter
Syntax	FE_LIMIT FELIMIT
Description	The FE_LIMIT axis parameter contains the maximum allowed Following Error in user units. When exceeded, bit 8 of the AXISSTATUS parameter of the axis will be set. If the ERRORMASK parameter has been properly set, a motion error will be generated and WDOG enable relay will be reset to 0. This limit is used to guard against fault conditions, such as mechanical lock-up, loss of encoder feedback, etc.

Arguments	N/A
Example	No example.
See also	AXIS, AXISSTATUS, ERRORMASK, FE, FE_RANGE, UNITS.

3.2.121 FE_LIMIT_MODE

Type	Axis parameter
Syntax	FE_LIMIT_MODE=value
Description	<p>When this parameter is set to 0, the axis will cause a MOTION_ERROR immediately when the FE exceeds the FE_LIMIT value.</p> <p>If FE_LIMIT_MODE is set to 1, the axis will only generate a MOTION_ERROR when the FE exceeds FE_LIMIT during 2 consecutive servo periods. This means that if FE_LIMIT is exceeded for one servo period only, it will be ignored.</p> <p>The default value for FE_LIMIT_MODE is 0.</p>
Arguments	N/A
Example	No example.
See also	N/A

3.2.122 FE_RANGE

Type	Axis parameter
Syntax	FE_RANGE
Description	<p>The FE_RANGE axis parameter contains the limit for the Following Error warning range in user units. When the Following Error exceeds this value on a servo axis, bit 1 in the AXISSTATUS axis parameter will be turned on.</p> <p>This range is used as a first indication for fault conditions in the application (compare FE_LIMIT).</p>
Arguments	N/A
Example	No example.
See also	AXIS, AXISSTATUS, ERRORMASK, FE, UNITS.

3.2.123 FHOLD_IN

Type	Axis parameter
Syntax	FHOLD_IN
Description	<p>The FHOLD_IN axis parameter contains the input number to be used as the feedhold input. The valid input range is 0 to 31. Values 0 to 15 represent physically present inputs of TJ1-MC__ I/O connector and are common for all axes. Values 16 to 31 are mapped directly to driver inputs that are present on the CN1 connector. They are unique for each axis. It depends on the type of Servo Driver which Servo Driver inputs are mapped into inputs 16 to 31. For more information on Servo Driver I/O mapping into the Trajexia I/O space, refer to section 6.1.4.</p> <p>As default the parameter is set to -1, no input is used for feedhold.</p> <p>Note: This input is active low.</p> <p>If an input number is set and the feedhold input turns set, the speed of the move on the axis is changed to the value set in the FHSPEED axis parameter. The current move is not cancelled. Furthermore, bit 7 of the AXISSTATUS parameter is set. When the input turns reset again, any move in progress when the input was set will return to the programmed speed.</p> <p>Note: This feature only works on speed controlled moves. Moves which are not speed controlled (CAMBOX, CONNECT and MOVELINK) are not affected.</p>
Arguments	N/A
Example	No example.
See also	AXIS, AXISSTATUS, FHSPEED, UNITS.

3.2.124 FHSPEED

Type	Axis parameter
Syntax	FHSPEED

Description	The FHSPEED axis parameter contains the feedhold speed. This parameter can be set to a value in user units/s and defines at which speed the axis will move when the feedhold input turns on. The current move is not cancelled. FHSPEED can have any positive value including 0. The default value is 0. This default value is applicable to most applications as motion is usually ramped down to zero speed when the freehold input is set. In some cases it may be desirable for the axis to ramp to a known constant speed when the freehold input is set. Note: This feature only works on speed controlled moves. Moves which are not speed controlled (CAMBOX , CONNECT and MOVELINK) are not affected.
Arguments	N/A
Example	No example.
See also	AXIS , AXISSTATUS , FHOLD_IN , UNITS .

3.2.125 FINS_COMMS

Type	Communication command
Syntax	FINS_COMMS (<i>type</i> , <i>network</i> , <i>node</i> , <i>unit</i> , <i>remote_area</i> , <i>remote_offset</i> , <i>length</i> , <i>local_area</i> , <i>local_offset</i> , <i>timeout</i> [, <i>ip1</i> , <i>ip2</i> , <i>ip3</i> , <i>ip4</i>])

Description	FINS (Factory Interface Network Service) is a Proprietary OMRON communication protocol. A subset of this protocol has been implemented in Trajexia. The FINS protocol has been implemented with the intention of enabling seamless communication with other OMRON devices (PLCs, HMs, etc.) and software (CX-Drive, CX-Server, etc.). For more information on FINS communication protocol, see section 4.2.4 and the Communication Commands Reference Manual, cat. num. W342-E1, Sections 3 and 5. Trajexia has built in FINS client capabilities, so it can initiate the FINS communications with FINS slave devices using FINS_COMMS . Only FINS 0101 (Read Memory) and FINS 0102 (Write Memory) commands are implemented at the moment of this writing. With FINS 0101, memory can be read from other devices with FINS server capability. FINS 0102 can be used to write data to devices with FINS server capability. This command returns one of the following values, depending on outcome of the execution: -1: The command executed successfully. 0: The command failed. 1: Request not sent because the client or the FINS protocol is busy. 2: One or more of the request parameters are invalid. 3: Invalid source memory area. 4: Request was sent, but no response from remote server received within timeout period. 5: Error response code received from remote server.
-------------	--

<p>Arguments</p> <ul style="list-style-type: none"> • type The type of the FINS command. 0 means FINS 0101, read memory from remote FINS server. 1 means FINS 0102, write memory to the remote server. • network The destination network. For more details, see the Communication Commands Reference Manual, cat. num. W342-E1, Section 3. • node The node of the destination FINS server. For more details, see the Communication Commands Reference Manual, cat. num. W342-E1, Section 3. • unit The unit number of the destination FINS server. For more details, see the Communication Commands Reference Manual, cat. num. W342-E1, Section 3. • remote_area The area of memory accessed on the destination FINS server. Range: 128..255. Note that this area must be one of the following values if the destination is another Trajexia system: 0xB0: Integer VR value; 0x82: Integer TABLE value; 0xC2: float TABLE value. • remote_offset The memory offset on the destination FINS server. Range: 0..65535. Note that this range will be more limited to the maximum TABLE or VR addresses if the destination is another Trajexia system. • length The number of items to be transferred. The range will depend upon the FINS frame length and the capabilities of the client and remote servers. The range for a Trajexia system is from 1 to 700 integer values, or 1 to 350 floating point values. • local_area The local (source) memory area. Note that this area must be one of the following values: 0x00: Integer VR value; 0x01: Integer TABLE value; 0x02 : float TABLE value. 	<ul style="list-style-type: none"> • local_offset The offset of the first value in the local (source) memory area. The range depends upon the VR or TABLE array size and value for the length argument. • timeout The number of milliseconds to wait for a response from the destination FINS server, before timing out. • IP1, IP2, IP3, IP4 Optional parameters that define the remote (destination) server IP address. These arguments must be used if both the Trajexia system and the destination FINS server do not belong to same network.
<p>Example</p>	<p>A Trajexia system and an OMRON CJ1 PLC with Ethernet Unit CJ1W-ETN11 system are connected to the same network. The IP address of Trajexia system is 192.168.0.5. The IP address of the PLC Ethernet Unit is 192.168.0.12. When you execute the command FINS_COMMS(0,0,12,0,\$82, 1000,20,0,500,5000,192,168,0,12), 20 words (length=20) of DM PLC memory area (remote_area=\$82) is read, starting from DM1000 (remote_offset=1000), and is written in the Trajexia VR memory in integer format (local_area=0), starting from VR(500) (local_offset=500). So, values in PLC memory range DM1000 to DM1019 are placed in Trajexia memory VR(500) to VR(519). The timeout is set to 5 seconds.</p> <p>When you execute the command FINS_COMMS(1,0,12,0,\$80, 50,10,0,300,3000,192,168,0,12), 10 words (length=10) of Trajexia VR memory as integers (local_area=0), starting from VR(300) (local_offset=300), are written to the CIO area of the PLC (remote_area=\$80), starting from CIO50 (remote_offset=50). So, values in Trajexia memory range VR(300) to VR(309) are placed in memory CIO50 to CIO59 of the PLC. The timeout is set to 3 seconds.</p>

See also N/A

3.2.126 FLAG

Type	System command
Syntax	FLAG(flag_number [,value])

Description The **FLAG** command is used to set and read a bank of 24 flag bits. The **FLAG** command can be used with one or two parameters. With one parameter specified the status of the given flag bit is returned. With two parameters specified the given flag is set to the value of the second parameter. The **FLAG** command is provided to aid compatibility with earlier controllers and is not recommended for new programs.

- Arguments
- **flag_number**
The flag number is a value from 0..23.
 - **value**
If specified this is the state to set the given flag to i.e. ON or OFF. This can also be written as 1 or 0.

Example **FLAG(21,ON)**
Set flag bit 21 on.

See also N/A

Bit number	Decimal value
5	32
6	64
7	128

Example **FLAGS(146) ' 2 + 16 + 128**
Set Flags 1,4 and 7 on, all others off.

Example **IF (FLAGS and 8) <>0 then GOSUB somewhere**
Test if Flag 3 is set.

See also N/A

3.2.127 FLAGS

Type System command

Syntax **FLAGS([value])**

Description Read and set the **FLAGS** as a block. The **FLAGS** command is provided to aid compatibility with earlier controllers and is not recommended for new programs. The 24 flag bits can be read with **FLAGS** and set with **FLAGS(value)**.

- Arguments
- **value**
The decimal equivalent of the bit pattern to which the flags must be set.
See the table below.

Bit number	Decimal value
0	1
1	2
2	4
3	8
4	16

3.2.128 FOR..TO..STEP..NEXT

Type Program control command

Syntax **FOR variable = start TO end [STEP increment] commands
NEXT variable**

Description The **FOR ... NEXT** loop allows the program segment between the **FOR** and the **NEXT** statement to be repeated a number of times. On entering this loop, the variable is initialized to the value of start and the block of commands is then executed. Upon reaching the **NEXT** command, the variable is increased by the increment specified after **STEP**. The **STEP** value can be positive or negative, if omitted the value is assumed to be 1. While variable is less than or equal to end, the block of commands is repeatedly executed until variable is greater than end, at which time program execution will continue after **NEXT**.

Note: **FOR ... NEXT** statements can be nested up to 8 levels deep in a BASIC program.

- Arguments
- **variable**
Any valid BASIC expression.
 - **start**
Any valid BASIC expression.
 - **end**
Any valid BASIC expression.
 - **increment**
Any valid BASIC expression.
 - **commands**
One or more BASIC commands.

Example **FOR opnum = 8 TO 13**
 OP(opnum,ON)
 NEXT opnum

This loop turns on outputs 8 to 13.

Example **loop:**
 FOR dist = 5 TO -5 STEP -0.25
 MOVEABS(dist)
 GOSUB pick_up
 NEXT dist

The **STEP** increment can be positive or negative.

Example **loop1:**
 FOR I1 = 1 TO 8
 loop2:
 FOR I2 = 1 TO 6
 MOVEABS(I1*100,I2*100)
 GOSUB 1000
 NEXT I2
 NEXT I1


FOR..TO..STEP..NEXT statements can be nested (up to 8 levels deep) provided the inner **FOR** and **NEXT** commands are both within the outer **FOR..TO..STEP..NEXT** loop.

See also **REPEAT..UNTIL, WHILE..WEND.**

3.2.129 FORWARD

Type	Axis command
Syntax	FORWARD FO
Description	<p>The FORWARD command moves an axis continuously forward at the speed set in the SPEED axis parameter. The acceleration rate is defined by the ACCEL axis parameter.</p> <p>FORWARD works on the default basis axis (set with BASE) unless AXIS is used to specify a temporary base axis.</p> <p>Note: The forward motion can be stopped by executing the CANCEL or RAPIDSTOP command, or by reaching the forward limit. If stopped by execution of the CANCEL or RAPIDSTOP command, the axis decelerates to a stop at the programmed DECEL rate.</p>
Arguments	N/A
Example	<p>Run an axis forwards. When an input signal is detected on input 12, bring the axis to a stop.</p> <pre>FORWARD ' wait for stop signal WAIT UNTIL IN(12)=ON CANCEL WAIT IDLE</pre>

fig. 25



Example Move an axis forward until it hits the end limit switch, then move it in the reverse direction for 25 cm.


```
BASE(3)
FWD_IN=7 limit switch connected to input 7
FORWARD
WAIT IDLE ' wait for motion to stop on the switch
MOVE(-25.0)
WAIT IDLE
```

Example A machine that applies lids to cartons uses a simulated line shaft. This example sets up a virtual axis running forward to simulate the line shaft. Axis 0 is then connected, with the **CONNECT** command, to this virtual axis to run the conveyor. Axis 1 controls a vacuum roller that feeds the lids on to the cartons using the **MOVELINK** control.

```
BASE(4)
ATYPE=0 'Set axis 4 to virtual axis
REP_OPTION=1
SERVO=ON
FORWARD 'starts line shaft
BASE(0)
CONNECT(-1,4) 'Connects base 0 to virtual axis in reverse
WHILE IN(2)=ON
  BASE(1)
  'Links axis 1 to the shaft in reverse direction
  MOVELINK(-4000,2000,0,0,4,2,1000)
  WAIT IDLE
WEND
RAPIDSTOP
```

See also **AXIS, CANCEL, RAPIDSTOP, REVERSE, UNITS.**

fig. 26



3.2.130 FPGA_VERSION

Type	Slot parameter
Syntax	FPGA_VERSION SLOT(unit_number)
Description	This parameter returns the FPGA version of the unit with unit_number in a controller system.
Arguments	<ul style="list-style-type: none"> • unit_number Unit numbers are -1 to 6, including 0, with -1 being the TJ1-MC__ and 0 being the unit immediately to the right of the TJ1-MC__.
Example	N/A
See also	N/A

3.2.131 FRAC

Type	Mathematical function
Syntax	FRAC(expression)
Description	The FRAC function returns the fractional part of the expression.
Arguments	<ul style="list-style-type: none"> • expression Any valid BASIC expression.
Example	<pre>>> PRINT FRAC(1.234) 0.2340</pre>
See also	N/A

3.2.132 FRAME

Type	System parameter
Syntax	FRAME=value

Description	Used to specify which frame to operate within when employing frame transformations. Frame transformations are used to allow movements to be specified in a multi-axis coordinate frame of reference which do not correspond one-to-one with the axes. An example is a SCARA robot arm with jointed axes. For the end tip of the robot arm to perform straight line movements in X-Y the motors need to move in a pattern determined by the robots geometry. Frame transformations to perform functions such as these need to be compiled from C language source and loaded into the controller system software. Contact OMRON if you need to do this.
Arguments	A machine system can be specified with several different frames. The currently active "frame" is specified with the FRAME System parameter.
Example	FRAME=1
See also	N/A

3.2.133 FREE

Type	System function
Syntax	FREE
Description	The FREE function returns the remaining amount of memory available for user programs and TABLE array elements. Note: Each line takes a minimum of 4 characters (bytes) in memory. This is for the length of this line, the length of the previous line, number of spaces at the beginning of the line and a single command token. Additional commands need one byte per token; most other data is held as ASCII.
Example	<pre>>> PRINT FREE 47104.0000</pre>
See also	DIR, TABLE

3.2.134 FS_LIMIT

Type	Axis parameter	Description	The FS_LIMIT axis parameter contains the input number to be used as a forward limit input. The valid input range is 0 to 31. Values 0 to 15 represent physically present inputs of TJ1-MC__ I/O connector and are common for all axes. Values 16 to 31 are mapped directly to driver inputs that are present on the CN1 connector. They are unique for each axis. It depends on the type of Servo Driver which Servo Driver inputs are mapped into inputs 16 to 31. For more information on Servo Driver I/O mapping into the Trajexia I/O space, refer to section 6.1.4.
Syntax	FS_LIMIT FSLIMIT		For more information on setting driver parameter Pn81E, see Servo Driver manual. As default the parameter is set to -1, no inputs selected.
Description	The FS_LIMIT axis parameter contains the absolute position of the forward software limit in user units. A software limit for forward movement can be set from the program to control the working range of the machine. When the limit is reached, the TJ1-MC__ will ramp down the speed of an axis to 0, and then cancel the move. Bit 9 of the AXISSTATUS axis parameter will be turned on while the axis position is greater than FS_LIMIT . FS_LIMIT is disabled when it has a value greater than REP_DIST .		If an input number is set and the limit is reached, any forward motion on that axis will be stopped. Bit 4 of the AXISSTATUS will also be set. Note: This input is active low.
Arguments	N/A	Arguments	N/A
Example	No example.	Example	No example.
See also	AXIS , AXISSTATUS , REP_DIST , UNITS .	See also	AXIS , AXISSTATUS , REV_IN .

3.2.135 FWD_IN

Type	Axis parameter	Type	Axis parameter
Syntax	FWD_IN	Syntax	FWD_JOG
Description		Description	The FWD_JOG axis parameter contains the input number to be used as a jog forward input. The input can be set from 0 to 31. As default the parameter is set to -1, no input is selected. Note: This input is active low.
Arguments		Arguments	N/A
Example	No example.	Example	No example.
See also		See also	AXIS , FAST_JOG , JOGSPEED , REV_JOG .

3.2.137 GET

Type	I/O command
------	-------------

Syntax	GET [#n.] variable	Syntax	GLOBAL "name", vr_number														
Description	<p>The GET command assigns the ASCII code of a received character to a variable. If the serial port buffer is empty, program execution will be paused until a character has been received. Channels 5 to 7 are logical channels that are superimposed on the programming port 0 when using Trajexia Tools.</p> <p>Note: Channel 0 is reserved for the connection to Trajexia Tools and/or the command line interface. Please be aware that this channel may give problems for this function.</p>																
Arguments	<ul style="list-style-type: none"> • n The specified input device. When this argument is omitted, the port as specified by INDEVICE will be used. See the table below. 																
<table border="1"> <thead> <tr> <th>Input device number</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>Programming port 0</td></tr> <tr> <td>1</td><td>RS-232C serial port 1</td></tr> <tr> <td>2</td><td>RS-422A/485 serial port 2</td></tr> <tr> <td>5</td><td>Trajexia Tools port 0 user channel 5</td></tr> <tr> <td>6</td><td>Trajexia Tools port 0 user channel 6</td></tr> <tr> <td>7</td><td>Trajexia Tools port 0 user channel 7</td></tr> </tbody> </table>				Input device number	Description	0	Programming port 0	1	RS-232C serial port 1	2	RS-422A/485 serial port 2	5	Trajexia Tools port 0 user channel 5	6	Trajexia Tools port 0 user channel 6	7	Trajexia Tools port 0 user channel 7
Input device number	Description																
0	Programming port 0																
1	RS-232C serial port 1																
2	RS-422A/485 serial port 2																
5	Trajexia Tools port 0 user channel 5																
6	Trajexia Tools port 0 user channel 6																
7	Trajexia Tools port 0 user channel 7																
<ul style="list-style-type: none"> • variable The name of the variable to receive the ASCII code. 																	
Example	GET#5, k This line stores the ASCII character received on the Trajexia Tools port channel 5 in k .																
See also	INDEVICE, INPUT, KEY, LINPUT																
<h3>3.2.138 GLOBAL</h3>																	
Type	System command																
<table> <tr> <td>Type</td><td colspan="3">Program control command</td></tr> <tr> <td>Syntax</td><td colspan="3"> GOSUB label ... RETURN </td></tr> </table>				Type	Program control command			Syntax	GOSUB label ... RETURN								
Type	Program control command																
Syntax	GOSUB label ... RETURN																

Description The **GOSUB** structure enables a subroutine jump. **GOSUB** stores the position of the line after the **GOSUB** command and then jumps to the specified label. Upon reaching the **RETURN** statement, program execution is returned to the stored position.
Note: Subroutines on each task can be nested up to 8 levels deep.

Arguments

- **label**
A valid label that occurs in the program. An invalid label will give a compilation error before execution.
Labels can be character strings of any length, but only the first 15 characters are significant. Alternatively line numbers may be used as labels.

Example

```
main:
  GOSUB routine
  GOTO main
routine:
  PRINT "Measured position=";MPOS;CHR(13);
  RETURN
```

See also [GOTO](#)

3.2.140 GOTO

Type Program control command
Syntax **GOTO label**
Description The **GOTO** structure enables a jump of program execution. **GOTO** jumps program execution to the line of the program containing the label.
Arguments

- **label**
A valid label that occurs in the program. An invalid label will give a compilation error before execution.
Labels can be character strings of any length, but only the first 15 characters are significant. Alternatively line numbers may be used as labels.

Example

```
loop:
  PRINT "Measured position = ";MPOS;CHR(13);
  WA(1000)
  GOTO loop
```

See also [GOSUB..RETURN](#)

3.2.141 HALT

Type System command

Syntax **HALT**

Description The **HALT** command stops execution of all program tasks currently running. The command can be used both on Command Line Terminal as in programs. The **STOP** command can be used to stop a single program task.
Note: **HALT** doesn't stop any motion. Currently executing, or buffered moves will continue unless they are terminated with a **CANCEL** or **RAPIDSTOP** command.

Arguments N/A

Example No example.

See also [PROCESS, STOP](#).

3.2.142 HEX

Type I/O command

Syntax **HEX**

Description This command is used in a print statement to output a number in hexadecimal format.

Arguments N/A

Example **PRINT#5,HEX(IN(8,16))**

See also N/A

3.2.143 HLM_COMMAND

Type Communication command

Syntax **HLM_COMMAND(command, port [, node [, mc_area/mode [, mc_offset]]])**

Description The **HLM_COMMAND** command performs a specific Host link command operation to one or to all Host Link Slaves on the selected port. Program execution will be paused until the response string has been received or the timeout time has elapsed. The timeout time is specified by using the **HLM_TIMEOUT** parameter. The status of the transfer can be monitored with the **HLM_STATUS** parameter.

Notes:

- When using the **HLM_COMMAND**, be sure to set-up the Host Link Master protocol by using the **SETCOM** command.
- The Host Link Master commands are required to be executed from one program task only to avoid any multi-task timing problems.

Arguments • **command**
The selection of the Host Link operation to perform. See the table below.

- port**
The specified serial port. 1 = RS-232C serial port 1; 2 = RS-422A serial port 2.
- node** (for **HLM_MREAD**, **HLM_TEST**, **HLM_ABORT** and **HLM_STWR**)
The Slave node number to send the Host link command to. Range: [0, 31].
- mode** (for **HLM_STWR**)
The specified CPU Unit operating mode. 0 = PROGRAM mode; 2 = MONITOR mode; 3 = RUN mode.
- mc_area** (for **HLM_MREAD**)
The memory selection of the TJ1-MC__ to read the send data from. See the table below.

command value	Description
HLM_MREAD (or value 0)	This performs the Host Link PLC MODEL READ (MM) command to read the CPU Unit model code. The result is written to the TJ1-MC__ variable specified by mc_area and mc_offset .
HLM_TEST (or value 1)	This performs the Host Link TEST (TS) command to check correct communication by sending string "MC__ TEST STRING" and checking the echoed string. Check the HLM_STATUS parameter for the result.
HLM_ABORT (or value 2)	This performs the Host Link ABORT (XZ) command to abort the Host link command that is currently being processed. The ABORT command does not receive a response.
HLM_INIT (or value 3)	This performs the Host Link INITIALIZE (**) command to initialize the transmission control procedure of all Slave Units.
HLM_STWR (or value 4)	This performs the Host Link STATUS WRITE (SC) command to change the operating mode of the CPU Unit.

mc_area value	Data area
MC_TABLE (or value 8)	TABLE variable array
MC_VR (or value 9)	Global (VR) variable array

- mc_offset** (for **HLM_MREAD**)
The address of the specified TJ1-MC__ memory area to read from. Range for VR variables: [0, 1023]. Range for TABLE variables: [0, 63999].

Example

HLM_COMMAND(HLM_MREAD,1,12,MC_VR,233)

This command reads the CPU Unit model code of the Host Link Slave with node address 12 connected to the RS-232C port. The result is written to VR(233).

If the connected Slave is a any OMRON CJ/CS PLC model, the VR(233) will contain value 30 (hex) after successful execution.

Example	HLM_COMMAND(HLM_TEST,2,23) PRINT HLM_STATUS PORT(2)	Description	The HLM_READ command reads data from a Host Link Slave by sending a Host link command string containing the specified node of the Slave to the serial port. The received response data will be written to either VR or TABLE variables. Each word of data will be transferred to one variable. The maximum data length is 30 words (single frame transfer). Program execution will be paused until the response string has been received or the timeout time has elapsed. The timeout time is specified by using the HLM_TIMEOUT parameter. The status of the transfer can be monitored with the HLM_STATUS parameter.
Example	HLM_COMMAND(HLM_INIT,2) HLM_COMMAND(HLM_ABORT,2,4)	Notes:	When using the HLM_READ , be sure to set-up the Host Link Master protocol by using the SETCOM command. The Host Link Master commands are required to be executed from one program task only to avoid any multi-task timing problems.
Example	HLM_COMMAND(HLM_STWR,2,0,2)	Arguments	<ul style="list-style-type: none"> • port The specified serial port. 1 = RS-232C serial port 1; 2 = RS-422A serial port 2. • node The Slave node number to send the Host link command to. Range: [0, 31]. • plc_area The PLC memory selection for the Host link command. See the table below.
See also	HLM_READ , HLM_STATUS , HLM_TIMEOUT , HLS_NODE , HLM_WRITE , SETCOM .		

3.2.144 HLM_READ

Type	Communication command
Syntax	HLM_READ(port, node, plc_area, plc_offset, length, mc_area, mc_offset)

pc_area value	Data area	Host link command
PLC_DM (or value 0)	DM area	RD
PLC_IR (or value 1)	CIO/IR area	RR
PLC_LR (or value 2)	LR area	RL
PLC_HR (or value 3)	HR area	RH
PLC_AR (or value 4)	AR area	RJ

pc_area value	Data area	Host link command
PLC_EM (or value 6)	EM area	RE

- plc_offset**
The address of the specified PC memory area to read from. Range: [0, 9999].
- length**
The number of words of data to be transferred. Range: [1, 30].
- mc_area**
The memory selection of the TJ1-MC__ to read the send data from. See the table below.

mc_area value	Data area
MC_TABLE (or value 8)	TABLE variable array
MC_VR (or value 9)	Global (VR) variable array

- mc_offset**
The address of the specified TJ1-MC__ memory area to write to. Range for VR variables: [0, 1023]. Range for TABLE variables: [0, 63999].

Example **HLM_READ(2,17,PLC_DM,120,20,MC_TABLE,4000)**

This example shows how to read 20 words from the PLC DM area addresses 120-139 to TJ1-MC__ TABLE addresses 4000-4019. The PC has Slave node address 17 and is connected to the RS-422A port.

See also **HLM_COMMAND, HLM_STATUS, HLM_TIMEOUT, HLS_NODE, HLM_WRITE, SETCOM.**

3.2.145 HLM_STATUS

Type Communication parameter

Syntax **HLM_STATUS PORT(n)**

Description The **HLM_STATUS** parameter contains the status of the last Host Link Master command sent to the specified port. The parameter will indicate the status for the **HLM_READ**, **HLM_WRITE** and **HLM_COMMAND** commands. The status bits are defined in the table below.

Bit	Name	Description
0 - 7	End code	The end code can be either the end code which is defined by the Host Link Slave (problem in sent command string) or an end code defined because of a problem found by the Host Link Master (problem in received response string).
8	Timeout error	A timeout error will occur if no response has been received within the timeout time. This indicates communication has been lost.
9	Command not recognized	This status indicates that the Slave did not recognize the command and has returned a IC response.

The **HLM_STATUS** will have value 0 when no problems did occur. In case of a non-0 value, any appropriate action such as a re-try or emergency stop needs to be programmed in the user BASIC program.

Each port has an **HLM_STATUS** parameter. The **PORT** modifier is required to specify the port.


Arguments

- n**
The specified serial port. 1 = RS-232C serial port 1; 2 = RS-422A serial port 2

- Example **>> HLM_WRITE(1,28,PLC_EM,50,25,MC_VR,200)**
>> PRINT HEX(HLM_STATUS PORT(1))
1
 Apparently the CPU Unit is in RUN mode and does not accept the write operation.
- Example **>> HLM_COMMAND(HLM_TEST,2,0)**
>> PRINT HLM_STATUS PORT(2)
256.0000
 A timeout error has occurred.
- See also **HLM_READ, HLM_COMMAND, HLM_TIMEOUT, HLS_NODE,**
HLM_WRITE, SETCOM.

3.2.146 HLM_TIMEOUT

- Type Communication parameter
- Syntax **HLM_TIMEOUT**
- Description The **HLM_TIMEOUT** parameter specifies the fixed timeout time for the Host Link Master protocol for both serial ports. A timeout error will occur when the time needed to both send the command and receive the response from the Slave is longer than the time specified with this parameter.
 The parameter applies for the **HLM_READ**, **HLM_WRITE** and **HLM_COMMAND** commands. The **HLM_TIMEOUT** parameter is specified in servo periods.
- Arguments N/A
- Example **>> HLM_TIMEOUT=2000**
 Consider the servo period of the TJ1-MC__ is set to 1 ms (SERVO_PERIOD=1000). For both serial ports the Host Link Master timeout time has been set to 2 s.
- See also **HLM_READ, HLM_COMMAND, HLM_STATUS, HLS_NODE,**
HLM_WRITE, SETCOM, SERVO_PERIOD.



3.2.147 HLM_WRITE

Type Communication command

Syntax **HLM_WRITE(port, node, plc_area, plc_offset, length, mc_area, mc_offset)**

Description The **HLM_WRITE** command writes data from the TJ1-MC__ to a Host Link Slave by sending a Host link command string containing the specified node of the Slave to the serial port. The received response data will be written from either VR or TABLE variables. Each variable will define the word or data that will be transferred. The maximum data length is 29 words (single frame transfer).

Program execution will be paused until the response string has been received or the timeout time has elapsed. The timeout time is specified by using the **HLM_TIMEOUT** parameter. The status of the transfer can be monitored with the **HLM_STATUS** parameter.

Notes:

- When using the **HLM_WRITE**, be sure to set-up the Host Link Master protocol by using the **SETCOM** command.
- The Host Link Master commands are required to be executed from one program task only to avoid any multi-task timing problems.

Arguments

port

The specified serial port. 1 = RS-232C serial port 1; 2 = RS-422A serial port 2

node

The Slave node number to send the Host link command to. Range: [0, 31].

plc_area

The PLC memory selection for the Host link command. See the table below.

pc_area value	Data area	Host link command
PLC_LR (or value 2)	LR area	WL
PLC_HR (or value 3)	HR area	WH
PLC_AR (or value 4)	AR area	WJ
PLC_EM (or value 6)	EM area	WE

- plc_offset**

The address of the specified PLC memory area to write to. Range: [0, 9999].

- length**

The number of words of data to be transferred. Range: [1, 29].

- mc_area**

The memory selection of the TJ1-MC__ to read the send data from. See the table below.

mc_area value	Data area
MC_TABLE (or value 8)	Table variable array
MC_VR (or value 9)	Global (VR) variable array

Type Communication command

- mc_offset**

The address of the specified TJ1-MC__ memory area to read from. Range for VR variables: [0, 1023]. Range for TABLE variables: [0, 63999].

pc_area value	Data area	Host link command
PLC_DM (or value 0)	DM area	WD
PLC_IR (or value 1)	CIO/IR area	WR

Example	HLM_WRITE(1,28,PLC_EM,50,25,MC_VR,200) This example shows how to write 25 words from TJ1-MC__'s VR addresses 200-224 to the PC EM area addresses 50-74. The PC has Slave node address 28 and is connected to the RS-232C port.
See also	HLM_READ, HLM_COMMAND, HLM_STATUS, HLM_TIMEOUT, HLS_NODE, SETCOM.

3.2.148 HLS_NODE

Type	Communication parameter
Syntax	HLS_NODE
Description	The HLS_NODE parameter defines the Slave unit number for the Host Link Slave protocol. The TJ1-MC__ will only respond as a Host Link Slave to Host Link Master command strings with the unit number as specified in this parameter. The valid range for this parameter is [0, 31]. The default value is 0.
Arguments	N/A
Example	No example.
See also	N/A

3.2.149 HW_PSWITCH

Type	Axis command
Syntax	HW_PSWITCH(mode, direction, opstate, table_start, table_end)

Description The **HW_PSWITCH** command turns on the OUT 0 output for the axis when the predefined axis measured position is reached, and turns the output off when another measured position is reached. Positions are defined as sequence in the TABLE memory in range from **table_start**, to **table_end**, and on execution of the **HW_PSWITCH** command are stored in FIFO queue. This command is applicable only to Flexible axis axes with **ATYPE** values 43, 44 and 45.

The command can be used with either 1 or 5 parameters. Only 1 parameter is needed to disable the switch or clear FIFO queue. All five parameters are needed to enable switch.

After loading FIFO and going through the sequence of positions in it, if the same sequence has to be executed again, FIFO must be cleared before executing **HW_PSWITCH** command with the same parameters.

- Arguments
- **mode**
0 = disable switch; 1 = on and load FIFO; 2 = clear FIFO.
 - **direction**
0 = decreasing; 1 = increasing.
 - **opstate**
Output state to set in the first position in the FIFO; ON or OFF.
 - **table_start**
Starting TABLE address of the sequence.
 - **table_end**
Ending TABLE address of the sequence.

Example **HW_PSWITCH(1, 1, ON, 21, 50)**
This command will load FIFO with 30 positions, stored in TABLE memory starting from **TABLE(21)** in increasing direction. When the position stored in **TABLE(21)** is reached, the OUT 0 output will be set ON and then alternatively OFF and ON on reaching following positions in the sequence, until the position stored in **TABLE(50)** reached.

Example **HW_PSWITCH(0)**
This command will disable switch if it was enabled previously, but will not clear the FIFO queue.

Example **HW_PSWITCH(2)**
This command will clear FIFO queue if loaded previously.

See also **AXIS**

3.2.150 I_GAIN

Type	Axis parameter
Syntax	I_GAIN
Description	<p>The I_GAIN parameter contains the integral gain for the axis. The integral output contribution is calculated by multiplying the sums of the Following Errors with the value of the I_GAIN parameter. The default value is 0.</p> <p>Adding integral gain to a servo system reduces positioning error when at rest or moving steadily, but it can produce or increase overshooting and oscillation and is therefore only suitable for systems working on constant speed and with slow accelerations.</p> <p>Note: In order to avoid any instability the servo gains should be changed only when the SERVO is off.</p> <p>Note: Servo gains have no affect on stepper output axis, ATYPE=46.</p>
Arguments	N/A
Example	No example.
See also	D_GAIN, OV_GAIN, P_GAIN, VFF_GAIN.

3.2.151 IDLE

See **WAIT IDLE**.

3.2.152 IEEE_IN

Type	Mathematical function
Syntax	IEEE_IN(byte0,byte1,byte2,byte3)
Description	<p>The IEEE_IN function returns the floating point number represented by 4 bytes which typically have been received over a communications link, such as ModbusTCP or FINS.</p> <p>Note: byte0 is the high byte of the 32 bit IEEE floating point format.</p>
Arguments	<ul style="list-style-type: none"> • byte0 - byte3 Any combination of 8 bit values that represents a valid IEEE floating point number.

Example **VR(20) = IEEE_IN(b0,b1,b2,b3)**

See also N/A

3.2.153 IEEE_OUT

Type	Mathematical function
Syntax	byte_n = IEEE_OUT(value, n)
Description	<p>The IEEE_OUT function returns a single byte in IEEE format extracted from the floating point value for transmission over a communications link. The function will typically be called 4 times to extract each byte in turn.</p> <p>Note: Byte 0 is the high byte of the 32 bit IEEE floating point format.</p>
Arguments	<ul style="list-style-type: none"> • value Any BASIC floating point variable or parameter. • n The byte number (0 - 3) to be extracted.
Example	<pre>a=MPOS AXIS(2) byte0 = IEEE_OUT(a, 0) byte1 = IEEE_OUT(a, 1) byte2 = IEEE_OUT(a, 2) byte3 = IEEE_OUT(a, 3)</pre>
See also	N/A

3.2.154 IF..THEN..ELSE..ENDIF

Type	Program control command
Syntax	IF condition_1 THEN commands {ELSEIF condition_i THEN commands} [ELSE commands] ENDIF IF condition_1 THEN commands

Description This structure controls the flow of the program based on the results of the condition. If the condition is **TRUE** the commands following **THEN** up to **ELSEIF**, **ELSE** or **ENDIF** are executed. If the condition is **FALSE** and the command of a subsequent **ELSEIF** substructure is **TRUE**, the commands of this substructure are executed. If all conditions are **FALSE** the commands following **ELSE** will be executed or the program will resume at the line after **ENDIF** in case no **ELSE** is included. The **ENDIF** is used to mark the end of the conditional block. Note: **IF..THEN..ELSE..ENDIF** sequences can be nested without limit. For a multi-line **IF..THEN** construction, there must not be any statement after **THEN**. A single-line construction must not use **ENDIF**.

- Arguments**
- **condition_i**
A logical expression.
 - **commands**
One or more BASIC commands.

Example **IF MPOS > (0.22 * VR(0)) THEN GOTO exceeds_length**

Example **IF IN(0) = ON THEN**
count = count + 1
PRINT "COUNTS = ";count
fail = 0
ELSE
fail = fail + 1
ENDIF

Example **IF IN(stop)=ON THEN**
OP(8,ON)
VR(cycle_flag)=0
ELSEIF IN(start_cycle)=ON THEN
VR(cycle_flag)=1
ELSEIF IN(step1)=ON THEN
VR(cycle_flag)=99
ENDIF

Example **IF key_char=\$31 THEN**
GOSUB char_1
ELSEIF key_char=\$32 THEN
GOSUB char_2
ELSEIF key_char=\$33 THEN
GOSUB char_3
ELSE
PRINT "Character unknown"
ENDIF

See also N/A

3.2.155 IN

Type I/O function

Syntax **IN(input_number [,final_input_number])**
IN

Description The **IN** function returns the value of digital inputs.

- **IN(input_number, final_input_number)** will return the binary sum of the group of inputs in range [**input_number**, **final_input_number**]. The two arguments must be less than 24 apart.
- **IN(input_number)** will return the value of the particular input specified by the parameter **input_number**.

Arguments

- **input_number**
The number of the input for which to return a value. The range for this parameter depends on the number of additional digital I/O connected over the MECHATROLINK-II bus. If there are no digital I/O connected, the range for this parameter is 0..31.
- **final_input_number**
The number of the last input for which to return a value. The range for this parameter depends on the number of additional digital I/O connected over the MECHATROLINK-II bus. If there are no digital I/O connected, the range for this parameter is 0..31

Example The following lines can be used to move to the position set on a thumb wheel multiplied by a factor. The thumb wheel is connected to inputs 4, 5, 6 and 7, and gives output in BCD.

moveloop:

```
MOVEABS(IN(4,7)*1.5467)
```

```
WAIT IDLE
```

```
GOTO moveloop
```

The **MOVEABS** command is constructed as follows:

Step 1: **IN(4,7)** will get a number between 0 and 15.

Step 2: The number is multiplied by 1.5467 to get required distance.

Step 3: An absolute move is made to this position.

Example In this example a single input is tested:

test:

```
WAIT UNTIL IN(4)=ON ' Conveyor is in position when ON
GOSUB place
```

See also **OP.**

3.2.156 INDEVICE

Type I/O parameter

Syntax **INDEVICE**

Description The **INDEVICE** parameter defines the default input device. This device will be selected for the input commands when the **#n** option is omitted. The **INDEVICE** parameter is task specific. The supported values are listed in the table below.

Value	Description
0	Programming port 0 (default)
1	RS-232C serial port 1
2	RS-422A/485 serial port 2
5	Trajexia Tools port 0 user channel 5
6	Trajexia Tools port 0 user channel 6

Value	Description
7	Trajexia Tools port 0 user channel 7

Arguments N/A

Example No example.

See also **GET, INPUT, LINPUT, KEY.**

3.2.157 INITIALISE

Type System command

Syntax **INITIALISE**

Description Sets all axes, system and process parameters to their default values. The parameters are also reset each time the controller is powered up, or when an **EX** (software reset) command is performed. In Trajexia Tools the menu **Reset the controller...** under the **Controller** menu performs the equivalent of an **EX** command.

Arguments N/A

Example No example.

See also • **EX**

3.2.158 INPUT

Type I/O command

Syntax **INPUT [#n], variable { , variable }**

Description The **INPUT** command will assign numerical input string values to the specified variables. Multiple input string values can be requested on one line, separated by commas, or on multiple lines separated by carriage return. The program execution will be paused until the string is terminated with a carriage return after the last variable has been assigned.

If the string is invalid, the user will be prompted with an error message and the task will be repeated. The maximum amount of inputs on one line has no limit other than the line length.

Channels 5 to 7 are logical channels that are superimposed on the programming port 0 when using Trajexia Tools.

Note: Channel 0 is reserved for the connection to Trajexia Tools and/or the Command Line Terminal interface. Please be aware that this channel may give problems for this function.

Arguments

- **n**
The specified input device. When this argument is omitted, the port as specified by INDEVICE will be used.
- **variable**
The variable to write to.

Example Consider the following program to receive data from the terminal.

```
INPUT#5, num
PRINT#5, "BATCH COUNT=";num[0]
A possible response on the terminal could be:
123<CR>
BATCH COUNT=123
```

See also **INDEVICE, GET, LINPUT, KEY**

3.2.159 INT

Type Mathematical function

Syntax **INT(expression)**

Description The **INT** function returns the integer part of the expression.
Note: To round a positive number to the nearest integer value take the **INT** function of the value added by 0.5. Similarly, to round for a negative value subtract 0.5 to the value before applying **INT**.

Arguments

- **expression**
Any valid BASIC expression.

Example **>> PRINT INT(1.79)**
1.0000

See also N/A

3.2.160 INVERT_IN

Type System command

Syntax **INVERT_IN(input, on/off)**

Description The **INVERT_IN** command allows the input channels 0..31 to be individually inverted in software. This is important as these input channels can be assigned to activate functions such as feedhold.

The **INVERT_IN** function sets the inversion for one channel ON or OFF. It can only be applied to inputs 0..31.

Arguments

- **input**
Any valid BASIC expression

Example **>>? IN(3)**
0.0000
>>INVERT_IN(3,ON)
>>? IN(3)
1.0000

See also N/A

3.2.161 INVERT_STEP

Type Axis parameter

Syntax **INVERT_STEP**

Description **INVERT_STEP** is used to switch a hardware Inverter into the stepper pulse output circuit. This can be necessary for connecting to some stepper drivers. The electronic logic inside the Trajexia stepper pulse generator assumes that the FALLING edge of the step output is the active edge which results in motor movement. This is suitable for the majority of stepper drivers. Setting **INVERT_STEP=ON** effectively makes the RISING edge of the step signal the active edge. **INVERT_STEP** should be set if required prior to enabling the controller with **WDOG=ON**. Default is off.

Note: If the setting is incorrect a stepper motor may lose position by one step when changing direction.

Note: This parameter is applicable only to Flexible axis stepper output axes with ATYPE=46. With other types of axes, this parameter has no effect.

Arguments N/A

Example No example.

See also N/A

3.2.162 INVERTER_COMMAND

Type System command

Syntax **INVERTER_COMMAND(module, station, 1, alarm_number)**
INVERTER_COMMAND(module, station, 8, mode)
INVERTER_COMMAND(module, station, 7, operation_signals)

Description **INVERTER_COMMAND** controls inputs and clears alarm of the Inverter connected to the system via the MECHATROLINK-II bus.

There are three **INVERTER_COMMAND** functions:

- 1: Clears an alarm.
- 7: Controls operation signals.
- 8: Set an Inverter to Servo Driver mode, so it acts as a servo axis. This is possible only for Inverters with an encoder feedback option card connected.

To use an Inverter via MECHATROLINK-II you must put the command and the reference via communication option:

- Inverter MV/V7: N3=3; N4=9
- Inverter F7/G7: B1-01=3; B1-02=3.

Make sure that the Inverter firmware supports the MECHATROLINK-II board. The command returns -1 if successfully executed and 0 if failed.

The command sent to the Inverter corresponds with the bits given in the table below.

Bit	Value	Command	Description
0	Hex	1	Run forward
1	Hex	2	Run reverse
2	Hex	4	Inverter multifunction Input 3
3	Hex	8	Inverter multifunction Input 4
4	Hex	10	Inverter multifunction Input 5
5	Hex	20	Inverter multifunction Input 6
6	Hex	40	Inverter multifunction Input 7
7	Hex	80	Inverter multifunction Input 8 (Only G7)
8	Hex	100	External fault
9	Hex	200	Fault reset
10	Hex	400	Inverter multifunction Input 9 (only G7)
11	Hex	800	Inverter multifunction Input 10 (only G7)
12	Hex	1000	Inverter multifunction Input 11 (only G7)

Bit	Value	Command	Description
13	Hex	2000	Inverter multifunction Input 12 (only G7)
14	Hex	4000	Fault history data clear
15	Hex	8000	External BB command

If with function 8 the mode parameter is set to 1, the Inverter is set into servo axis mode. The corresponding axis number is assigned by the TJ1-MC__ using the formula:

AxisNo = MECHATROLINK-II Station Number - 0x21

Therefore the calculated AxisNo must not be occupied by another axis connected.

If with function 8 the mode parameter is set to 0, which is the default value at power-up, the Inverter is set into normal Inverter mode.

Arguments

- **module**
The number of the TJ1-ML__ that the Inverter is connected to.
- **station**
The MECHATROLINK-II station number of the Inverter.
- **alarm_number**
The number of the alarm. See the Inverter manual.
- **operation_signals**
A bitwise value to control the operation signals. See the table below.
- **mode**
The mode to set the Inverter to:
0 = Inverter mode. This is the default value at power-up.
1 = Servo Driver mode.

Example

```
>>INVERTER_WRITE(1,$23,2,4500)
>>INVERTER_COMMAND(1,$23,7,2)
>>WA(10000)
>>INVERTER_COMMAND(1,$23,7,0)
```

The sequence above controls an Inverter connected via MECHATROLINK-II bus to TJ1-ML__ unit at slot 1 and with station number 23 (hex), using following steps:

Step 1: Speed reference is set to 45.00 Hz.

Step 2: The Inverter is set to run in reverse direction for 10 seconds with speed reference defined in previous step.

Step 3: The Inverter is stopped.

See also

N/A

3.2.163 INVERTER_READ

Type

System command

Syntax

```
INVERTER_READ(module, station, 0, param_number, param_size, VR)
INVERTER_READ(module, station, 1, alarm_number, VR)
INVERTER_READ(module, station, 2, VR)
INVERTER_READ(module, station, 3, VR)
INVERTER_READ(module, station, 4, from, length, VR)
```

Description **INVERTER_READ** reads the parameter, speed reference, torque reference or alarm from the Inverter connected to the system via the MECHATROLINK-II bus.

There are five **INVERTER_READ** functions:

- 0: Reads an Inverter parameter.
- 1: Reads the Inverter alarm.
- 2: Reads the speed reference.
- 3: Reads the torque reference.
- 4: Reads the Inverter inputs.

To use an Inverter via MECHATROLINK-II you must put the command and the reference via communication option:

- Inverter MV/V7: N3=3; N4=9
- Inverter F7/G7: B1-01=3; B1-02=3.

Make you sure that the Inverter firmware supports the MECHATROLINK-II board.

The command returns 1 if successfully executed and 0 if failed. The result (if any) is returned in the selected VR.

Arguments

- **module**
The number of the TJ1-ML__ that the Inverter is connected to.
- **station**
The MECHATROLINK-II station number of the Inverter.
- **param_number**
The number of the parameter to read. See the Inverter manual.
- **param_size**
The size of the parameter to read, 2 or 4 bytes. Most of the Inverter parameters are 2 bytes long. See the Inverter manual.
- **VR**
The address in the VR memory of the TJ-MC__ where the read information is put. When the function is **4**, the result is returned as a bitwise value. See the table below.

Bit	Value	Command	Description
2	Hex	4	Inverter multifunction Input 3
3	Hex	8	Inverter multifunction Input 4
4	Hex	10	Inverter multifunction Input 5
5	Hex	20	Inverter multifunction Input 6
6	Hex	40	Inverter multifunction Input 7
8	Hex	100	External fault
9	Hex	200	Fault reset
14	Hex	4000	Fault history data clear
15	Hex	8000	External BB command

- **alarm_number**
The number of the alarm to read. See the Inverter manual.
- **from**
The start address of the input to read.
- **length**
The length of the input to read.

Example No example.

See also N/A

3.2.164 INVERTER_WRITE

Type System command

Syntax **INVERTER_WRITE(module, station, 0, param_number, param_size, VR, mode)**
INVERTER_WRITE(module, station, 2, value)
INVERTER_WRITE(module, station, 3, value)

Bit	Value	Command	Description
0	Hex	1	Run forward
1	Hex	2	Run reverse

Description **INVERTER_WRITE** writes the parameter, speed reference or torque reference from the Inverter connected to the system via the MECHATROLINK-II bus.

There are three **INVERTER_WRITE** functions:

- 0: Writes an Inverter parameter.
- 2: Writes the speed reference.
- 3: Writes the torque reference.

To use an Inverter via MECHATROLINK-II you should put the command and the reference via communication option:

- Inverter MV/V7: N3=3; N4=9
- Inverter F7/G7: B1-01=3; B1-02=3.

Make you sure that the Inverter firmware supports the MECHATROLINK-II board.

The command returns -1 if successfully executed and 0 if failed. The result (if any) is returned in the selected VR.

Arguments

- **module**
The number of the TJ1-ML__ that the Inverter is connected to.
- **station**
The MECHATROLINK-II station number of the Inverter
- **param_number**
The number of the parameter to write. See the Inverter manual.
- **param_size**
The size of the parameter to write, 2 or 4 bytes. Most of the Inverter parameters are 2 bytes long. See the Inverter manual.
- **VR**
The address in the VR memory of the TJ1-MC__ where the new value for the parameter is.
- **mode**
0 = just write; 1 = write and enter; 2 = write and config.
- **value**
The new value that is written.

Example

```
>>INVERTER_WRITE(1,$23,2,3500)
>>INVERTER_READ(1,$23,2,100)
>>PRINT VR(100)
3500.0000
```

See also

N/A



Note

If you have to transfer many parameters at the same time, the most efficient way is to use MODE 0 for all but the last parameter, and MODE 1 for the last parameter.
MODE 0 is executed faster than MODE 1.

3.2.165 JOGSPEED

Type Axis parameter

Syntax **JOGSPEED**

Description The **JOGSPEED** parameter sets the jog speed in user units for an axis. A jog will be performed when a jog input for an axis has been declared and that input is low. A forward jog input and a reverse jog input are available for each axis, respectively set by **FWD_JOG** and **REV_JOG**. The speed of the jog can be controlled with the **FAST_JOG** input.

Arguments N/A

Example No example.

See also **AXIS AXIS, FAST_JOG, FWD_JOG, REV_JOG, UNITS**.

3.2.166 KEY

Type I/O parameter

Syntax **KEY [#n]**

Description The **KEY** parameter returns **TRUE** or **FALSE** depending on if a character has been received on an input device or not. This command does not read the character but allows the program to test if any character has arrived. A **TRUE** result will reset when the character is read with the **GET** command.

Channels 5 to 7 are logical channels that are superimposed on the programming port 0 when using Trajexia Tools.

Note: Channel 0 is reserved for the connection to Trajexia Tools and/or the Command Line Terminal interface. Please be aware that this channel may give problems for this function.

Arguments • **n**

The specified input device. When this argument is omitted, the port as specified by **INDEVICE** will be used. See the table below.

Value	Input device
0	Programming port 0
1	RS-232C serial port 1
2	RS-422A/485 serial port 2
5	Trajexia Tools port 0 user channel 5
6	Trajexia Tools port 0 user channel 6
7	Trajexia Tools port 0 user channel 7

Example **WAIT UNTIL KEY#1****GET#1, k**

Beware that for using **KEY#1** in an equation may require parentheses in the statement, in this case: **WAIT UNTIL (KEY#1)=TRUE**.

See also • **GET****3.2.167 LAST_AXIS**

Type System parameter (read-only)

Syntax **LAST_AXIS**

Description The **LAST_AXIS** parameter contains the number of the last axis processed by the system.

Most systems do not use all the available axes. It would therefore be a waste of time to task the idle moves on all axes that are not in use. To avoid this to some extent, the TJ1-MC__ will task moves on the axes from 0 to **LAST_AXIS**, where **LAST_AXIS** is the number of the highest axis for which an **AXIS** or **BASE** command has been processed, whichever of the two is larger.

Arguments N/A

Example No example.

See also **AXIS, BACKLASH**.**3.2.168 LINKAX**

Type Axis parameter (read-only)

Syntax **LINKAX**

Description Returns the axis number that the axis is linked to during any linked moves. Linked moves are where the demand position is a function of another axis, e.g. **CONNECT**, **CAMBOX** and **MOVELINK**.

Arguments N/A

Example No example.

See also **CONNECT, CAMBOX, MOVELINK**.**3.2.169 LINPUT**

Type I/O command

Syntax **LINPUT [#n ,] vr_variable**

Description The **LINPUT** command assigns the ASCII code of the characters to an array of variables starting with the specified VR variable. Program execution will be paused until the string is terminated with a carriage return, which is also stored. The string is not echoed by the controller.

Channels 5 to 7 are logical channels that are superimposed on the programming port 0 when using Trajexia Tools.

Note: Channel 0 is reserved for the connection to Trajexia Tools and/or the Command Line Terminal interface. Please be aware that this channel may give problems for this command.

Arguments • **n**

The specified input device. When this argument is omitted, the port as specified by **INDEVICE** will be used. See the table below.

Value	Input device
0	Programming port 0
1	RS-232C serial port 1
2	RS-422A/485 serial port 2
5	Trajexia Tools port 0 user channel 5
6	Trajexia Tools port 0 user channel 6
7	Trajexia Tools port 0 user channel 7

- **vr_variable**
The first VR variable to write to.

Example Consider the following line in a program.

LINPUT#5, VR(0)

Entering START<CR> on port 5 will give

```
VR(0)=83  ' ASCII 'S'
VR(1)=84  ' ASCII 'T'
VR(2)=65  ' ASCII 'A'
VR(3)=82  ' ASCII 'R'
VR(4)=84  ' ASCII 'T'
VR(5)=13  ' ASCII carriage return
```

See also • **GET, INPUT, VR**

3.2.170 LIST

Type Program command (Trajexia Tools command line only)

Syntax **LIST ["program_name"]**
TYPE ["program_name"]

Description For use only with the Command Line Terminal interface. **LIST** is used as an immediate (command line) command only and must not be used in programs. The **LIST** command prints the current selected program or the program specified by **program_name**. The program name can also be specified without quotes. If the program name is omitted, the current selected program will be listed.
Note: This command is implemented for an offline Command Line Terminal. Within Trajexia Tools users can use the terminal window.

Arguments • **program_name**
The program to be printed.

Example No example.

See also **SELECT**.

3.2.171 LIST_GLOBAL

Type System command (terminal only)

Syntax **LIST_GLOBAL**

Description When executed from the Command Line Terminal interface (channel 0), all the currently set **GLOBAL** and **CONSTANT** parameters will be printed to the terminal.

Arguments N/A

Example In an application where the following GLOBAL and CONSTANT have been set:

```
CONSTANT "cutter", 23
GLOBAL "conveyor",5
```

>>LIST_GLOBAL

Global VR

conveyor 5

Constant Value

cutter 23.0000

See also N/A

3.2.172 LN

Type	Mathematical function
Syntax	LN(expression)
Description	The LN function returns the natural logarithm of the expression. The input expression value must be greater than 0.
Arguments	<ul style="list-style-type: none"> • expression Any valid BASIC expression.
Example	>> PRINT LN(10) 2.3026
See also	N/A

3.2.173 LOCK

Type	System command
Syntax	LOCK(code) UNLOCK(code)
Description	The LOCK command prevents the program from being viewed, modified or deleted by personnel unaware of the security code. The lock code number is stored in the flash EPROM. The UNLOCK command allows the locked state to be unlocked. The code number can be any integer and is held in encoded form. LOCK is always an immediate command and can be issued only when the system is UNLOCKED . LOCK and UNLOCK are available from within Trajexia Tools, users can select LOCK and UNLOCK commands from the Controller menu.
Arguments	<ul style="list-style-type: none"> • code Any valid integer with maximum 7 digits.
Example	>> LOCK(561234) The programs cannot be modified or seen. >> UNLOCK(561234) The system is now unlocked.
See also	N/A



Caution

The security code must be remembered; it will be required to unlock the system. Without the security code the system can not be recovered.

3.2.174 MARK

Type	Axis parameter (read-only)
Syntax	MARK
Description	The MARK is set to FALSE when the REGIST command has been executed and is set to TRUE when the primary registration event occurs. Only when this parameter is TRUE , the REG_POS value is correct.
Arguments	N/A
Example	loop: WAIT UNTIL IN(punch_clr)=ON MOVE(index_length) REGIST(3) WAIT UNITL(MARK) MOVEMODIFY(REG_POS + offset) WAIT IDLE GOTO loop
See also	AXIS, REGIST, REG_POS.

3.2.175 MARKB

Type	Axis parameter (read-only)
Syntax	MARKB
Description	The MARKB is set to FALSE when the REGIST command has been executed and is set to TRUE when the primary registration event occurs. Only when this parameter is TRUE , the REG_POSB value is correct.
Arguments	N/A

Example **IF MARKB AXIS(2) THEN**
 PRINT "Secondary registration event for axis 2 occurred"
 ENDIF

See also **AXIS, REGIST, REG_POSB.**

3.2.176 MECHATROLINK

Type	System command
Syntax	<p>MECHATROLINK(unit,0) Detects and connects devices on MECHATROLINK-II Master Unit unit. It is necessary to use it to reset the network from a communication problem and to re-detect servos that have been not detected (EG: when the A letter in the AXISSTATUS word becomes capital red).</p> <p>MECHATROLINK(unit,3,VR) Returns the number of detected MECHATROLINK-II devices after a MECHATROLINK(unit,0). It is used by the STARTUP program to check that the number of detected MECHATROLINK-II stations corresponds with the expected.</p> <p>MECHATROLINK(unit,4,station,VR) Returns the address of MECHATROLINK-II device at that "station" number. The station numbers are a sequence 0..x for all the attached devices. -1 is returned if no device is allocated to that station. It is used by the STARTUP program to check that the number of detected MECHATROLINK-II stations corresponds with the expected.</p> <p>MECHATROLINK(unit,5,station,VR) Reads and clears missed message count. A Non-Axis MECHATROLINK-II device does not report automatically a network problem so, use this command to poll the Inverter and IO modules for checking that the network is alive.</p> <p>Note:</p> <ul style="list-style-type: none"> • You can use the command MECHATROLINK(unit,5,station,VR) to monitor the status of a device during a program execution. If the contents of the VR address is greater than 0 a communication error with the device occurs and the device can malfunction. You can use this command to stop your program when the device has an error.

Description Note: This command has two forms, depending upon the function required: Master and Station Functions.
 All **MECHATROLINK** functions return **TRUE** (-1) if the command was successful or **FALSE** (0) if the command failed.
 The functions are separated out into 2 types, **Master** functions that work on a unit, and **Station** functions that work on a specific **station_address** of a given unit.
 All functions that retrieve a value store it in the **VR** variable indicated in the last parameter. If this parameter has the value -1 then the value is printed to the command line port.

Arguments N/A
 Example No example.
 See also N/A

3.2.177 MERGE

Type	Axis parameter
Syntax	MERGE

Description The **MERGE** parameter is a software switch that can be used to enable or disable the merging of consecutive moves. When **MERGE** is ON and the next move already in the next move buffer (**NTYPE**), the axis will not ramp down to 0 speed but will load up the following move enabling a seamless merge. The default setting of **MERGE** is OFF.

It is up to the programmer to ensure that merging is sensible. For example, merging a forward move with a reverse move will cause an attempted instantaneous change of direction.

MERGE will only function if the following are all true:

1. Only the speed profiled moves **MOVE**, **MOVEABS**, **MOVECIRC**, **MHELICAL**, **REVERSE**, **FORWARD** and **MOVEMODIFY** can be merged with each other. They cannot be merged with linked moves **CONNECT**, **MOVELINK** and **CAMBOX**.
2. There is a move in the next move buffer (**NTYPE**).
3. The axis group does not change for multi-axis moves.

When merging multi-axis moves, only the base axis **MERGE** axis parameter needs to be set.

Note: If the moves are short, a high deceleration rate must be set to avoid the TJ1-MC__ decelerating in anticipation of the end of the buffered move.

Arguments N/A

Example **MERGE = OFF** ' Decelerate at the end of each move
MERGE = ON ' Moves will be merged if possible

See also **AXIS**.

3.2.178 MHELICAL

Type	Axis command
Syntax	MHELICAL(end1, end2, centre1, centre2, direction, distance3 [,mode]) MH(end1, end2, centre1, centre2, direction, distance3 [,mode])
Description	<p>Performs a helical move, that is, moves 2 orthogonal axes in such a way as to produce a circular arc at the tool point with a simultaneous linear move on a third axis. The first 5 parameters are similar to those of a MOVECIRC command. The sixth parameter defines the simultaneous linear move.</p> <p>Finish 1 and centre 1 are on the current BASE axis. Finish 2 and centre 2 are on the following axis.</p> <p>The first 4 distance parameters are scaled according to the current unit conversion factor for the BASE axis. The sixth parameter uses its own axis units.</p>
Arguments	<ul style="list-style-type: none"> • end1 Position on BASE axis to finish at. • end2 Position on next axis in BASE array to finish at. • centre1 Position on BASE axis about which to move. • centre2 Position on next axis in BASE array about which to move. • direction The direction is a software switch which determines whether the arc is interpolated in a clockwise or anti-clockwise direction. The parameter is set to 0 or 1. See MOVECIRC. • distance3 The distance to move on the third axis in the BASE array axis in user units. • mode 0 = Interpolate the third axis with the main two axis when calculating path speed (true helical path). 1 = Interpolate only the first two axes for path speed, but move the third axis in coordination with the other 2 axes (circular path with following third axis).


Example The command sequence follows a rounded rectangle path with axis 1 and 2. Axis 3 is the tool rotation so that the tool is always perpendicular to the product. The **UNITS** for axis 3 are set such that the axis is calibrated in degrees.

```

REP_DIST AXIS(3)=360
REP_OPTION AXIS(3)=ON
' all 3 axes must be homed before starting
MERGE=ON
MOVEABS(360) AXIS(3) point axis 3 in correct starting direction
WAIT IDLE AXIS(3)
MOVE(0,12)
MHELICAL(3,3,3,0,1,90)
MOVE(16,0)
MHELICAL(3,-3,0,-3,1,90)
MOVE(0,-6)
MHELICAL(-3,-3,-3,0,1,90)
MOVE(-2,0)
MHELICAL(-3,3,0,3,1,90)

```

fig. 28



Example A PVC cutter uses 2 axes similar to a X-Y plotter. The third axis is used to control the cutting angle of the knife. To keep the resultant cutting speed for the x and y axis equal when cutting curves, mode 1 is applied to the helical command.

BASE(0,1,2) : MERGE=ON

'merge moves into one continuous movement

MOVE(50,0)

MHELICAL(0,-6,0,-3,1,180,1)

MOVE(-22,0)

WAIT IDLE

MOVE(-90) AXIS(2) 'rotate the knife after stopping at corner

WAIT IDLE AXIS(2)

MOVE(0,-50)

MHELICAL(-6,0,-3,0,1,180,1)

MOVE(0,50)

WAIT IDLE 'pause again to rotate the knife

MOVE(-90) AXIS(2)

WAIT IDLE AXIS(2)


MOVE(-22,0)

MHELICAL(0,6,0,3,1,180,1)

WAIT IDLE

See also **MOVECIRC.**

fig. 29



3.2.179 MOD

Type	Mathematical function
Syntax	expression1 MOD expression2
Description	The MOD function returns the expression2 modulus of expression1 . This function will take the integer part of any non-integer input.
Arguments	<ul style="list-style-type: none"> • expression1 Any valid BASIC expression. • expression2 Any valid BASIC expression.
Example	>> PRINT 122 MOD 13 5.0000
See also	N/A

3.2.180 MOTION_ERROR

Type	System parameter (read-only)
Syntax	MOTION_ERROR
Description	<p>The MOTION_ERROR parameter contains a bit pattern showing the axes which have a motion error. For example, if axis 2 and 6 have the motion error the MOTION_ERROR value would be 68 (4+64).</p> <p>A motion error occurs when the AXISSTATUS state for one of the axes matches the ERRORMASK setting. In this case the enable switch (WDOG) will be turned off, and MOTION_ERROR contains a bit pattern showing all axes which have the motion error. The ERROR_AXIS parameter will contain the number of the first axis to have the error.</p> <p>A motion error can be cleared executing a DATUM(0) command or resetting the controller with an EX command.</p>
Arguments	N/A
Example	No example.
See also	AXIS, AXISSTATUS, DATUM, ERROR_AXIS, ERRORMASK, WDOG.

3.2.181 MOVE

Type	Axis command
Syntax	MOVE(distance_1 [, distance_2 [, distance_3 [, distance_4 [, ...]]]]) MO(distance_1 [, distance_2 [, distance_3 [, distance_4 [, ...]]]])
Description	<p>The MOVE command moves with one or more axes at the demand speed and acceleration and deceleration to a position specified as increment from the current position. In multi-axis moves the movement is interpolated and the speed, acceleration and deceleration are taken from the base axis.</p> <p>The specified distances are scaled using the unit conversion factor in the UNITS axis parameter. If, for example, an axis has 4,000 encoder edges/mm, then the number of units for that axis would be set to 4000, and MOVE(12.5) would move 12.5 mm.</p> <p>MOVE works on the default basis axis group (set with BASE) unless AXIS is used to specify a temporary base axis. Argument distance_1 is applied to the base axis, distance_2 is applied to the next axis, etc. By changing the axis between individual MOVE commands, uninterpolated, unsynchronised multi-axis motion can be achieved. Incremental moves can be merged for profiled continuous path movements by turning on the MERGE axis parameter.</p> <p>Considering a 2-axis movement, the individual speeds are calculated using the equations below. Given command MOVE(x_1, x_2) and the profiled speed v_p as calculated from the SPEED, ACCEL and DECEL parameters from the base axis and the total multi-axes distance $L = \text{SQR}(x_1^2 + x_2^2)$.</p> <p>The individual speed v_i for axis i at any time of the movement is calculated as:</p> $v_i = (x_i * v_p) / L.$
Arguments	<p>The command can take up to 16 arguments.</p> <ul style="list-style-type: none"> • distance_i The distance to move for every axis in user units starting with the base axis.
Example	<p>A system works with a unit conversion factor of 1 and has a 1000 line encoder. Note that a 1000 line encoder gives 4000 edges/turn.</p> <p>MOVE(40000) ' move 10 turns on the motor.</p>

Example Axes 3, 4 and 5 must move independently, that is, without interpolation. Each axis moves at its own programmed **SPEED**, **ACCEL** and **DECEL** etc.


```
'setup axis speed and enable
BASE(3)
SPEED=5000
ACCEL=100000
DECEL=150000
SERVO=ON
BASE(4)
SPEED=5000
ACCEL=150000
DECEL=560000
SERVO=ON
BASE(5)
SPEED=2000
ACCEL=320000
DECEL=352000
SERVO=ON
WDOG=ON
MOVE(10) AXIS(5) 'start moves
MOVE(10) AXIS(4)
MOVE(10) AXIS(3)
WAIT IDLE AXIS(5) 'wait for moves to finish
WAIT IDLE AXIS(4)
WAIT IDLE AXIS(3)
```

Example An X-Y plotter can write text at any position within its working envelope. Individual characters are defined as a sequence of moves relative to a start point. Therefore, the same commands can be used regardless of the plot origin. The command subroutine for the letter M is:

```
write_m:
  MOVE(0,12) 'move A > B
  MOVE(3,-6) 'move B > C
  MOVE(3,6) 'move C > D
  MOVE(0,-12)'move D > E
RETURN
```

See also **AXIS, MOVEABS, UNITS.**

fig. 30



3.2.182 MOVEABS

Type Axis command

Syntax **MOVEABS(distance_1 [, distance_2 [, distance_3 [, distance_4 [, ...]]]])**
MA(distance_1 [, distance_2 [, distance_3 [, distance_4 [, ...]]]])

Description The **MOVEABS** command moves one or more axes at the demand speed, acceleration and deceleration to a position specified as absolute position, i.e., in reference to the origin. In multi-axis moves the movement is interpolated and the speed, acceleration and deceleration are taken from the base axis. The specified distances are scaled using the unit conversion factor in the **UNITS** axis parameter. If, for example, an axis has 4,000 encoder edges/mm, then the number of units for that axis would be set to 4000, and **MOVEABS(12.5)** would move to a position 12.5 mm from the origin. **MOVEABS** works on the default basis axis group (set with **BASE**) unless **AXIS** is used to specify a temporary base axis. Argument **distance_1** is applied to the base axis, **distance_2** is applied to the next axis, etc. By changing the axis between individual **MOVE** commands, uninterpolated, unsynchronised multi-axis motion can be achieved. Absolute moves can be merged for profiled continuous path movements by turning on the **MERGE** axis parameter.
Considering a 2-axis movement, the individual speeds are calculated using the equations below. Given command **MOVE(ax₁,ax₂)**, the current position (ay₁,ay₂) and the profiled speed v_p as calculated from the **SPEED**, **ACCEL** and **DECCEL** parameters from the base axis and the total multi-axes distance L = **SQR(x₁² + x₂²)**, where x_i = ax_i - ay_i. The individual speed for axis at any time of the movement is calculated as v_i = (x_i x v_p) / L.

Arguments The command can take up to 16 arguments.

- **distance_i**
The position to move every axis *i* to in user units starting with the base axis.


Example A machine must move to one of 3 positions depending on the selection made by 2 switches. The options are home (if both switches are off), position 1 (if the first switch is on and the second switch is off) and position 2 (if the first switch is off and the second switch is on). Position 2 has priority over position 1.

```
'define absolute positions
home=1000
position_1=2000
position_2=3000
WHILE IN(run_switch)=ON
  IF IN(6)=ON THEN 'switch 6 selects position 2
    MOVEABS(position_2)
    WAIT IDLE
  ELSEIF IN(7)=ON THEN 'switch 7 selects position 1
    MOVEABS(position_1)
    WAIT IDLE
  ELSE
    MOVEABS(home)
    WAIT IDLE
  ENDIF
WEND
```

Example An X-Y plotter has a pen carousel. The position of this carousel is fixed relative to the absolute zero position of the plotter. To change pens, an absolute move to the carousel position finds the target irrespective of the plot position.

```
MOVEABS(28.5,350) ' move to just outside the pen holder area
WAIT IDLE
SPEED = pen_pickup_speed
MOVEABS(20.5,350) ' move in to pick up the pen
```

fig. 31



Example A pallet consists of a 6 by 8 grid in which gas canisters are inserted 185 mm apart by a packaging machine. The canisters are picked up from a fixed point. The first position in the pallet is defined as position 0,0 with the **DEFPOS** command. The part of the program to position the canisters in the pallet is:


```

FOR x=0 TO 5
  FOR y=0 TO 7
    MOVEABS(-340,-516.5) 'move to pick-up point
    WAIT IDLE
    GOSUB pick 'call pick up subroutine
    PRINT Move to Position: ;x*6+y+1
    MOVEABS(x*185,y*185) 'move to position in grid
    WAIT IDLE
    GOSUB place 'call place down subroutine
  NEXT y
NEXT x

```

See also **AXIS, MOVE, MOVEABS, UNITS.**

fig. 32



3.2.183 MOVECIRC

Type Axis command

Syntax **MOVECIRC(end_1,end_2,centre_1,centre_2,direction)**
MC(end_1,end_2,centre_1,centre_2,direction)

Description The **MOVECIRC** command interpolates 2 orthogonal axes in a circular arc at the tool point. The path of the movement is determined by the 5 arguments, which are incremental from the current position.

The arguments **end_1** and **centre_1** apply to the **BASE** axis and **end_2** and **centre_2** apply to the following axis. All arguments are given in user units of each axis. The speed of movement along the circular arc is set by the **SPEED**, **ACCEL** and **DECEL** parameters of the **BASE** axis. The first four distance parameters are scaled according to the current unit conversion factor for the **BASE** axis.


MOVECIRC works on the default basis axis group (set with **BASE**) unless **AXIS** is used to specify a temporary base axis.

For **MOVECIRC** to be correctly executed, the two axes moving in the circular arc must have the same number of encoder pulses per linear axis distance. If they do not, it is possible to adjust the encoder scales in many cases by adjusting with **ENCODER_RATIO** axis parameters for the axis.

Arguments

- **end_1**
The end position for the **BASE** axis.
- **end_2**
The end position for the next axis.
- **centre_1**
The position around which the **BASE** axis is to move.
- **centre_2**
The position around which the next axis is to move.
- **direction**
A software switch that determines whether the arc is interpolated in a clockwise or counterclockwise direction. Value: 0 or 1.
If the two axes involved in the movement form a right-hand axis, set direction to 0 to produce positive motion about the third (possibly imaginary) orthogonal axis. If the two axes involved in the movement form a left-hand axis, set direction to 0 to produce negative motion about the third (possibly imaginary) orthogonal axis. See the table below.

fig. 33



Note: In order for the **MOVECIRC** to be correctly executed, the two axes generating the circular arc must have the same number of encoder pulses versus linear axis distance. If this is not the case it is possible to adjust the encoder scales in many cases by using **ENCODER_RATIO** parameter.

Note: The **MOVECIRC** computes the radius and the total angle of rotation from the centre, and end-point. If the end point is not on the calculated path, the move simply ends at the computed end and not the specified end point. It is the responsibility of the programmer to ensure that the two points correspond to correct points on a circle.

Note: Neither axis may cross the set absolute repeat distance REP_DIST during a **MOVECIRC**. Doing so may cause one or both axis to jump or for their FE value to exceed FE_LIMIT.

fig. 34





fig. 35



Example

The following command sequence plots the letter O:

```

MOVE(0,6) ' Move A -> B
MOVECIRC(3,3,3,0,1) ' Move B -> C
MOVE(2,0) ' Move C -> D
MOVECIRC(3,-3,0,-3,1) ' Move D -> E
MOVE(0,-6) ' Move E -> F
MOVECIRC(-3,-3,-3,0,1) ' Move F -> G
MOVE(-2,0) ' Move G -> H
MOVECIRC(-3,3,0,3,1) ' Move H -> A

```

Example A machine is required to drop chemicals into test tubes. The nozzle can move up and down and also along its rail. The most efficient motion for the nozzle is to move in an arc between the test tubes.

```

BASE(0,1)
MOVEABS(0,5) 'move to position above first tube
MOVEABS(0,0) 'lower for first drop
WAIT IDLE
OP(15,ON) 'apply dropper
WA(20)
OP(15,OFF)
FOR x=0 TO 5
MOVECIRC(5,0,2.5,0,1) 'arc between the test tubes
WAIT IDLE
OP(15,ON) 'Apply dropper
WA(20)
OP(15,OFF)
NEXT x
MOVECIRC(5,5,5,0,1) 'move to rest position

```

See also **AXIS, ENCODER_RATIO, UNITS**

3.2.184 MOVELINK


Type Axis command

Syntax

```

MOVELINK(distance, link_distance, link_acceleration,
link_deceleration, link_axis [ , link_option [ , link_position ]])
ML(distance, link_distance, link_acceleration, link_deceleration,
link_axis [ , link_option [ , link_position ]])

```



Description The **MOVELINK** command creates a linear move on the base axis linked via a software gearbox to the measured position of a link axis. The link axis can move in either direction to drive the output motion.

The parameters show the distance the BASE axis moves for a certain distance of the link axis (**link_distance**). The link axis distance is divided into three phases that apply to the movement of the base axis. These parts are the acceleration, the constant speed and the deceleration. The link acceleration and deceleration distances are specified by the **link_acceleration** and **link_deceleration** parameters. The constant speed link distance is derived from the total link distance and these two parameters.

The three phases can be divided into separate **MOVELINK** commands or can be added up together into one.

Consider the following two rules when setting up the **MOVELINK** command.

Rule 1: In an acceleration and deceleration phase with matching speed, the **link_distance** must be twice the distance. See the figure.

Rule 2: In a constant speed phase with matching speeds, the two axes travel the same distance so the distance to move must equal the **link_distance**.

MOVELINK works on the default basis axis group (set with **BASE**) unless **AXIS** is used to specify a temporary base axis. The axis set for **link_axis** drives the base axis.

MOVELINK is designed for controlling movements such as:

- Synchronization to conveyors
- Flying shears
- Thread chasing, tapping etc.
- Coil winding

Note: If the sum of **link_acceleration** and **link_deceleration** is greater than **link_distance**, they are both reduced in proportion in order to equal the sum to **link_distance**.

fig. 37

Arguments

- **distance**

The incremental distance in user units to move the BASE axis, as a result of the measured **link_distance** movement on the link axis.

- **link_distance**

The positive incremental distance in user units that is required to be measured on the link axis to result in the distance motion on the BASE axis.

- **link_acceleration**

The positive incremental distance in user units on the link axis over which the base axis will accelerate.

- **link_deceleration**

The positive incremental distance in user units on the link axis over which the base axis will decelerate.


Note: If the sum of parameter 3 and parameter 4 is greater than parameter 2, they are both reduced in proportion until their sum equals parameter 2.

- **link_axis**

The axis to link to.

- **link_option**

See the table below.



Link option	Description
1	Link starts when registration event occurs on link axis.
2	Link starts at an absolute position on link axis (see link_position).
4	MOVELINK repeats automatically and bidirectionally. This option is cancelled by setting bit 1 of REP_OPTION parameter (that is, REP_OPTION = REP_OPTION OR 2).
5	Combination of options 1 and 4.
6	Combination of options 2 and 4.

- **link_position**

The absolute position where **MOVELINK** will start when **link_option** is set to 2

Note: The command uses the BASE and AXIS, and unit conversion factors in a similar way to other MOVE commands.

Note: The “link” axis may move in either direction to drive the output motion. The link distances specified are always positive.

Example

A flying shear that moves at the speed of the material cuts a long sheet of paper into cards every 160 m. The shear can move up to 1.2 metres, of which 1m is used in this example. The paper distance is measured by an encoder. The unit conversion factor is set to give units of metres on both axes. Note that axis 7 is the link axis.

WHILE IN(2)=ON


```

MOVELINK(0,150,0,0,7) ' dwell (no movement) for 150m
MOVELINK(0.3,0.6,0.6,0,7) ' accelerate to paper speed
MOVELINK(0.7,1.0,0,0.6,7) ' track the paper then decelerate
WAIT LOADED ' wait until acceleration movelink is finished
OP(8,ON) ' activate cutter
MOVELINK(-1.0,0.8,4.0,0.5,0.5,7) retract cutter back to start
WAIT LOADED
OP(8,OFF) ' deactivate cutter at end of outward stroke
WEND

```

In this program, the controller waits for the roll to feed out 150 m in the first line. After this distance the shear accelerates to match the speed of the paper, moves at the same speed, and then decelerates to a stop within the 1 m stroke. This movement is specified using two separate **MOVELINK** commands. This allows the program to wait for the next move buffer to be clear, **NTYPE=0**, which indicates that the acceleration phase is complete. Note that the distances on the measurement axis (the link distance in each **MOVELINK** command), 150, 0.8, 1.0 and 8.2, add up to 160 m. To make sure that the speed and the positions of the cutter and paper match during the cut process, the parameters of the **MOVELINK** command must be correct. The easiest way to do this is to consider the acceleration, constant speed and deceleration phases separately, and then combine them as required, according to these 2 rules:

fig. 38



Rule 1: In an acceleration phase to a matching speed, the link distance must be twice the movement distance. Therefore, the acceleration phase can be specified alone as:

MOVELINK(0.3,0.6,0.6,0,1)' move is all accel

Rule 2: In a constant speed phase with matching speed, the two axes move the same distance. Therefore, the distance to move must be equal the link distance. Therefore, the constant speed phase can be specified as:

MOVELINK(0.4,0.4,0,0,1)' all constant speed

The deceleration phase is set in this case to match the acceleration:

MOVELINK(0.3,0.6,0,0.6,1)' all decel

The movements of each phase can be added to give the total movement.

MOVELINK(1,1.6,0.6,0.6,1)' Same as 3 moves above

But in the example above, the acceleration phase is kept separate:

MOVELINK(0.3,0.6,0.6,0,1)

MOVELINK(0.7,1.0,0,0.6,1)

This allows the output to be switched on at the end of the acceleration phase.

Example

MOVELINK can be used to create an exact ratio gearbox between two axes.

Suppose it is required to create a gearbox link of 4000/3072. This ratio is inexact (1.30208333). If this ratio is entered into a **CONNECT** command, the axes will slowly creep out of synchronisation. To prevent this problem, set the "link option" to 4 to make **MOVELINK** repeat continuously.


MOVELINK(4000,3072,0,0,linkaxis,4)

Example In this example on coil winding the unit conversion factors **UNITS** are set so that the payout movements are in mm and the spindle position is measured in revolutions. The payout eye therefore moves 50 mm over 25 revolutions of the spindle with the command **MOVELINK(50,25,0,0,linkax)**. To accelerate over the first spindle revolution and decelerate over the final 3 use the command **MOVELINK(50,25,1,3,linkax)**.

```
OP(motor,ON) ' Switch spindle motor on
FOR layer=1 TO 10
  MOVELINK(50,25,0,0,1)
  MOVELINK(-50,25,0,0,1)
NEXT layer
WAIT IDLE
OP(motor,OFF)
```

See also **AXIS, UNITS, REP_OPTION.**

fig. 39



3.2.185 MOVEMODIFY

Type Axis command

Syntax **MOVEMODIFY(position)**
MM(position)

Description The **MOVEMODIFY** command changes the absolute end position of the current single-axis linear move (**MOVE, MOVEABS**). If there is no current move or the current move is not a linear move, then **MOVEMODIFY** is treated as a **MOVEABS** command. The **ENDMOVE** parameter will contain the position of the end of the current move in user units.

MOVEMODIFY works on the default basis axis (set with **BASE**) unless **AXIS** is used to specify a temporary base axis.

Arguments • **position**

The absolute position to be set as the new end of move.

fig. 40





fig. 41



Example A sheet of glass is fed on a conveyor and is required to stop 250 mm after the leading edge is sensed by a proximity switch. The proximity switch is connected to the registration input:

MOVE(10000) 'Start a long move on conveyor

REGIST(3) 'set up registration

WAIT UNTIL MARK

'MARK becomes TRUE when sensor detects glass edge


OFFPOS = -REG_POS 'set position where mark was seen to 0

WAIT UNTIL OFFPOS=0 'wait for OFFPOS to take effect

MOVEMODIFY(250) 'change move to stop at 250mm


Example A paper feed system slips. To counteract this, a proximity sensor is positioned one third of the way into the movement. This detects at which position the paper passes, and thus how much slip has occurred. The move is then modified to account for this variation.

```
paper_length=4000
DEFPOS(0)
REGIST(3)
MOVE(paper_length)
WAIT UNTIL MARK
slip=REG_POS-(paper_length/3)
offset=slip*3
MOVEMODIFY(paper_length+offset)
```



Example A satellite receiver sits on top of a van. It must align correctly to the satellite from data processed in a computer. This information is sent to the controller through the serial link and sets VR(0) and VR(1). This information is used to control the two axes.

```
MOVEMODIFY is used so that the position can be continuously changed even if the previous set position is not achieved.
bearing=0 'set lables for VRs
elevation=1
UNITS AXIS(0)=360/counts_per_rev0
UNITS AXIS(1)=360/counts_per_rev1
WHILE IN(2)=ON
  MOVEMODIFY(VR(bearing))AXIS(0) 'adjust bearing to match VR0
  MOVEMODIFY(VR(elevation))AXIS(1)'adjust elevation to match VR1
  WA(250)
WEND
RAPIDSTOP 'stop movement
WAIT IDLE AXIS(0)
MOVEABS(0) AXIS(0) 'return to transport position
WAIT IDLE AXIS(1)
MOVEABS(0) AXIS (1)
```



3.2.186 MPOS

Type	Axis parameter (read-only)
Syntax	MPOS
Description	The MPOS parameter is the measured position of the axis in user units as derived from the encoder. This parameter can be set using the DEFPOS command. The OFFPOS axis parameter can also be used to shift the origin point. MPOS is reset to 0 at start-up or after the controller has been reset. The range of the measured position is controlled with the REP_DIST and REP_OPTION axis parameters.
Arguments	N/A
Example	WAIT UNTIL MPOS >= 1250 SPEED = 2.5
See also	UNITS, AXIS, DEFPOS, ENCODER, FE, OFFPOS, REP_DIST, REP_OPTION, UNITS.

3.2.187 MSPEED

Type	Axis parameter (read-only)
Syntax	MSPEED
Description	The MSPEED parameter contains the measured speed in units/s. It is calculated by taking the change in the measured position in user units in the last servo period and divide it by the servo period (in seconds). The servo period is set with the SERVO_PERIOD parameter. MSPEED represents a snapshot of the speed and significant fluctuations, which can occur, particularly at low speeds. It can be worthwhile to average several readings if a stable value is required at low speeds.
Arguments	N/A
Example	No example.
See also	AXIS, SERVO_PERIOD, VP_SPEED, UNITS.

3.2.188 MTYPE

Type	Axis parameter (read-only)
Syntax	MTYPE
Description	The MTYPE parameter contains the type of move currently being executed. The possible values are given in the table below.

Move number	Move type
0	IDLE (no move)
1	MOVE
2	MOVEABS
3	MHELICAL
4	MOVECIRC
5	MOVEMODIFY
10	FORWARD
11	REVERSE
12	DATUM
13	CAM
14	JOG_FORWARD refer to FWD_JOG
15	JOG_REVERSE refer to REV_JOG
20	CAMBOX
21	CONNECT
22	MOVELINK

MTYPE can be used to determine whether a move has finished or if a transition from one move type to another has taken place.

A non-idle move type does not necessarily mean that the axis is actually moving. It can be at 0 speed part way along a move or interpolating with another axis without moving itself.

Arguments N/A

Example No example.

See also **AXIS, NTYPE**.

3.2.189 NAO

Type System parameter (read-only)

Syntax **NAO**

Description This parameter returns the number of analogue input channels connected on the MECHATROLINK-II expansion bus. For example a TJ1-MC__ will return 8 if there are 2 x AN2900 Units connected as each has 4 analogue input channels.

Arguments N/A

Example No example.

See also N/A

3.2.190 NEG_OFFSET

Type System parameter

Syntax **NEG_OFFSET=value**

Description For Piezo Operation. This allows a negative offset to be applied to the output **DAC** signal from the servo loop. The offset is applied after the **DAC_SCALE** function. An offset of 327 will represent an offset of 0.1 volts. It is suggested that an offset of 65% to 70% of the value required to make the stage move in an open loop situation is used.

Arguments • **value**
A BASIC expression.

Example No example.

See also N/A

3.2.191 NEW

Type Program command

Syntax **NEW ["program_name"]**

Description The **NEW** command deletes all program lines of the program in the controller. **NEW** without a program name can be used to delete the currently selected program (using **SELECT**). The program name can also be specified without quotes. **NEW ALL** will delete all programs.

The command can also be used to delete the TABLE memory.

NEW "TABLE" The name "**TABLE**" must be in quotes.

Note: This command is implemented for a Command Line Terminal. Within Trajexia Tools users can select the command from the Program menu.

Arguments N/A

Example No example.

See also **COPY, DEL, RENAME, SELECT, TABLE**

3.2.192 NEXT

See **FOR..TO..STEP..NEXT**.

3.2.193 NIO

Type System parameter

Syntax **NIO**

Description Returns the number of inputs/outputs fitted to the system, or connected on the MECHATROLINK-II expansion bus. A TJ-MC__ with no MECHATROLINK-II I/O will return **NIO=32**. The built-in inputs are channels 0 to 15. The built-in outputs are channels 8 to 15. Channels 16 to 27 can be used as "virtual" I/Os which are connected together. Input channels 28 to 31 are reserved to allow each axis to use the MECHATROLINK-II driver input channels for axis control functions.

Arguments N/A

Example No example.

See also N/A

3.2.194 NOT

Type Mathematical operation

Syntax **NOT expression**

Description The **NOT** operator performs the logical **NOT** function on all bits of the integer part of the expression.

The logical **NOT** function is defined as in the table below.

Bit	Result
0	1
1	0

Arguments • **expression.**
Any valid BASIC expression.

Example **>> PRINT 7 AND NOT 1**
6.0000

See also N/A

3.2.195 NTYPE

Type Axis parameter (read-only)

Syntax **NTYPE**

Description The **NTYPE** parameter contains the type of the move in the next move buffer. Once the current move has finished, the move present in the **NTYPE** buffer will be executed. The values are the same as those for the **MTYPE** axis parameter.
NTYPE is cleared by the **CANCEL(1)** command.

Arguments N/A

Example No example.

See also **AXIS, MTYPE**.

3.2.196 OFF

Type Constant (read-only)

Syntax **OFF**

Description The **OFF** constant returns the numerical value 0.

Arguments N/A

Example **OP (lever,OFF)**

The above line sets the output named lever to OFF.

See also N/A

3.2.197 OFFPOS

Type	Axis parameter
Syntax	OFFPOS
Description	<p>The OFFPOS parameter contains an offset that will be applied to the demand position (DPOS) without affecting the move which is in progress in any other way. The measured position will be changed accordingly in order to keep the Following Error. OFFPOS can therefore be used to effectively datum a system at full speed. The value set in OFFPOS will be reset to 0 by the system as the offset is loaded.</p> <p>Note: The offset is applied on the next servo period. Other commands may be executed prior to the next servo period. Be sure that these commands do not assume the position shift has occurred. This can be done by using the WAIT UNTIL statement (see example).</p>
Arguments	N/A
Example	<p>Change the current position by 125, with the Command Line Terminal:</p> <pre>>>?DPOS 300.0000 >>OFFPOS=125 >>?DPOS 425.0000</pre>
Example	<p>Define the current demand position as 0</p> <pre>OFFPOS=-DPOS WAIT UNTIL OFFPOS=0 ' wait until applied</pre> <p>This is equivalent to DEFPOS(0).</p>

Example A conveyor transports boxes. Labels must be applied onto these boxes. The **REGIST** function can capture the position at which the leading edge of the box is seen. Then, the **OFFPOS** command can adjust the measured position of the axis to make it 0 at that point. Thus, after the registration event has occurred, the measured position (seen in **MPOS**) reflects the absolute distance from the start of the box. The mechanism that applies the label can take advantage of the absolute position start mode of the **MOVELINK** or **CAMBOX** commands to apply the label.

BASE(conv)


REGIST(3)

WAIT UNTIL MARK

OFFPOS = -REG_POS ' Leading edge of box is now zero

See also **AXIS, DEFPOS, DPOS, MPOS, UNITS.**

fig. 44



3.2.198 ON

Type	Constant (read-only)
Syntax	ON
Description	The ON constant returns the numerical value 1.
Arguments	N/A
Example	OP (lever,ON) The above line sets the output named lever to ON .
See also	N/A

3.2.199 ON.. GOSUB

Type	Program control command
Syntax	ON expression GOSUB label [,label[,...]]
Description	The ON..GOSUB and ON..GOTO structures enable a conditional jump. The integer expression is used to select a label from the list. If the expression has value 1 the first label is used, for value 2 the second label is used, and so on. Once the label is selected, subroutine GOSUB jump to that label is performed. Note: If the expression is not valid e.g. the result of the expression is less than 1 or greater than the number of available labels in the program, no jump is performed.
Arguments	<ul style="list-style-type: none"> • expression Any valid BASIC expression. • label Any valid label in the program.
Example	REPEAT GET #1,char UNTIL 1<=char and char<=3 ON char GOSUB mover,stopper,change
See also	GOSUB..RETURN, GOTO.

3.2.200 ON.. GOTO

Type	Program control command
Syntax	ON expression GOTO label [,label[,...]]
Description	The expression is evaluated and then the integer part is used to select a label from the list. If the expression has the value 1 then the first label is used, 2 then the second label is used, and so on. If the value of the expression is less than 1 or greater than the number of labels then an error occurs. Once the label is selected, subroutine GOTO jump to that label is performed.
Arguments	<ul style="list-style-type: none"> • expression Any valid BASIC expression. • label Any valid label in the program.
Example	REPEAT GET #1,char UNTIL 1<=char and char<=3 ON char GOTO mover,stopper,change
See also	N/A

3.2.201 OP

Type	I/O command
Syntax	OP(output_number, value) OP(binary_pattern) OP

Description	<p>The OP command sets one or more outputs or returns the state of the first 24 outputs. OP has three different forms depending on the number of arguments.</p> <ul style="list-style-type: none"> Command OP(output_number,value) sets a single output channel. The range of output_number depends on the number of additional digital I/O connected over the MECHATROLINK-II bus and value is the value to be output, either 0 or 1. Command OP(binary_pattern) sets the binary pattern to the 24 outputs according to the value set by binary_pattern. Function OP (without arguments) returns the status of the first 24 outputs. This allows multiple outputs to be set without corrupting others which are not to be changed. <p>Note: The first 8 outputs (0 to 7) do not physically exist on the TJ1-MC__. They can not be written to and will always return 0.</p>	Example	<pre>val = 8 ' The value to set mask = OP AND NOT(15*256) ' Get current status and mask OP(mask OR val*256) ' Set val to OP(8) to OP(11) This routine sets value val to outputs 8 to 11 without affecting the other outputs by using masking.</pre>
Arguments	<ul style="list-style-type: none"> output_number The number of the output to be set. The range for this parameter depends on the number of additional digital I/O connected over the MECHATROLINK-II bus. If there are no digital I/O connected, the range for this parameter is 8..31 value The value to be output, either OFF (0) or ON (1). All non-0 values are considered as ON. binary_pattern The integer equivalent of the binary pattern is to be output. 	See also	IN.
Example	OP(12,1) OP(12,ON) <p>These two lines are equivalent.</p>	Type	Axis parameter
Example	OP(18*256) <p>This line sets the bit pattern 10010 on the first 5 physical outputs, outputs 13 to 17 would be cleared. The bit pattern is shifted 8 bits by multiplying by 256 to set the first available outputs as outputs 0 to 7 do not exist.</p>	Syntax	OPEN_WIN OW
Example	VR(0) = OP VR(0) = VR(0) AND 65280 OP(VR(0)) <p>This routine sets outputs 8 to 15 ON and all others off. The above programming can also be written as follows: OP(OP AND 65280)</p>	Description	The OPEN_WIN parameter defines the beginning of the window inside or outside which a registration event is expected. The value is in user units.
		Arguments	N/A
		Example	only look for registration marks between 170 and 230 OPEN_WIN = 170 CLOSE_WIN = 230 REGIST(256+3) WAIT UNTIL MARK
		See also	CLOSE_WIN, REGIST, UNITS.

3.2.202 OPEN_WIN

Type Axis parameter

Syntax **OPEN_WIN**
OW

Description The **OPEN_WIN** parameter defines the beginning of the window inside or outside which a registration event is expected. The value is in user units.

Arguments N/A

Example


```
only look for registration marks between 170 and 230
OPEN_WIN = 170
CLOSE_WIN = 230
REGIST(256+3)
WAIT UNTIL MARK
```

See also **CLOSE_WIN, REGIST, UNITS.**

3.2.203 OR

Type Mathematical operation

Syntax **expression1 OR expression2**

Description The **OR** operator performs the logical **OR** function between corresponding bits of the integer parts of two valid BASIC expressions.
The logical **OR** function between two bits is defined as in the table below.

Bit 1	Bit 2	Result
0	0	0
0	1	1
1	0	1
1	1	1

Arguments

- **expression1**
Any valid BASIC expression.
- **expression2**
Any valid BASIC expression.

Example **result = 10 OR (2.1*9)**
The parentheses are evaluated first, but only the integer part of the result, 18, is used for the operation. Therefore, this expression is equivalent to the following:
result = 10 OR 18

The **OR** is a bit operator and so the binary action taking place is:

01010 OR 10010 = 11010

Therefore, result will contain the value 26.

Example **IF KEY OR VR(0) = 2 THEN GOTO label**

See also N/A

3.2.204 OUTDEVICE

Type I/O parameter
Syntax **OUTDEVICE**
Description The **OUTDEVICE** parameter defines the default output device. This device will be selected for the **PRINT** command when the **#n** option is omitted. The **OUTDEVICE** parameter is task specific. The supported values are listed in the table below.

Value	Description
0	Programming port 0 (default)
1	RS-232C serial port 1
2	RS-422A/485 serial port 2
5	Trajexia Tools port 0 user channel 5
6	Trajexia Tools port 0 user channel 6
7	Trajexia Tools port 0 user channel 7

Arguments N/A

Example No example.

See also **PRINT**, INDEVICE.

3.2.205 OUTLIMIT

Type Axis parameter
Syntax **OUTLIMIT**
Description The output limit restricts the demand output from a servo axis to a lower value than the maximum. The value required varies depending on the maximum demand output possible. If the voltage output is generated by a 16 bit DAC values an **OUTLIMIT** of 32767 will produce the full +/-10v range. A MECHATROLINK-II speed axis has a 32 bit maximum demand.

Arguments N/A
Example **OUTLIMIT AXIS(1) = 16384**
The above will limit the voltage output to a +/-5V output range from the TJ1-FL02 unit. This will apply to the DAC command if SERVO=OFF, or to the voltage output by the servo loop if SERVO=ON.
See also **AXIS, S_REF, S_REF_OUT, SERVO**.

3.2.206 OV_GAIN

Type	Axis parameter
Syntax	OV_GAIN
Description	<p>The OV_GAIN parameter contains the output velocity gain. The output velocity output contribution is calculated by multiplying the change in measured position with the OV_GAIN parameter value. The default value is 0.</p> <p>Adding NEGATIVE output velocity gain to a system is mechanically equivalent to adding damping. It is likely to produce a smoother response and allow the use of a higher proportional gain than could otherwise be used, but at the expense of higher Following Errors. High values may cause oscillation and produce high Following Errors.</p> <p>Note: Negative values are normally required for OV_GAIN.</p> <p>Note: In order to avoid any instability the servo gains should be changed only when the SERVO is off.</p>
Arguments	N/A
Example	No example.
See also	D_GAIN, I_GAIN, P_GAIN, VFF_GAIN.

3.2.207 P_GAIN

Type	Axis parameter
Syntax	P_GAIN
Description	<p>The P_GAIN parameter contains the proportional gain. The proportional output contribution is calculated by multiplying the Following Error with the P_GAIN parameter value. The default value of P_GAIN for MECHATROLINK-II Speed axis (ATYPE = 41) is 131072. The default value for Flexible axis Servo (ATYPE = 44) is 1.0.</p> <p>The proportional gain sets the stiffness of the servo response. Values that are too high will cause oscillation. Values that are too low will cause large Following Errors.</p> <p>Note: In order to avoid any instability the servo gains should be changed only when the SERVO is off.</p>

Arguments N/A

Example No example.

See also **D_GAIN, I_GAIN, OV_GAIN, VFF_GAIN.**

3.2.208 PI

Type	Constant (read-only)
Syntax	PI
Description	The PI constant returns the numerical constant value of approximately 3.14159.
Arguments	N/A
Example	circum = 100 PRINT "Radius = "; circum/(2*PI)
See also	N/A

3.2.209 PMOVE

Type	Task parameter (read-only)
Syntax	PMOVE
Description	<p>The PMOVE parameter contains the status of the task buffers. The parameter returns TRUE if the task buffers are occupied, and FALSE if they are empty.</p> <p>When the task executes a movement command, the task loads the movement information into the task move buffers. The buffers can hold one movement instruction for any group of axes. PMOVE will be set to TRUE when loading of the buffers has been completed. When the next servo interrupt occurs, the motion generator loads the movement into the next move (NTYPE) buffer of the required axes if they are available. When this second transfer has been completed, PMOVE is cleared to 0 until another move is executed in the task. Each task has its own PMOVE parameter. Use the PROC modifier to access the parameter for a certain task. Without PROC the current task will be assumed.</p>
Arguments	N/A

Example No example.
See also **NTYPE, PROC.**

3.2.210 POS_OFFSET

Type System parameter
Syntax **POS_OFFSET=value**
Description For Piezo Operation. This keyword allows a positive offset to be applied to the output **DAC** signal from the servo loop. The offset is applied after the **DAC_SCALE** function. An offset of 327 will represent an offset of 0.1 volts for axis with servo output generated by a 16 bit DAC. It is suggested that as offset of 65% to 70% of the value required to make the stage move in an open loop situation is used.
Arguments N/A
Example No example.
See also N/A

3.2.211 POWER_UP

Type System parameter
Syntax **POWER_UP**
Description This parameter is used to determine whether or not programs should be read from flash EPROM on power up or software reset (**EX**).
Two values are possible: 0: Use the programs in battery backed RAM; 1: Copy programs from the controllers flash EPROM into RAM.
Programs are individually selected to be run at power up with the **RUNTYPE** command
Notes:

- **POWER_UP** is always an immediate command and therefore cannot be included in programs.
- This value is normally set by Trajexia Tools.

Arguments N/A

Example No example.
See also **EPROM**

3.2.212 PRINT

Type I/O command
Syntax **PRINT [#n,] expression { , expression }**
? [#n,] expression { , expression }
Description The **PRINT** command outputs a series of characters to the communication ports. **PRINT** can output parameters, fixed ASCII strings, and single ASCII characters. By using **PRINT #n**, any port can be selected to output the information to.
Multiple items to be printed can be put on the same line separated by a comma or a semi-colon. A comma separator in the print command places a tab between the printed items. The semi-colon separator prints the next item without any spaces between printed items.
The width of the field in which a number is printed can be set with the use of [w,x] after the number to be printed. The width of the column is given by w and the number of decimal places is given by x. Using only one parameter [x] takes the default width and specifies the number of decimal places to be printed. The numbers are right aligned in the field with any unused leading characters being filled with spaces. If the number is too long, then the field will be filled with asterisks to signify that there was not sufficient space to display the number. The maximum field width allowable is 127 characters.
The backslash \ command can be used to print a single ASCII character.

Arguments • **n**
The specified output device. When this argument is omitted, the port as specified by **OUTDEVICE** will be used. See the table below.

Value	Description
0	Programming port 0 (default)
1	RS-232C serial port 1
2	RS-422A/485 serial port 2

Value	Description
5	Trajexia Tools port 0 user channel 5
6	Trajexia Tools port 0 user channel 6
7	Trajexia Tools port 0 user channel 7

- **expression**
The expression to be printed.

Example **PRINT "CAPITALS and lower case CAN BE PRINTED"**

Example Consider VR(1) = 6 and **variab** = 1.5, the print output will be as follows:

```
PRINT 123.45, VR(1)-variab
123.4500 4.5000
```

Example **length:**

```
PRINT "DISTANCE = ";mpos
DISTANCE = 123.0000
```

In this example, the semi-colon separator is used. This does not tab into the next column, allowing the programmer more freedom in where the print items are placed.

Example **PRINT VR(1)[4,1]; variab[6,2]**
6.0 1.50

Example **params:**
PRINT "DISTANCE = ";mpos[0];" SPEED = ";v[2];
DISTANCE = 123 SPEED = 12.34

Example **PRINT "ITEM ";total" OF ";limit;CHR(13);**

Example **>> PRINT HEX(15),HEX(-2)**
F FFFF

See also **\$ (HEXADECIMAL INPUT), OUTDEVICE.**

3.2.213 PROC

Type Task command

Syntax **PROC(task_number)**

Description The **PROC** modifier allows a process parameter from a particular process to be read or written. If omitted, the current task will be assumed.

Arguments • **task_number**
The number of the task to access.

Example **WAIT UNTIL PMOVE PROC(3)=0**

See also N/A

3.2.214 PROC_STATUS

Type Task parameter

Syntax **PROC_STATUS**

Description The **PROC_STATUS** parameter returns the status of the process or task specified. The parameter is used with the **PROC** modifier and can return values listed in the table below.

Value	Description
0	Process stopped
1	Process running
2	Process stepping
3	Process paused

Arguments N/A

Example **WAIT UNTIL PROC_STATUS PROC(3)=0**

See also **PROCNR, PROC.**

3.2.215 PROCESS

Type Program command

Syntax	PROCESS
Description	The PROCESS command displays the running status of all current tasks with their task number.
Arguments	N/A
Example	No example.
See also	HALT, RUN, STOP.

3.2.216 PROCNUMBER

Type	Task parameter (read-only)
Syntax	PROCNMBER
Description	The PROCNMBER parameter contains the number of the task in which the currently selected program is running. PROCNMBER is often required when multiple copies of a program are running on different tasks.
Arguments	N/A
Example	MOVE(length) AXIS(PROCNMBER)
See also	PROC_STATUS, PROC.

3.2.217 PROFIBUS

Type	System command
Syntax	PROFIBUS(unit_number, 2,1,VR_start_outputs,no_outputs, VR_start_inputs,no_inputs) PROFIBUS(unit_number,4,0)
Description	PROFIBUS function 2 configures the TJ1-PRT for data exchange with the PROFIBUS-DP master unit and defines areas in the VR memory where I/O exchange takes place. PROFIBUS function 4 returns the data exchange status of the TJ1-PRT. Refer to the table below for the description of the bits in the data exchange status word.

Bit	Value	Description
0	0	Failed configuration of I/O data exchange
	1	I/O data exchange configured successfully
1	0	I/O data not available
	1	I/O data available
2	0	Data exchange active in OPERATE mode
	1	Data exchange active in CLEAR mode

Type	Task parameter (read-only)
Syntax	PROCNMBER
Description	The PROCNMBER parameter contains the number of the task in which the currently selected program is running. PROCNMBER is often required when multiple copies of a program are running on different tasks.
Arguments	<ul style="list-style-type: none"> • unit_number Specifies the unit number of the TJ1-PRT in the Trajexia system. • VR_start_outputs The starting address in VR memory of the controller where the output data from the PROFIBUS-DP master is located. • no_outputs The number of output words from the PROFIBUS-DP master in VR memory. • VR_start_inputs The starting address in VR memory of the controller where the input data for the PROFIBUS-DP master is located. • no_inputs The number of input words to the PROFIBUS-DP master in VR memory.
Example	PROFIBUS (0,2,1,10,16,150,31) In this example, the TJ1-PRT is configured to exchange data with PROFIBUS-DP master with 16 output words (received from the master) located at VR(10) to VR(25), and 31 input words (sent to the master) located at VR(150) to VR(180).

See also N/A

3.2.218 PSWITCH

Type	I/O command
------	-------------

Syntax	PSWITCH (switch, enable [, axis, output_number, output_state, set_position, reset_position])	Example
Description	<p>The PSWITCH command turns on an output when a predefined position is reached, and turns off the output when a second position is reached. The positions are specified as the measured absolute positions.</p> <p>There are 16 position switches each of which can be assigned to any axis. Each switch has assigned its own ON and OFF positions and output number. The command can be used with 2 or all 7 arguments. With only 2 arguments a given switch can be disabled.</p> <p>PSWITCHs are calculated on each servo cycle and the output result applied to the hardware. The response time is therefore 1 servo cycle period approximately.</p> <p>Note: An output may remain ON if it was ON when the PSWITCH was disabled. In such cases the OP command can be used to turn off an output as follows:</p> <p>PSWITCH(2,OFF) OP(14,OFF) ' Turn OFF pswitch controlling OP 14</p> <p>Note: The physical switches that are used with PSWITCH are not fast hardware switches, so switching is done by software, which can introduce some small delays in operation. Fast hardware switching can be used only with axes connected via the TJ1-FL02. Use the HW_PSWITCH command.</p>	<p>A rotating shaft has a cam operated switch which has to be changed for different size work pieces. There is also a proximity switch on the shaft to indicate the TDC of the machine. With a mechanical cam, the change from job to job is time consuming. This can be eased by using PSWITCH as a software cam switch. The proximity switch is wired to input 7 and the output is output 11. The shaft is controlled by axis 0. The motor has a 900ppr encoder. The output must be on from 80 units.</p> <p>PSWITCH uses the unit conversion factor to allow the positions to be set in convenient units. First the unit conversion factor must be calculated and set. Each pulse on an encoder gives four edges for the TJ1-MC__ to count. There are thus 3,600 edges/rev or 10 edges/degree. If you set the unit conversion factor to 10, you can work in degrees.</p> <p>Next you have to determine a value for all the PSWITCH arguments.</p> <p>sw: The switch number can be any switch that is not in use. In this example, you will use number 0.</p> <p>en: The switch must be enabled to work; set the enable to 1.</p> <p>axis: The shaft is controlled by axis 0.</p> <p>opno: The output being controlled is output 11.</p> <p>opst: The output must be on so set to 1.</p> <p>setpos: The output is to be produced at 80 units.</p> <p>rspos: The output is to be on for a period of 120 units.</p> <p>This can all be put together in the following lines of BASIC code:</p> <p>switch:</p> <p style="padding-left: 2em;">UNITS AXIS(0) = 10 ' Set unit conversion factor</p> <p style="padding-left: 2em;">REP_DIST = 360</p> <p style="padding-left: 2em;">REP_OPTION = ON</p> <p style="padding-left: 2em;">PSWITCH(0,ON,0,11,ON,80,200)</p> <p>This program uses the repeat distance set to 360 degrees and the repeat option on so that the axis position will be maintained between 0 and 360 degrees.</p> <p>HW_PSWITCH, OP, UNITS.</p>
Arguments	<ul style="list-style-type: none"> • switch The switch number. Range: [0,15]. • enable The switch enable. Range: [on, off]. • axis The number of the axis providing the position input. • output_number The physical output to set. Range: [8,31]. • output_state The state to output. Range: [on, off]. • set_position The absolute position in user units at which output is set. • reset_position The absolute position in user units at which output is reset. 	See also

3.2.219 RAPIDSTOP

Type Axis command

Syntax **RAPIDSTOP**
RS

Description The **RAPIDSTOP** command cancels the current move on all axes from the current move buffer (**MTYPE**). Moves for speed profiled move commands (**MOVE**, **MOVEABS**, **MOVEMODIFY**, **FORWARD**, **REVERSE**, **MOVECIRC** and **MHELICAL**) will decelerate to a stop with the deceleration rate as set by the **DECCEL** parameter. Moves for other commands will be immediately stopped.

Notes:

- **RAPIDSTOP** cancels only the presently executing moves. If further moves are buffered in the next move buffers (**NTYPE**) or the task buffers they will then be loaded.
- During the deceleration of the current moves additional **RAPIDSTOPs** will be ignored.

Arguments N/A


Example This example shows the implementation of a stop override button that cuts out all motion.

```

CONNECT (1,0) AXIS(1) 'axis 1 follows axis 0
BASE(0)
REPAEAT
MOVE(1000) AXIS (0)
MOVE(-100000) AXIS (0)
MOVE(100000) AXIS (0)
UNTIL IN (2)=OFF 'stop button pressed?
RAPIDSTOP
WA(10) 'wait to allow running move to cancel
RAPIDSTOP 'cancel the second buffered move
WA(10)
RAPIDSTOP 'cancel the third buffered move

```


fig. 45



Example This example shows the use of **RAPIDSTOP** to cancel a **MOVE** on the main axis and a **FORWARD** on the second axis. When the axes have stopped, a **MOVEABS** is applied to re-position the main axis.

```
BASE(0)
REGIST(3)
FORWARD AXIS(1)
MOVE (100000) 'apply a long move
WAIT UNTIL MARK
RAPIDSTOP
WAIT IDLE 'for MOVEABS to be accurate, the axis must stop
MOVEABS(3000)
```


fig. 46



Example This example shows the use of **RAPIDSTOP** to break a **CONNECT** and stop the motion. The connected axis stops immediately on the **RAPIDSTOP** command. The forward axis decelerates at the **DECCEL** value.

```
BASE(0)
CONNECT(1,1)
FORWARD AXIS(1)
WAIT UNTIL VPSPEED=SPEED 'let the axis get to full speed
WA(1000)
RAPIDSTOP
WAIT IDLE AXIS(1) 'wait for axis 1 to decel
CONNECT(1,1) 're-connect axis 0
REVERSE AXIS(1)
WAIT UNTIL VPSPEED=SPEED
WA(1000)
RAPIDSTOP
WAIT IDLE AXIS(1)
```

fig. 47



See also **CANCEL**, **MTYPE**, **NTYPE**.

3.2.220 READ_BIT

Type	System command
Syntax	READ_BIT(bit_number, vr_number)
Description	The READ_BIT command returns the value of the specified bit in the specified VR variable, either 0 or 1.
Arguments	<ul style="list-style-type: none"> • bit_number The number of the bit to be read. Range: [0,23]. • vr_number The number of the VR variable for which the bit is read. Range: [0,1023].
Example	No example.
See also	CLEAR_BIT, SET_BIT.

3.2.221 READ_OP

Type	I/O command
Syntax	READ_OP(output_no) READ_OP(first_output_no, last_output_no)
Description	<p>READ_OP(output_no), returns the binary value (0 or 1) of the digital output output_no.</p> <p>READ_OP(first_output_no, last_output_no), returns the number that is the decimal representation of the concatenation of the binary values of the range first_output_no to final_output_no.</p> <p>Note: The difference between first_output_no and last_output_no must be less than 24.</p> <p>Note: Outputs 0 to 7 do not physically exist on the TJ1-MC__. They cannot be written. Their return value is always 0.</p> <p>Note: READ_OP checks the state of the output logic. READ_OP can return the value 1 even if no actual output is present.</p>

Arguments	<ul style="list-style-type: none"> • output_no The number of the output. • first_output_no The number of the first output of the output range. • last_output_no The number of the last output of the output range.
Example	If output 11 has value 1, output 12 has value 1, output 13 has value 0, and output 14 has value 1, READ_OP(11,14) returns 13 (1101 bin).
Example	In this example a single output is tested: WAIT UNTIL READ_OP(12) = ON GOSUB place
Example	Check a range of 8 outputs and call a routine if one of them has value 1: op_bits = READ_OP(16, 23) IF op_bits <> 0 THEN GOSUB check_outputs ENDIF

See also N/A

3.2.222 REG_POS

Type	Axis parameter (read-only)
Syntax	REG_POS
Description	The REG_POS parameter stores the position in user units at which the primary registration event occurred.
Arguments	N/A

Example A paper cutting machine uses a CAM profile shape to quickly draw paper through servo driven rollers, and stop the paper so it can be cut. The paper is printed with a registration mark. This mark is detected and the length of the next sheet is adjusted by scaling the CAM profile with the third parameter of the CAM command:

' Example Registration Program using CAM stretching:

' Set window open and close:

length=200

OPEN_WIN=10

CLOSE_WIN=length-10

GOSUB Initial

Loop:

TICKS=0' Set millisecond counter to 0

IF MARK THEN

 offset=REG_POS

 ' This next line makes offset -ve if at end of sheet:

 IF ABS(offset-length)<offset THEN offset=offset-length

 PRINT "Mark seen at:"offset[5.1]

ELSE

 offset=0

 PRINT "Mark not seen"

ENDIF

' Reset registration prior to each move:

DEFPOS(0)

REGIST(3+768)' Allow mark at first 10mm/last 10mm of sheet

CAM(0,50,(length+offset*0.5)*cf,1000)

WAIT UNTIL TICKS<-500

GOTO Loop

Note: variable **cf** is a constant that is calculated depending on the draw length of the machine per encoder edge.

See also **AXIS, MARK, REGIST.**

3.2.223 REG_POSB

Type Axis parameter (read-only)

Syntax **REG_POSB**

Description The **REG_POSB** parameter stores the position in user units at which the secondary registration event occurred.

Arguments N/A

Example No example.

See also **AXIS, MARKB, REGIST.**

3.2.224 REGIST

Type	Axis command
Syntax	REGIST(mode)
Description	<p>The REGIST command sets up the registration operation. The command captures an axis position when a registration signal is detected. With a TJ1-FL02 the capture is done by the hardware, so software delays do not affect the accuracy of the position that is captured. With a MECHATROLINK-II axis, the capture is done by the Servo Driver.</p> <p>With a TJ1-FL02 Flexible Axis, a REGIST command can capture two registration positions using separate registration inputs. When a primary registration event has occurred, the MARK axis parameter is set to ON and the position is stored in the REG_POS axis parameter. For the secondary registration event, the MARKB axis parameter is set to ON and the position is stored in the REG_POSB axis parameter. MARKB and REG_POSB are applicable only to flexible axis axes with ATYPE values 43, 44 and 45.</p> <p>MECHATROLINK-II registration can be performed using encoder Z-marker or external registration inputs EXT1, EXT2 or EXT3 on a Servo Driver. Unlike Flexible axis axes, only one registration position can be captured. When a registration event has occurred, the MARK axis parameter is set to ON and the position is stored in the REG_POS axis parameter.</p> <p>The registration signals EXT1, EXT2 and EXT3 must be allocated to CN1 inputs with the driver parameter Pn511. For example Pn511=654x sets the connections of EXT1 to CN1 pin44, EXT2 to CN1 pin45 and EXT3 to CN1 pin46 of the Sigma II Servo Driver.</p> <p>The table below shows how to configure the external inputs individually.</p> <p>Note: To configure EXT1, EXT2 and EXT3 registration signals parameter numbers Pn511.1, Pn511.2 and Pn511.3 are used respectively. Pn511.0 is not used. Refer to the user manual of the Servo Driver for more details.</p>

Registration signal	Parameter number	Parameter value	Description
EXT 1	Pn511.1	0 to 3	Not used
		4	Input from CN1 pin44 (Rising edge)
		5	Input from CN1 pin45 (Rising edge).
		6	Input from CN1 pin46 (Rising edge).
		7	Signal always OFF.
		8	Signal always ON.
		9 to C	Not used
		D	Input from CN1 pin44 (Falling edge).
		E	Input from CN1 pin45 (Falling edge).
		F	Input from CN1 pin46 (Falling edge).
EXT 2	Pn511.2	As for EXT 1	As for EXT 1
EXT 3	Pn511.3	As for EXT 1	As for EXT 1



Note

The mapping of the registration signals in the table above applies to the Sigma-II Servo Driver. For the mapping of the registration signals of the Sigma-V Servo Driver, refer to section 6.1.6.

Inclusive windowing lets the registration to occur only within a specified window of axis positions. With this windowing function, registration events are ignored if the axis measured position is not greater than the **OPEN_WIN** axis parameter, and less than the **CLOSE_WIN** parameter.

Exclusive windowing allows the registration to occur only outside of the specified window of axis positions. With this windowing function, the registration events are ignored if the axis measured position is not less than the **OPEN_WIN** axis parameter, and greater than the **CLOSE_WIN** parameter.

Arguments • mode

The mode parameter specifies the registration input and event for use and the signal edge the registration event occurs. The mode parameter also specifies the use of the windowing function and filtering.

The mode parameter differs between MECHATROLINK-II and Flexible Axis.

The function of each bit in the mode parameter is explained in the tables below.

Bit	Function (MECHATROLINK-II)
1, 0	Primary registration occurs for: <ul style="list-style-type: none">• 00: Z-mark of the encoder• 01: EXT1 input (CN1 pin programmed with Pn511.1)• 10: EXT2 input (CN1 pin programmed with Pn511.2)• 11: EXT3 input (CN1 pin programmed with Pn511.3)
2 -7	Not used
9, 8	Windowing function choice: <ul style="list-style-type: none">• 00: No windowing• 01: Inclusive windowing• 10: Inclusive windowing• 11: Exclusive windowing
10	Not used

Bit	Function (Flexible Axis)
1, 0	Primary registration occurs for: <ul style="list-style-type: none">• 00: Z-mark of the encoder• 01: REG 0 input• 10: REG 1 input• 11: AUX IN input
2	Set this bit to use primary registration event
3	Primary registration event occurs on signal: <ul style="list-style-type: none">• 0: rising edge• 1: falling edge

Bit	Function (Flexible Axis)
5, 4	Secondary registration occurs for: <ul style="list-style-type: none"> • 00: Z-mark of the encoder • 01: REG 0 input • 10: REG 1 input • 11: AUX IN input
6	Set this bit to use secondary registration event
7	Secondary registration event occurs on signal: <ul style="list-style-type: none"> • 0: rising edge • 1: falling edge
9, 8	Windowing function choice: <ul style="list-style-type: none"> • 00: No windowing • 01: Inclusive windowing • 10: Inclusive windowing • 11: Exclusive windowing
10	Set this bit to use filtering function


Example A disc used in a laser printing process requires registration to the Z marker before it can start to print. The example code locates to the Z marker, and then sets it as the zero position.

```

REGIST(1) 'set registration point on Z mark
FORWARD 'start movement
WAIT UNTIL MARK
CANCEL 'stops movement after Z mark
WAIT IDLE
MOVEABS (REG_POS) 'relocate to Z mark
WAIT IDLE
DEFPOS(0) 'set zero position

```

fig. 48




Example Components are placed on a flighted belt. The flights are 120 mm apart. The components are on the belt 30 mm from the flights. When a component is found, an actuator pushes it off the belt. To prevent that the sensor finds a flight instead of a component, registration with windowing is used.

```

REP_DIST=120 'sets repeat distance to pitch of belt flights
REP_OPTION=ON
OPEN_WIN=30 ' sets window open position
CLOSE_WIN=90 ' sets window close position
REGIST(4+256) ' R input registration with windowing
FORWARD ' start the belt
box_seen=0
REPEAT
  WAIT UNTIL MPOS<60 ' wait for centre point between flights
  WAIT UNTIL MPOS>60 ' so that actuator is fired between flights
  IF box_seen=1 THEN ' was a box seen on the previous cycle?
    OP(8,ON) ' fire actuator
    WA(100)
    OP(8,OFF) ' retract actuator
    box_seen=0
  ENDIF
  IF MARK THEN box_seen=1 ' set "box seen" flag
  REGIST(4+256)
  UNTIL IN(2)=OFF
  CANCEL ' stop the belt
  WAIT IDLE

```

fig. 49



Example A machine adds glue to the top of a box. To do this, it must switch output 8. It must detect the rising edge (appearance) and the falling edge (end) of a box. Also, the MPOS must be set to zero when the Z position is detected.

```
reg=6 'select registration mode 6 (rising edge R, rising edge Z)
```

```
REGIST(reg)
```

```
FORWARD
```

```
WHILE IN(2)=OFF
```

```
  IF MARKB THEN 'on a Z mark mpos is reset to zero
```

```
    OFFPOS=-REG_POSB
```

```
    REGIST(reg)
```

```
  ELSEIF MARK THEN 'on R input output 8 is toggled
```

```
    IF reg=6 THEN
```

```
      'select registration mode 8 (falling edge R, rising edge Z)
```

```
      reg=8
```

```
      OP(8,ON)
```

```
    ELSE
```

```
      reg=6
```

```
      OP(8,OFF)
```

```
    ENDIF
```

```
    REGIST(reg)
```


```
  ENDIF
```

```
WEND
```

```
CANCEL
```

See also [AXIS](#), [MARK](#), [MARKB](#), [REG_POS](#), [REG_POSB](#), [OPEN_WIN](#), [CLOSE_WIN](#).

fig. 50



Note

The current Trajexia firmware version (1.6652) does not properly support this command for Sigma-V Servo Drivers.

3.2.225 REMAIN

Type	Axis parameter (read-only)
Syntax	REMAIN
Description	<p>The REMAIN parameter contains the distance remaining to the end of the current move. It can be checked to see how much of the move has been completed.</p> <p>The units in which REMAIN is expressed depends on the type of the motion command:</p> <ul style="list-style-type: none"> • If a master axis is moved by MOVELINK or CAMBOX, REMAIN is expressed in user units set by UNITS. • If a slave axis is moved by MOVELINK or CAMBOX, REMAIN is expressed in encoder counts. • If a master or a slave axis is moved by a motion command that is not MOVELINK or CAMBOX, REMAIN is expressed in user units set by UNITS. <p>The CONNECT command moves an axis without a defined end. For this command, REMAIN has the fixed value of 1000.</p>
Arguments	N/A
Example	<p>To change the speed to a slower value 5mm from the end of a move.</p> <p>start:</p> <pre>SPEED = 10 MOVE(45) WAIT UNTIL REMAIN < 5 SPEED = 1 WAIT IDLE</pre>
See also	AXIS, UNITS

3.2.226 REMOTE_ERROR

Type	Axis parameter
Syntax	REMOTE_ERROR

Description	Returns the number of errors on the MECHATROLINK-II communication link of a driver.
Arguments	N/A
Example	>>PRINT REMOTE_ERROR 1.0000
See also	N/A

3.2.227 RENAME

Type	Program command
Syntax	RENAME "old_program_name" "new_program_name"
Description	<p>The RENAME command changes the name of a program in the TJ1-MC__ directory. The program names can also be specified without quotes.</p> <p>Note: This command is implemented for a Command Line Terminal only and should not be used from within programs. Within Trajexia Tools users can select the command from the Program menu.</p>
Arguments	<ul style="list-style-type: none"> • old_program_name The current name of the program. • new_program_name The new name of the program.
Example	RENAME "car" "voiture"
See also	COPY, DEL, NEW.

3.2.228 REP_DIST

Type	Axis parameter
Syntax	REP_DIST

Description The **REP_DIST** parameter contains the repeat distance, which is the allowable range of movement for an axis before the demand position (**DPOS**) and measured position (**MPOS**) are corrected. **REP_DIST** is defined in user units. The exact range is controlled by **REP_OPTION**. The **REP_DIST** can have any non-0 positive value.

When the measured position has reached its limit, the TJ1-MC__ will adjust the absolute positions without affecting the move in progress or the servo algorithm. Note that the demand position can be outside the range because the measured position is used to trigger the adjustment. When measured position reaches **REP_DIST**, twice that distance is subtracted to ensure that the axis always stays in the range [-**REP_DIST**, **REP_DIST**], assuming that **REP_OPTION=OFF**, or in the range [0, **REP_OPTION**], assuming that **REP_OPTION=ON**.

For every occurrence (**DEFPOS**, **OFFPOS**, **MOVEABS**, **MOVEMODIFY**) which defines a position outside the range, the end position will be redefined within the range.

The default value for all axes is 5000000.

Arguments N/A

Example No example.

See also **AXIS**, **DPOS**, **MPOS**, **REP_OPTION**, **UNITS**.

3.2.229 REP_OPTION

Type Axis parameter

Syntax **REP_OPTION**

Description The **REP_OPTION** parameter controls the application of the **REP_DIST** axis parameter and the repeat option of the **CAMBOX** and **MOVELINK** Axis commands. The default value is 0. See the table below.

Bit	Description
0	The repeated distance range is controlled by bit 0 of the REP_OPTION parameter. <ul style="list-style-type: none"> If REP_OPTION bit 0 is off, the range of the demanded and measured positions will be between -REP_DIST and REP_DIST. If REP_OPTION bit 0 is on, the range of the demanded and measured positions will be between 0 and REP_DIST.
1	The automatic repeat option of the CAMBOX and MOVELINK commands are controlled by bit 1 of the REP_OPTION parameter. The bit is set on to request the system software to end the automatic repeat option. When the system software has set the option off it automatically clears bit 1 of REP_OPTION .

Arguments N/A

Example No example.

See also **AXIS**, **CAMBOX**, **MOVELINK**, **REP_DIST**.

3.2.230 REPEAT..UNTIL

Type Program control command

Syntax **REPEAT**
 commands
 UNTIL condition

Description The **REPEAT ... UNTIL** structure allows the program segment between the **REPEAT** and the **UNTIL** statement to be repeated a number of times until the condition becomes **TRUE**.

Note: **REPEAT ... UNTIL** construct can be nested indefinitely.

Arguments

- commands**
Any valid set of BASIC commands
- condition**
Any valid BASIC logical expression

Example A conveyor is to index 100mm at a speed of 1000mm/s, wait for 0.5s and then repeat the cycle until an external counter signals to stop by turning on input 4. cycle:

```
SPEED = 1000
REPEAT
  MOVE(100)
  WAIT IDLE
  WA(500)
UNTIL IN(4) = ON
```

See also **FOR..TO..STEP..NEXT, WHILE..WEND.**

Description The **REV_IN** parameter contains the input number to be used as a reverse limit input. The valid input range is 0 to 31. Values 0 to 15 represent physically present inputs of TJ1-MC__ I/O connector and are common for all axes. Values 16 to 31 are mapped directly to driver inputs that are present on the CN1 connector. They are unique for each axis. It depends on the type of Servo Driver which Servo Driver inputs are mapped into inputs 16 to 31. For more information on Servo Driver I/O mapping into the Trajexia I/O space, refer to section 6.1.4.
As default the parameter is set to -1, no input is selected.
If an input number is set and the limit is reached, any reverse motion on that axis will be stopped. Bit 5 of the **AXISSTATUS** axis parameter will also be set.
Note: This input is active low.

3.2.231 RESET

Type System command

Syntax **RESET**

Description The **RESET** command sets the value of all local variables of the current BASIC task to 0.

Arguments N/A

Example No example.

See also **CLEAR.**

Arguments N/A

Example No example.

See also **AXIS, AXISSTATUS, FWD_IN.**

3.2.232 RETURN

See **GOSUB..RETURN.**

3.2.233 REV_IN

Type Axis parameter

Syntax **REV_IN**

Type Axis parameter

Syntax **REV_JOG**

Description The **REV_JOG** parameter contains the input number to be used as a jog reverse input. The input can be from 0 to 31. As default the parameter is set to -1, no input is selected.
Note: This input is active low.

Arguments N/A

Example No example.

See also **AXIS, FAST_JOG, FWD_JOG, JOGSPEED, UNITS.**


3.2.235 REVERSE

Type	Axis command
Syntax	REVERSE RE
Description	<p>The REVERSE command moves an axis continuously in reverse at the speed set in the SPEED parameter. The acceleration rate is defined by the ACCEL axis parameter.</p> <p>REVERSE works on the default basis axis (set with BASE) unless AXIS is used to specify a temporary base axis.</p> <p>Note: The reverse motion can be stopped by executing the CANCEL or RAPIDSTOP command, or by reaching the reverse limit, inhibit, or origin return limit.</p>
Arguments	N/A
Example	Run an axis in reverse. When an input signal is detected on input 5, stop the axis. back: REVERSE WAIT UNTIL IN(0) = ON ' Wait for stop signal CANCEL

Example Run an axis in reverse. When it reaches a certain position, slow down.

```
DEFPOS(0) ' set starting position to zero
REVERSE
WAIT UNTIL MPOS<-129.45
SPEED=slow_speed
WAIT UNTIL VP_SPEED=slow_speed ' wait until the axis slows
OP(11,ON) ' turn on an output to show that speed is now slow
```

fig. 51




Example A joystick is used to control the speed of a platform. A deadband is required to prevent oscillations from the joystick midpoint. This is done with the **REVERSE** command, which sets the correct direction relative to the operator. Then, the joystick adjusts the speed through analog input 0.

```
REVERSE
WHILE IN(2)=ON
  IF AIN(0)<50 AND AIN(0)>-50 THEN 'sets a deadband in the input
    SPEED=0
  ELSE
    SPEED=AIN(0)*100 'sets speed to a scale of AIN
  ENDIF
WEND
CANCEL
```

See also **AXIS, CANCEL, FORWARD, RAPIDSTOP.**

fig. 52



3.2.236 RS_LIMIT

Type	Axis parameter
Syntax	RS_LIMIT RSLIMIT
Description	<p>The RS_LIMIT parameter contains the absolute position of the reverse software limit in user units.</p> <p>A software limit for reverse movement can be set from the program to control the working range of the machine. When the limit is reached, the TJ1-MC__ will decelerate to 0, and then cancel the move. Bit 10 of the AXISSTATUS axis parameter will be turned on while the axis position is smaller than / below RS_LIMIT.</p>
Arguments	N/A
Example	No example.
See also	AXIS, FS_LIMIT, UNITS.

3.2.237 RUN

Type	Program command
Syntax	RUN ["program_name" [, task_number]]
Description	<p>The RUN command executes the program in the TJ1-MC__ as specified with program_name. RUN with the program name specification will run the current selected program. The program name can also be specified without quotes.</p> <p>The task number specifies the task number on which the program will be run. If the task number is omitted, the program will run on the highest available task. RUN can be included in a program to run another program.</p> <p>Note: Execution continues until one of the following occurs:</p> <ul style="list-style-type: none"> • There are no more lines to execute. • HALT is typed at the command line to stop all programs. • STOP is typed at the command line to stop a single program. • The STOP command in the program is encountered. • A run-time error is encountered.

- Arguments
- **program_name**
Any valid program name.
 - **task_number**
Any valid task number. Range: [1,14].

Example

```
>> SELECT "PROGRAM"
PROGRAM selected
>> RUN
This example executes the currently selected program.
```

Example

```
RUN "sausage"
```

This example executes the program named **sausage**.

Example

```
RUN "sausage",3
```

This example executes the program named **sausage** on task 3.

See also

HALT, STOP.

3.2.238 RUN_ERROR

Type	Task parameter (read-only)
Syntax	RUN_ERROR
Description	<p>The RUN_ERROR parameter contains the number of the last BASIC run-time error that occurred on the specified task.</p> <p>Each task has its own RUN_ERROR parameter. Use the PROC modifier to access the parameter for a certain task. Without PROC the current task will be assumed.</p> <p>The table below gives an overview of error numbers and the associated error messages.</p>

Number	Message	Number	Message
1	Command not recognized	70	Value is incorrect
2	Invalid transfer type	71	Invalid I/O channel
3	Error programming Flash	72	Value cannot be set. Use CLEAR_PARAMS command
4	Operand expected	73	Directory not locked

Number	Message	Number	Message
5	Assignment expected	74	Directory already locked
6	QUOTES expected	75	Program not running on this process
7	Stack overflow	76	Program not running
8	Too many variables	77	Program not paused on this process
9	Divide by zero	78	Program not paused
10	Extra characters at end of line	79	Command not allowed when running Trajexia Tools
11] expected in PRINT	80	Directory structure invalid
12	Cannot modify a special program	81	Directory is locked
13	THEN expected in IF/ELSEIF	82	Cannot edit program
14	Error erasing Flash	83	Too many nested OPERANDS
15	Start of expression expected	84	Cannot reset when drive servo on
16) expected	85	Flash Stick blank
17	, expected	86	Flash Stick not available on this controller
18	Command line broken by ESC	87	Slave error
19	Parameter out of range	88	Master error
20	No process available	89	Network timeout
21	Value is read only	90	Network protocol error
22	Modifier not allowed	91	Global definition is different
23	Remote axis is in use	92	Invalid program name
24	Command is command line only	93	Program corrupt
25	Command is runtime only	94	More than one program running when trying to set GLOBAL/CONSTANT
26	LABEL expected	95	Program encrypted
27	Program not found	96	TOKEN definition incorrect

Number	Message	Number	Message
28	Duplicate label	97	Cannot change program type once it has been created
29	Program is locked	98	Command expected
30	Program(s) running	99	Invalid command
31	Program is stopped	100	Invalid parameter for command
32	Cannot select program	101	Too many tokens in block
33	No program selected	102	Invalid mix of modal groups
34	No more programs available	103	Variable defined outside include file
35	Out of memory	104	Invalid program type
36	No code available to run	105	Variable not declared
37	Command out of context	106	(expected
38	Too many nested structures	107	Number expected
39	Structure nesting error	108	AS expected
40	ELSE/ELSEIF/ENDIF without previous IF	109	STRING, VECTOR or ARRAY expected
41	WEND without previous WHILE	110	String expected
42	UNTIL without previous REPEAT	111	Invalid MSPHERICAL input
43	Variable expected	112	Too many labels
44	TO expected after FOR	113	Symbol table locked
45	Too many nested FOR/NEXT	114	Incorrect symbol type
46	NEXT without FOR	115	Invalid mix of data types
47	UNTIL/IDLE expected after WAIT	116	Command not allowed when running Trajexia Tools
48	GOTO/GOSUB expected	117	Parameter expected
49	Too many nested GOSUB	118	Firmware error: Device in use
50	RETURN without GOSUB	119	Device error: Timeout waiting for device

Number	Message	Number	Message
51	LABEL must be at start of line	120	Device error: Command not supported by device
52	Cannot nest one line IF	121	Device error: CRC error
53	LABEL not found	122	Device error: Error writing to device
54	LINE NUMBER cannot have decimal point	123	Device error: Invalid response from device
55	Cannot have multiple instances of REMOTE	124	Firmware error: Cannot reference data outside current block
56	Invalid use of \$	125	Disk error: Invalid MBR
57	VR(x) expected	126	Disk error: Invalid boot sector
58	Program already exists	127	Disk error: Invalid sector/cluster reference
59	Process already selected	128	File error: Disk full
60	Duplicate axes not permitted	129	File error: File not found
61	PLC type is invalid	130	File error: Filename already exists
62	Evaluation error	131	File error: Invalid filename
63	Reserved keyword not available on this controller	132	File error: Directory full
64	VARIABLE not found	133	Command only allowed when running Trajexia Tools
65	Table index range error	134	# expected
66	Features enabled do not allow ATYPE change	135	FOR expected
67	Invalid line number	136	INPUT/OUTPUT/APPEND expected
68	String exceeds permitted length	137	File not open
69	Scope period should exceed number of AIN parameters	138	End of file

Arguments N/A
Example >> PRINT RUN_ERROR PROC(5)
9.0000
See also **BASICERROR, ERROR_LINE, PROC.**

3.2.239 RUNTYPE

Type Program command
Syntax **RUNTYPE "program_name", auto_run [, task_number]**
Description The **RUNTYPE** command determines whether the program, specified by **program_name**, is run automatically at start-up or not and which task it is to run on. The task number is optional, if omitted the program will run at the highest available task.
The current **RUNTYPE** status of each programs is displayed when a **DIR** command is executed. If any program has compilation errors no programs will be started at power up. To set the **RUNTYPE** using Trajexia Tools, select **Set Power-up mode** from the **Program** menu.

Arguments

- program_name**
The name of the program whose **RUNTYPE** is being set.
- auto_run**
0 = Running manually on command; 1 = Automatically execute on power up. All non-zero values are considered as 1.
- task_number**
The number of the task on which to execute the program. Range: [1, 14].

Example >> **RUNTYPE progname,1,3**
This line sets the program **progname** to run automatically at start-up on task 3.

Example >> **RUNTYPE progname,0**
This line sets the program **progname** to manual running.

See also **AUTORUN, EPROM, EX.**

3.2.240 S_REF

Type	Axis parameter
Syntax	DAC S_REF
Description	<p>This parameter contains the speed reference value which is applied directly to the Servo Driver when the axis is in open loop (SERVO=OFF). The range of this parameter is defined by the number of available bits. For MECHATROLINK-II axes, S_REF takes 32 bits, so the available range is [-2147483648, 2147483648], which corresponds to a voltage range [-10V, 10V]. For Flexible axis axes, S_REF takes 16 bits, so the available range is [-32768, 32767], which corresponds to a voltage range [-10V, 10V]. These ranges can be limited by using the OUTLIMIT parameter.</p> <p>The value currently being applied to the driver can be read using the S_REF_OUT axis parameter.</p>
Arguments	N/A
Example	WDOG = ON SERVO = OFF square: S_REF AXIS(0) = 2000 WA(250) S_REF AXIS(0) = -2000 WA(250) GOTO square <p>These lines can be used to force a square wave of positive and negative movement with a period of approximately 500ms on axis 0.</p>
See also	AXIS, S_REF_OUT, OUTLIMIT, SERVO.

3.2.241 S_REF_OUT

Type	Axis parameter (read-only)
Syntax	DAC_OUT S_REF_OUT

Description	The S_REF_OUT parameter contains the speed reference value being applied to the Servo Driver for both open and closed loop. In closed loop (SERVO=ON), the motion control algorithm will output a speed reference signal determined by the control gain settings and the Following Error. The position of the servo motor is determined using the Axis commands. In open loop (SERVO=OFF), the speed reference signal is determined by the S_REF axis parameter.
Arguments	N/A
Example	>> PRINT S_REF_OUT AXIS(0) 288.0000
See also	AXIS, S_REF, OUTLIMIT, SERVO.

3.2.242 SCOPE

Type	System command
Syntax	SCOPE(control, period, table_start, table_stop, P0 [, P1 [, P2 [, P3]]])
Description	<p>The SCOPE command programs the system to automatically store up to 4 parameters every sample period. The storing of data will start as soon as the TRIGGER command has been executed.</p> <p>The sample period can be any multiple of the servo period. The parameters are stored in the TABLE array and can then be read back to a computer and displayed on the Trajexia Tools Oscilloscope or written to a file for further analysis using the Create Table file option on the File menu.</p> <p>The current TABLE position for the first parameter which is written by SCOPE can be read from the SCOPE_POS parameter.</p> <p>Notes:</p> <ol style="list-style-type: none"> 1.Trajexia Tools uses the SCOPE command when running the Oscilloscope function. 2.To minimize calculation time for writing the real-time data, the SCOPE command is writing raw data to the TABLE array. For example <ul style="list-style-type: none"> a)The parameters are written in encoder edges (per second) and therefore not compensated for the UNITS conversion factor. b)The MSPEED parameter is written as the change in encoder edges per servo period. 3.Applications like the CAM command, CAMBOX command and the SCOPE command all use the same TABLE as the data area.

Arguments	<ul style="list-style-type: none"> • control Set on or off to control SCOPE execution. If turned on the SCOPE is ready to run as soon as the TRIGGER command is executed. • period The number of servo periods between data samples. • table_start The address of the first element in the TABLE array to start storing data. • table_stop The address of the last element in the TABLE array to be used. • P0 First parameter to store. • P1 Optional second parameter to store. • P2 Optional third parameter to store. • P3 Optional fourth parameter to store.
-----------	---

Example **SCOPE(ON,10,0,1000,MPOS AXIS(1),DPOS AXIS(1))**
This example programs the **SCOPE** function to store the **MPOS** parameter for axis 1 and the **DPOS** parameter for axis 1 every 10 servo cycles. The **MPOS** parameter will be stored in TABLE locations 0 to 499; the **DPOS** parameters, in TABLE locations 500 to 999. The **SCOPE** function will wrap and start storing at the beginning again unless stopped. Sampling will not start until the **TRIGGER** command is executed.

Example **SCOPE(OFF)**
This above line turns the scope function off.

See also **SCOPE_POS, TABLE, TRIGGER.**

3.2.243 SCOPE_POS

Type	System parameter (read-only)
Syntax	SCOPE_POS
Description	The SCOPE_POS parameter contains the current TABLE position at which the SCOPE command is currently storing its parameters.
Arguments	N/A

Example No example.

See also **SCOPE.**

3.2.244 SELECT

Type Program command

Syntax **SELECT "program_name"**

Description The **SELECT** command specifies the current program for editing, running, listing, etc. **SELECT** makes a new program if a program with the name entered does not exist. The program name can also be specified without quotes. When a program is selected, the commands **COMPILE, DEL, EDIT, LIST, NEW, RUN, STEPLINE, STOP** and **TROFF** will apply to the currently selected program unless a program name is specified in the command line. When another program is selected, the previously selected program will be compiled. The selected program cannot be changed when a program is running. Note: This command is implemented for a Command Line Terminal. Trajexia Tools automatically selects programs when you click on their entry in the list in the control panel.

Arguments N/A

Example **>> SELECT "PROGRAM"**
PROGRAM selected
>> RUN

See also **COMPILE, DEL, EDIT, LIST, NEW, RUN, STEPLINE, STOP, TROFF.**

3.2.245 SERVO

Type Axis parameter

Syntax **SERVO**

Description The **SERVO** parameter determines whether the base axis runs under servo closed loop control (**SERVO=ON**) or open loop (**SERVO=OFF**). In closed loop, the motion control algorithm will output a speed reference signal determined by the control gain settings and the Following Error. The position of the servo motor is determined using the Axis commands.
In open loop, the speed reference signal is completely determined by the **S_REF** axis parameter.

Arguments N/A

Example **SERVO AXIS(0) = ON** ' Axis 0 is under servo control
SERVO AXIS(1) = OFF ' Axis 1 is run open loop

See also **AXIS, FE_LIMIT, S_REF, S_REF_OUT, WDOG.**

3.2.246 SERVO_PERIOD

Type System parameter

Syntax **SERVO_PERIOD**

Description The **SERVO_PERIOD** parameter sets the servo cycle period of the TJ1-MC__. The timing of the execution of the program tasks and the refreshing of the control data and I/O of the Unit are all depending on this setting. The parameter is defined in microseconds. The TJ1-MC__ can be set in either 0.5, 1.0 or 2.0ms servo cycle. See the table below. The controller must be reset before the new servo period will be applied.

Value	Description
500	0.5ms
1000	1.0ms
2000	2.0ms

Arguments N/A

Example No example.

See also EX.



Caution

When the parameter has been set, a power down or software reset (using **EX**) must be performed for the complete system. Not doing so may result in undefined behaviour.

3.2.247 SET_BIT

Type System command

Syntax **SET_BIT(bit_number, vr_number)**

Description The **SET_BIT** command sets the specified bit in the specified VR variable to one. Other bits in the variable will keep their values.

Arguments

- **bit_number**
The number of the bit to be set. Range: [0,23].
- **vr_number**
The number of the VR variable for which the bit is set. Range: [0,1023].

Example No example.

See also **CLEAR_BIT, READ_BIT, VR.**

3.2.248 SETCOM

Type Communication command

Syntax **SETCOM(baud_rate, data_bits, stop_bits, parity, port_number, mode)**

Description The **SETCOM** command sets the serial communications for the serial ports. The command will enable the Host Link protocols or define the general-purpose communication. The serial ports have 9,600 baud rate, 7 data bits, 2 stop bits, even parity and XON/XOFF enabled for general-purpose communication by default. These default settings are recovered at start-up.

- Arguments
- **baud_rate**
1200, 2400, 4800, 9600, 19200, 38400
 - **data_bits**
7, 8
 - **stop_bits**
1, 2
 - **parity**
0 = None; 1 = Odd; 2 = Even.
 - **port_number**
See the table below.

port_number value	Description
1	RS-232C serial port 1
2	RS-422A/485 serial port 2

- **mode**
Select one of the modes listed in the table below for serial ports 1 and 2.

Mode	Description
0	General-purpose communication (no XON/XOFF mechanism)
5	Host Link Slave protocol
6	Host Link Master protocol

Example **SETCOM(19200, 7, 2, 2, 1, 6)**
 This sets RS-232C port to 19200 baud rate, 7 data bits, 2 stop bits, even parity for communication as a Host Link Master.

See also N/A

3.2.249 SGN

Type Mathematical function
 Syntax **SGN(expression)**
 Description The **SGN** function returns the sign of a number. It returns value 1 for positive values (including 0) and value -1 for negative values.
 Arguments • **expression**
 Any valid BASIC expression.
 Example **>> PRINT SGN(-1.2)**
-1.0000
 See also N/A

3.2.250 SIN

Type Mathematical function
 Syntax **SIN(expression)**
 Description The **SIN** function returns the sine of the expression. Input values are in radians and may have any value. The result value will be in the range from -1 to 1.
 Arguments • **expression**
 Any valid BASIC expression.
 Example **>> PRINT SIN(PI/2)**
1.0000
 See also N/A

3.2.251 SLOT

Type Slot modifier
 Syntax **SLOT**

Description Modifier specifies the unit number for a parameter such as **COMMSTYPE**.
Trajexia unit numbers are 0 to 6, counting from the left most unit.

Arguments N/A

Example No example.

See also N/A

3.2.252 SPEED

Type Axis parameter

Syntax **SPEED**

Description The **SPEED** parameter contains the demand speed for an axis in units/s. It can have any positive value (including 0). The demand speed is the maximum speed for the speed profiled motion commands.

Arguments N/A

Example **SPEED = 1000**
PRINT "Set speed = ";SPEED

See also **ACCEL, AXIS, DATUM, DECEL, FORWARD, MOVE, MOVEABS, MOVECIRC, MOVEMODIFY, REVERSE, UNITS.**

3.2.253 SPEED_SIGN

Type Axis parameter

Syntax **SPEED_SIGN**

Description The **SPEED_SIGN** parameter configures the voltage range of the analog speed reference output of the TJ1-FL02 when the axis type **ATYPE** is set to 44.

If **SPEED_SIGN = OFF**, the voltage range of the analog speed reference output is [-10V, 10V]. The positive reference voltage corresponds to forward movements, in which case **DPOS** and **MPOS** increment. The negative reference voltage corresponds to reverse movements, in which case **DPOS** and **MPOS** decrement. OFF is the default setting at power-on.

If **SPEED_SIGN = ON**, the voltage range of the analog speed reference output is [0V, 10V]. The OUT1 signal of the TJ1-FL02 for the corresponding axis is used as a direction signal. During forward movements, the controller sets OUT1 to OFF. During reverse movements, the controller sets OUT1 to ON. This setting is to be used for Servo Drivers that require both speed and direction signals as a speed reference.

Arguments N/A

Example No example.

See also **ATYPE, S_REF, S_REF_OUT**.

3.2.254 SQR

Type Mathematical function

Syntax **SQR(expression)**

Description The **SQR** function returns the square root of the expression. The expression must have positive (including 0) value.

Arguments • **expression**
Any valid BASIC expression.

Example **>> PRINT SQR(4)**
2.0000

See also N/A

3.2.255 SRAMP

Type Axis parameter

Syntax	SRAMP	Description	This command sets up a ratio for the output of the stepper axis. Every servo-period the number of steps is passed through the STEP_RATIO function before it goes to the step pulse output. Pulse Count Out = (numerator)/(denominator) * MPOS . STEP_RATIO affects both MOVECIRC and CAMBOX .
Description	The SRAMP parameter contains the S-curve factor. The S-curve factor controls the amount of rounding applied to the trapezoidal profiles. A value of 0 sets no rounding. A value of 10 sets maximum rounding. The default value of the parameter is 0. SRAMP is applied to the FORWARD , MOVE , MOVEABS , MOVECIRC , MHELICAL and REVERSE commands.	Notes:	<ul style="list-style-type: none"> Using S-curves increases the time required for the movement to complete. The S-curve factor must not be changed while a move is in progress.
Arguments	N/A	Arguments	<ul style="list-style-type: none"> denominator An integer number between 0 and 16777215 that is used to define the denominator in the above equation. numerator An integer number between 0 and 16777215 that is used to define the numerator in the above equation.
Example	No example.	Example	Two axes are set up as X and Y but the axes' steps per mm are not the same. Interpolated moves require identical UNITS values on both axes in order to keep the path speed constant and for MOVECIRC to work correctly. The axis with the lower resolution is changed to match the higher step resolution axis so as to maintain the best accuracy for both axes. <pre>' Axis 0: 500 counts per mm (31.25 steps per mm) ' Axis 1: 800 counts per mm (50.00 steps per mm) BASE(0) STEP_RATIO(500,800) UNITS = 800 BASE(1) UNITS = 800</pre>
See also	AXIS .	See also	N/A

3.2.256 STEP

See **FOR..TO..STEP..NEXT**.

3.2.257 STEP_RATIO

Type	Axis command
Syntax	STEP_RATIO(output_count, dpos_count)

3.2.258 STEPLINE

Type Program command

Syntax **STEPLINE ["program_name" [, task_number]]**

Description The **STEPLINE** command executes one line (i.e., "steps") in the program specified by **program_name**. The program name can also be specified without quotes. If **STEPLINE** is executed without program name on the command line the current selected program will be stepped. If **STEPLINE** is executed without program name in a program this program will be stepped. If the program is specified then all occurrences of this program will be stepped. A new task will be started when there is no copy of the program running. If the task is specified as well then only the copy of the program running on the specified task will be stepped. If there is no copy of the program running on the specified task then one will be started on it.

Arguments

- **program_name**
The name of the program to be stepped.
- **task_number**
The number of the task with the program to be stepped. Range: [1,14].

Example **>> STEPLINE "conveyor"**

Example **>> STEPLINE "maths",2**

See also **RUN, SELECT, STOP, TROFF, TRON.**

Arguments

- **program_name**
The name of the program to be stopped.
- **task_number**
The number of the task with the program to be stopped.
Range: [1,14].

Example **>> STOP programe**

Example The lines from label on will not be executed in this example.

```
STOP
label:
PRINT var
RETURN
```

See also **HALT, RUN, SELECT.**

3.2.260 SYSTEM_ERROR

Type System parameter (read only)

Syntax **SYSTEM_ERROR**

Description The **SYSTEM_ERROR** parameter contains system errors that occurred in the TJ1 system since the last time it was initialized. The bits in the **SYSTEM_ERROR** parameter are given in the table below.

Bit	Description
0	BASIC error
1	Battery low error
2 - 7	Reserved for future use
8	Configuration unit error (Any unit in the system)
9	Configuration device error (Any device in the system)
10 - 15	Reserved for future use
16	Unit lost error (Any unit in the system)
17	Terminator not fitted

3.2.259 STOP

Type Program command

Syntax **STOP ["program_name" [, task_number]]**

Description The **STOP** command will halt execution of the program specified with **program_name**. If the program name is omitted, then the currently selected program will be halted. The program name can also be specified without quotes.

In case of multiple executions of a single program on different tasks the **task_number** can be used to specify the specific task to be stopped.

Bit	Description
18	Device lost error (Any device in the system)

Arguments N/A.

Example No example.

See also N/A

Description The **TABLE** command loads data to and reads data from the TABLE array. The TABLE has a maximum length of 64000 elements. The TABLE values are floating-point numbers with fractions. The TABLE can also be used to hold information, as an alternative to variables. The **TABLE** command has two forms.

- **TABLE(address, value{, value})** writes a sequence of values to the TABLE array. The location of the first element to write is specified by address. The sequence can have a maximum length of 20 elements.
- **TABLE(address)** returns the TABLE value at the entry specified by address.

3.2.261 T_REF

Type Axis parameter

Syntax **T_REF**
DAC

Description The **T_REF** parameter contains the torque reference value which will be applied to the servo motor. The range of this parameter is defined by the number of available bits. For MECHATROLINK-II axes, **T_REF** takes 32 bits, so the available range is [-2147483648, 2147483648], which corresponds to a voltage range [-10V, 10V]. For Flexible axis axes, **T_REF** takes 16 bits, so available range is [-32768, 32767], which corresponds to a voltage range [-10V, 10V]. These ranges can be limited by using the **OUTLIMIT** parameter. The actual torque reference is depending on the servo motor.

Arguments N/A

Example **T_REF AXIS(0)=1000**See also **AXIS, S_REF**.

A value in the TABLE can be read-only if a value of that number or higher has been previously written to the TABLE. For example, printing **TABLE(1001)** will produce an error message if the highest TABLE location previously written to the TABLE is location 1000. The total TABLE size is indicated by the **TSIZE** parameter. Note that this value is one more than the highest defined element address. The TABLE can be deleted with by using **DEL "TABLE"** or **NEW "TABLE"** on the command line.

Notes:

- Applications like the **CAM** command, **CAMBOX** command and the **SCOPE** command in Trajexia Tools all use the same TABLE as the data area. Do not use the same data area range for different purposes.
- The TABLE and VR data can be accessed from all different running tasks. To avoid problems of two program tasks writing unexpectedly to one global variable, write the programs in such a way that only one program writes to the global variable at a time.

Arguments **address**
The first location in the TABLE to read or write. Range: [0,63999]
value
The value to write at the given location and at subsequent locations.

Example **TABLE(100,0,120,250,370,470,530,550)**

The above line loads an internal table as below.

3.2.262 TABLE

Type System command

Syntax **TABLE(address, value {, value})**
TABLE(address)

Table entry	Value
100	0
101	120

Table entry	Value
102	250
103	370
104	470
105	530
106	550

Example The following line will print the value at location 1000.
>> PRINT TABLE(1000)

See also **CAM, CAMBOX, DEL, NEW, SCOPE, TSIZE, VR.**

3.2.263 TABLEVALUES

Type System command

Syntax **TABLEVALUES(address, number_of_points, format)**

Description Returns a list of TABLE points starting at the number specified. There is only one format supported at the moment, and that is comma delimited text.

Note: **TABLEVALUES** is provided mainly for Trajexia Tools to allow for fast access to banks of TABLE values.

Arguments

- **address**

Number of the first point to be returned

- **number_of_points**

Total number of points to be returned

- **format**

Format for the list

Example No example.

See also N/A

3.2.264 TAN

Type Mathematical function

Syntax **TAN(expression)**

Description The **TAN** function returns the tangent of the expression. The expression is assumed to be in radians.

Arguments

- **expression**
Any valid BASIC expression.

Example **>> print TAN(PI/4)**
1.0000

See also N/A

3.2.265 THEN

See **IF..THEN..ELSE..ENDIF**.

3.2.266 TICKS

Type Task parameter

Syntax **TICKS**

Description The **TICKS** parameter contains the current count of the task clock pulses. **TICKS** is a 32-bit counter that is decremented on each servo cycle. **TICKS** can be written and read. It can be used to measure cycles times, add time delays, etc.

Each task has its own **TICKS** parameter. Use the **PROC** modifier to access the parameter for a certain task. Without **PROC** the current task will be assumed.

Arguments N/A

Example	delay: TICKS = 3000 OP(9,ON) test: IF TICKS <= 0 THEN OP(9,OFF) ELSE GOTO test ENDIF	Arguments	N/A
		Example	When the time is 13:20:00 >> PRINT TIME\$ >> 13:20:00
See also	N/A		

3.2.267 TIME

Type	System parameter
Syntax	TIME
Description	Sets and returns the time from the real time clock. The time returned as an integer is the number of seconds since midnight 00:00:00.
Arguments	N/A
Example	Sets the real time clock in 24 hour format; hh:mm:ss 'Set the real time clock >>TIME = 13:20:00 >> PRINT TIME >> 48002.0000 Print executed after 2 seconds
See also	N/A

3.2.268 TIME\$

Type	System command
Syntax	TIME\$
Description	Prints the current time as defined by the real time clock as a string in 24-hour format.

Example	When the time is 13:20:00 >> PRINT TIME\$ >> 13:20:00
See also	N/A

3.2.269 TO

See FOR..TO..STEP..NEXT.

3.2.270 TRANS_DPOS

Type	Axis parameter (read-only)
Syntax	TRANS_DPOS
Description	Axis demand position at output of frame transformation. TRANS_DPOS is normally equal to DPOS on each axis. The frame transformation is therefore equivalent to 1:1 for each axis. For some machinery configurations it can be useful to install a frame transformation which is not 1:1, these are typically machines such as robotic arms or machines with parasitic motions on the axes. Frame transformations have to be specially written in the C language and downloaded into the controller. It is essential to contact OMRON if you want to install frame transformations.
Arguments	N/A
Example	No example.
See also	FRAME .

3.2.271 TRIGGER

Type	System command
Syntax	TRIGGER

Description	The TRIGGER command starts a previously set up SCOPE command. Note: Trajexia Tools uses TRIGGER automatically for its oscilloscope function.
Arguments	N/A
Example	No example.
See also	SCOPE .

3.2.272 TROFF

Type	Program command
Syntax	TROFF ["program_name"]
Description	The TROFF command suspends a trace at the current line and resumes normal program execution for the program specified with program_name . The program name can also be specified without quotes. If the program name is omitted, the selected program will be assumed.
Arguments	<ul style="list-style-type: none"> • program_name The name of the program for which to suspend tracing.
Example	>> TROFF "lines"
See also	SELECT, TRON .

3.2.273 TRON

Type	Program command
Syntax	TRON

Description	The TRON command creates a breakpoint in a program that will suspend program execution at the line following the TRON command. The program can then for example be executed one line at a time using the STEPLINE command.
Notes:	<ul style="list-style-type: none"> • Program execution can be resumed without using the STEPLINE command by executing the TROFF command. • The trace mode can be stopped by issuing a STOP or HALT command. • Trajexia Tools highlights lines containing TRON in the Edit and Debug Windows.
Arguments	N/A

Example	TRON MOVE(0,10) MOVE(10,0) TRON MOVE(0,-10) MOVE(-10,0)
See also	SELECT, TROFF .

3.2.274 TRUE

Type	Constant (read-only)
Syntax	TRUE
Description	The TRUE constant returns the numerical value -1.
Arguments	N/A
Example	test: t = IN(0) AND IN(2) IF t = TRUE THEN PRINT "Inputs are ON" ENDIF
See also	N/A

3.2.275 TSIZE

Type System parameter (read-only)

Syntax **TSIZE**

Description The **TSIZE** parameter returns the size of the TABLE array, which is one more than the currently highest defined TABLE element.
TSIZE is reset to 0 when the TABLE array is deleted using **DEL "TABLE"** or **NEW "TABLE"** on the command line.

Arguments N/A

Example The following example assumes that no location higher than 1000 has been written to the TABLE array.
>> TABLE(1000,3400)
>> PRINT TSIZE
1001.0000

See also **DEL, NEW, TABLE.**

Example

A lead crew arrangement has a 5mm pitch and a 1,000-pulse/rev encoder. The units must be set to allow moves to be specified in mm. The 1,000 pulses/rev will generate $1,000 \times 4 = 4,000$ edges/rev. One rev is equal to 5mm. Therefore, there are $4,000/5 = 800$ edges/mm. **UNITS** is thus set as following.
>> UNITS = 1000*4/5

See also

AXIS, ENCODER_RATIO.

3.2.277 UNLOCK

See **LOCK**.

3.2.278 UNTIL

See **REPEAT..UNTIL**.

3.2.279 VERIFY

Type Axis parameter

Syntax **VERIFY**

Description The verify axis parameter is used to select different modes of operation on a stepper encoder axis.

- **VERIFY=OFF**

Encoder count circuit is connected to the **STEP** and **DIRECTION** hardware signals so that these are counted as if they were encoder signals. This is particularly useful for registration as the registration circuit can therefore function on a stepper axis.

- **VERIFY=ON**

Encoder circuit is connected to external A,B, Z signal

Note: On the TJ1-FL02 when **VERIFY=OFF**, the encoder counting circuit is configured to accept **STEP** and **DIRECTION** signals hard wired to the encoder A and B inputs. If **VERIFY=ON**, the encoder circuit is configured for the usual quadrature input.

Make sure that the encoder inputs do not exceed 5 volts.

3.2.276 UNITS

Type Axis parameter

Syntax **UNITS**

Description The **UNITS** parameter contains the unit conversion factor. The unit conversion factor enables the user to define a more convenient user unit like m, mm or motor revolutions by specifying the amount of encoder edges to include in a user unit.
Axis parameters like speed, acceleration, deceleration and the Axis commands are specified in these user units.
Note: The **UNITS** parameter can be any non-zero value, but it is recommended to design systems with an integer number of encoder pulses per user unit. Changing **UNITS** will affect all axis parameters which are dependent on **UNITS** in order to keep the same dynamics for the system.

Arguments N/A

Arguments N/A

Example **VERIFY AXIS(3)=ON**

See also N/A

3.2.280 VERSION

Type System parameter (read-only)

Syntax **VERSION**

Description The **VERSION** parameter returns the current firmware version number of the current system installed in the TJ1-MC__.

Arguments N/A

Example **>> PRINT VERSION**
 1.6100

See also N/A

3.2.281 VFF_GAIN

Type Axis parameter

Syntax **VFF_GAIN**

Description The **VFF_GAIN** parameter contains the speed feed forward gain. The speed feed forward output contribution is calculated by multiplying the change in demand position with the **VFF_GAIN** parameter value. The default value is 0. Adding speed feed forward gain to a system decreases the Following Error during a move by increasing the output proportionally with the speed.
Note: In order to avoid any instability the servo gains should be changed only when the **SERVO** is off.

Arguments N/A

Example No example.

See also **D_GAIN, I_GAIN, OV_GAIN, P_GAIN.**

3.2.282 VP_SPEED

Type Axis parameter (read-only)

Syntax **VP_SPEED**

Description The **VP_SPEED** parameter contains the speed profile speed in user units/s. The speed profile speed is an internal speed which is accelerated and decelerated as the movement is profiled.

Arguments N/A

Example '**Wait until at command speed**
MOVE(100)
WAIT UNTIL SPEED = VP_SPEED

See also **AXIS, MSPEED, UNITS.**

3.2.283 VR

Type System command

Syntax **VR(address)**

Description The VR command reads or writes the value of a global (VR) variable. These VR variables hold real numbers and can be easily used as an element or as an array of elements. The TJ1-MC__ has in total 1024 VR variables. The VR variables can be used for several purposes in BASIC programming. The VR variables are globally shared between tasks and can be used for communications between tasks. VR variable memory area is battery backed, so all VR variables retain their values between power ups

Notes:

- The TABLE and VR data can be accessed from all different running tasks. To avoid problems of two program tasks writing unexpectedly to one global variable, write the programs in such a way that only one program writes to the global variable at a time.

Arguments • **address**

The address of the VR variable. Range: [0,1023].

Example In the following example, the value 1.2555 is placed into VR variable 15. The local variable **val** is used to name the global variable locally:

```
val = 15
VR(val) = 1.2555
```

Example A transfer gantry has 10 put down positions in a row. Each position may at any time be full or empty. VR(101) to VR(110) are used to hold an array of ten 1 's and 0 's to signal that the positions are full (1) or empty (0). The gantry puts the load down in the first free position. Part of the program to achieve this would be as follows:

```
movep:
MOVEABS(115) ' Move to first put down position
FOR VR(0) = 101 TO 110
  IF (VR(VR(0)) = 0) THEN GOSUB load
  MOVE(200) ' 200 is spacing between positions
NEXT VR(0)
PRINT "All positions are full"
WAIT UNTIL IN(3) = ON
GOTO movep
```

```
load: ' Put load in position and mark array
OP(15,OFF)
VR(VR(0)) = 1
RETURN
```

The variables are backed up by a battery so the program here could be designed to store the state of the machine when the power is off. It would of course be necessary to provide a means of resetting completely following manual intervention.

Example **loop: ' Assign VR(65) to VR(0) multiplied by axis 1 measured position**

VR(65) = VR(0)*MPOS AXIS(1)

PRINT VR(65)

GOTO loop

See also **CLEAR_BIT, READ_BIT, SET_BIT, TABLE.**

3.2.284 VRSTRING

Type System command

Syntax **VRSTRING(vr_start)**

Description Combines the contents of an array of VR() variables so that they can be printed as a text string. All printable characters will be output and the string will terminate at the first null character found. (i.e. VR(n) contains 0)

Arguments • **vr_start**
number of first VR() in the character array.

Example **PRINT #5,VRSTRING(100)**

See also N/A

3.2.285 WA

Type System command

Syntax **WA(time)**

Description The **WA** command pauses program execution for the number of milliseconds specified for time. The command can only be used in a program.

Arguments • **time**
The number of milliseconds to hold program execution.

Example The following lines would turn ON output 7 two seconds after turning off output 1.

```
OP(1,OFF)
WA(2000)
OP(7,ON)
```

See also N/A

3.2.286 WAIT IDLE

Type System command

Syntax **WAIT IDLE**

Description The **WAIT IDLE** command suspends program execution until the base axis has finished executing its current move and any buffered move. The command can only be used in a program. **WAIT IDLE** works on the default basis axis (set with **BASE**) unless **AXIS** is used to specify a temporary base axis.
Note: The execution of **WAIT IDLE** does not necessarily mean that the axis will be stationary in a servo motor system.

Arguments N/A

Example

```
MOVE(1000)
WAIT IDLE
PRINT "Move Done"
The print statement is printed at the end of the movement.
```

Example

```
MOVE(1000)
WAIT UNTIL MTYPE=0
PRINT "Movement finished"
The print statement is printed, most of the times BEFORE the movement starts, and sometimes, when the movement is finished.
```

Explanation Motion programs and motion sequence work in parallel and unsynchronized. One complete cycle can occur before the movement is loaded into the buffer. The program executes **MOVE(1000)** but the movement is not loaded to the buffer until the start of the next "motion sequence" so when you check **MTYPE=0**, it is 0 because the movement HAS NOT STARTED YET, not because it has finished.

See also [AXIS](#), [WAIT LOADED](#).

Note

WAIT IDLE is a command specifically designed to wait until the previous movement has been finished so, it handles the delay from when the previous command is executed in the program until the command is correctly loaded in the motion buffer.

3.2.287 WAIT LOADED

Description The **WAIT LOADED** command suspends program execution until the base axis has no moves buffered ahead other than the currently executing move. The command can only be used in a program. This is useful for activating events at the beginning of a move, or at the end when multiple moves are buffered together. **WAIT LOADED** works on the default basis axis (set with **BASE**) unless **AXIS** is used to specify a temporary base axis.

Arguments N/A

Example

```
' Switch output 8 ON at start of MOVE(500) and OFF at end
MOVE(800)
MOVE(500)
WAIT LOADED
OP(8,ON)
MOVE(400)
WAIT LOADED
OP(8,OFF)
```

See also [AXIS](#), [WAIT IDLE](#)

3.2.288 WAIT UNTIL

Type System command

Syntax **WAIT UNTIL condition**

Description The **WAIT UNTIL** command repeatedly evaluates the condition until it is **TRUE**. After this program execution will continue. The command can only be used in a program.

Arguments

- **condition**
Any valid BASIC logical expression.

Example In this example, the program waits until the measured position on axis 0 exceeds 150, and then starts a movement on axis 1.

```
WAIT UNTIL MPOS AXIS(0)>150
MOVE(100) AXIS(1)
```

Type	System command
Syntax	WAIT LOADED

Example	The expressions evaluated can be as complex as you like provided they follow BASIC syntax, for example: WAIT UNTIL DPOS AXIS(2) <= 0 OR IN(1) = ON The above line would wait until the demand position of axis 2 is less than or equal to 0 or input 1 is on.
See also	N/A

3.2.289 WDOG

Type	System parameter
Syntax	WDOG
Description	<p>The WDOG parameter contains the software switch which enables the Servo Driver using the RUN (Servo on) input signal. The enabled Servo Driver will control the servo motor depending on the speed and torque reference values. WDOG can be turned on and off under program control, on Command Line Terminal and the Trajexia Tools control button.</p> <p>The Servo Driver will automatically be disabled when a MOTION_ERROR occurs. A motion error occurs when the AXISSTATUS state for one of the axes matches the ERRORMASK setting. In this case the software switch (WDOG) will be turned off, the MOTION_ERROR parameter will have value different than 0 and the ERROR_AXIS parameter will contain the number of the first axis to have the error.</p> <p>Note: The WDOG parameter can be executed automatically by Trajexia Tools when the Drives Enabled check box is clicked on the control panel.</p>
Arguments	N/A
Example	No example.
See also	AXISSTATUS, ERROR_AXIS, ERRORMASK, MOTION_ERROR, SERVO.

3.2.290 WHILE..WEND

Type	Program control command
------	-------------------------

Syntax	WHILE condition commands WEND
Description	<p>The WHILE ... WEND structure allows the program segment between the WHILE and the WEND statement to be repeated a number of times until the condition becomes FALSE. In that case program execution will continue after WEND.</p> <p>Note: WHILE ... WEND loops can be nested without limit.</p>
Arguments	<ul style="list-style-type: none"> • condition Any valid logical BASIC expression.
Example	WHILE IN(12) = OFF MOVE(200) WAIT IDLE OP(10,OFF) MOVE(-200) WAIT IDLE OP(10,ON) WEND
See also	FOR..TO..STEP..NEXT, REPEAT..UNTIL

3.2.291 XOR

Type	Mathematical operation
Syntax	expression1 XOR expression2
Description	<p>The XOR (eXclusive OR) operator performs the logical XOR function between corresponding bits of the integer parts of two valid BASIC expressions.</p> <p>The logical XOR function between two bits is defined as in the table below.</p>

Bit 1	Bit 2	Result
0	0	0
0	1	1
1	0	1

Bit 1	Bit 2	Result
1	1	0

- Arguments
- **expression1**
Any valid BASIC expression.
 - **expression2**
Any valid BASIC expression.

Example **VR(0)=10 XOR 18**
The **XOR** is a bit operator and so the binary action taking place is as follows:
01010 XOR 10010 = 11000. The result is therefore 24.

See also N/A

4 Communication protocols

4.1 Available interfaces

The Trajexia units have these interfaces to communicate:

Unit	Interface	Protocol	Comment
TJ1-MC__	Ethernet	Trajexia Tools protocol	To program, monitor and debug the project with Trajexia Tools.
		FINS server	To communicate with any FINS master, for example PLC, HMI, or personal computer.
		FINS client	To communicate to any FINS server, for example PLC or another Trajexia unit.
		ModbusTCP	To respond to any ModbusTCP request, for example a PLC unit.
	Serial	Host Link Master	To communicate with any Host Link slave, for example an OMRON PLC.
		Host Link Slave	To communicate with any Host Link master, HMI typically.
		User defined	This protocol is created and handled using BASIC commands.
TJ1-PRT	PROFIBUS	PROFIBUS Slave DP-V0	To exchange word variables with any PROFIBUS master.
TJ1-DRT	DeviceNet	DeviceNet	To exchange word variables with any DeviceNet master.
TJ1-CORT	CANopen	CANopen	To exchange word variables within a CANopen network.
TJ1-ML__	MECHATRO-LINK-II	MECHATROLINK-II	To communicate with supported MECHATROLINK-II slaves. This protocol is transparent to the user.

4.2 Ethernet

The TJ1-MC__ has a standard 10/100 Mbps Ethernet port. You can use a crossover or a patch Ethernet cable to connect the TJ1-MC__ to a PC. To configure the interface, set these parameters:

Item	Default value	Comment
IP address	192.168.0.250	Set one IP address that is unique in the network.
Subnet mask	255.255.255.0	Set the same subnet that the LAN uses.
Gateway	0.0.0.0	The gateway is necessary to have remote access from another LAN.

Make sure that the IP address of the PC is in the same range as the TJ1-MC__: if the IP address of the TJ1-MC__ is *aaa.bbb.ccc.ddd*, the IP address of the PC must be *aaa.bbb.ccc.xxx*, where *xxx* is 000 to 255 other than *ddd*. You can change the IP address of the TJ1-MC__ to match the IP address of your PC if you connect to the PC through a network hub or switch. For example, if the IP address of the PC is 192.200.185.001, you can set the IP address of the TJ1-MC__ to 192.200.185.002.



Note

The above is true if the subnet mask setting is the factory setting, that is, the subnet mask is not changed.



Note

The TJ1-MC__ does not have DHCP functionality, therefore it cannot assign an IP address to a PC.

The subnet mask of the TJ1-MC__ is generic. It does not need to match with the subnet mask of the PC.

Use the **Ethernet** command to read or write the Ethernet settings. It is necessary to power off and on again the units for the changes to take effect. You can check the IP address of the TJ1-MC__ with the Trajexia Tools command-line and the **Ethernet** command: Type the command **Ethernet(0, -1, 0)** at the command-line, and the IP address of the TJ1-MC__ shows on the command-line.


**Note**

You need to set the power of the Trajexia system off and back on before the change of the IP address takes effect.

4.2.1 Communicate with Trajexia directly from your computer


1. Do not change the Ethernet settings in Trajexia.
2. Set the Trajexia Tools settings as shown.

fig. 1



3. Set your computer settings as shown.

fig. 2



4.2.2 Communicate with Trajexia remotely

This example shows how to connect to a local Trajexia system from a computer on a remote location. Suppose the Ethernet settings of the Trajexia system are:

- 10.83.50.70 is the assigned IP address of Trajexia.
- 255.255.240.0 is the local Subnet Mask.
- 10.83.48.1 is the local gateway.
- The server assigns an IP address to the computers automatically.

1. Set the IP address, the Subnet Mask, and the gateway from the Terminal window command line in Trajexia with:

Ethernet(1,-1,0,10,83,50,70)

Ethernet(1,-1,2,255,255,240,0)

Ethernet(1,-1,8,10,83,48,1)

2. Check that the IP settings of the local Trajexia system and the remote computer are as shown.

After power on, the TJ1-MC__ display shows alternatively the IP address and the Subnet mask. After every re-connection of the Ethernet cable, the display shows only the IP address.

fig. 3





fig. 4



4.2.3 Trajexia Tools protocol

The Trajexia Tools protocol is used by Trajexia Tools to program, monitor and debug the TJ1-MC__.

Trajexia Tools uses a Telnet protocol. By default, this connection uses port 23. If this port is not accessible, you can change the port number with the command **Ethernet(1,-1,4,new_port_n)**.

Unlike the standard Ethernet commands, this command takes effect immediately after execution. The port changes to default at power on. Therefore, this command needs to be included in any program that is executed at power on.

The Trajexia Tools Protocol is TCP only.

4.2.4 FINS server protocol

FINS (Factory Interface Network Service) is a Proprietary OMRON communication protocol. A subset of this protocol is implemented in Trajexia. Refer to the Communication Commands Reference manual (W342-E1).

The FINS protocol enables seamless communication with other OMRON devices such as PLCs, HMs, and CX-Drive.

The FINS server protocol requires no configuration settings.



WARNING

As the TJ1-MC__ can communicate with different sources at the same time, the commands from two sources can interfere with each other.

By default, this connection uses port 9600. If this port is not accessible, you can change the port with the command **Ethernet(1,-1,12,new_port_n)**.

Unlike the standard Ethernet commands, this command takes effect immediately after execution. The port changes to default at power on. Therefore, this command needs to be included in any program that is executed at power on.

The FINS commands allow communications between nodes in different networks. A FINS master device can read and write the Trajexia VR variables and TABLE memory variables with FINS commands. These commands use the Ethernet connection of the TJ1-MC__. The FINS server protocol is UDP only.



Note

The maximum length of a FINS command over an Ethernet connection is 2012 bytes.

Trajexia uses these FINS commands:

- 0101 (Read memory)
- 0102 (Write memory)

Read command

The FINS **read** command has this format:

01	01	00
command_code	var_type	start_address	fixed	element_count	

The parameters can have the following values:

Parameter	Values (hex)
command_code	01 01
var_type	<ul style="list-style-type: none"> • 82 (TABLE memory in 16-bit integer format) • C2 (TABLE memory in 32-bit IEEE floating-point format) • B0 (VR memory in 16-bit integer format)
start_address	0 <= start_address <= number of variables - 1 <= FFFF

Parameter	Values (hex)
element_count	1 <= element_count <= number of variables - start_address

The TJ1-MC__ responds with these codes:

Condition	Response code (hex)	Description
All elements valid	0000	OK
Var_type invalid	1101	No area type
Start_address invalid	1103	Address range designation error
Number of elements invalid	1104	Address out of range

If var_type is 82 or B0, and the response code is 0000, the TJ1-MC__ responds with:

01	01	00	00			
command_code	response_code	word_1	word_2	...		

If var_type is C2, and the response code is 0000, the TJ1-MC__ responds with:

01	01	00	00		
command_code	response_code	dword_1	...		



Note

The returned words and dwords are in big-endian format.

Write command

The FINS write command has these formats:

- If var_type is 82 or B0:

01	02	00
command_c ode	var_ type	start_ address	fixed	total_words	word 1

- If var_type is C2:

01	02	C2	00
command_c ode	var_t ype	start_ address	fixed	total_words	dword 1

- If var_type is 30:

01	02	30	00	
command_ code	var_ type	start_ address	bit_ num	total_bits	bit

The parameters can have the following values:

Parameter	Values
command_code	01 02
var_type	<ul style="list-style-type: none"> 82 (TABLE memory in 16-bit integer format) C2 (TABLE memory in 32-bit IEEE floating-point format) B0 (VR memory in 16-bit integer format) 30 (VR memory in bit format)
start_address	0 <= start_address <= number of variables - 1 <= FFFF
total_words	1 <= total_words <= memory size - start_address + 1
total_bits	1
bit	00 or 01

The TJ1-MC__ responds with these codes:

Condition	Response code (hex)	Description
All elements valid	0000	OK
Var_type invalid	1101	No area type
Start_address invalid	1103	Address range designation error
Bit_number invalid	1103	Address range designation error
Number of elements invalid (totals)	1104	Address out of range

4.2.5 FINS client protocol

Trajexia can initiate the FINS communication using the **FINS_COMMS BASIC** command. Refer to the command description for details.

Both the Read Memory (0101) and the Write Memory (0102) commands are supported.

This functionality is useful to communicate with an OMRON PLC, another Trajexia system or a PC running FINS server application software.

With the Read Memory command, memory can be read from other devices with FINS server capability. The Write Memory command can be used to write data to devices with FINS server capability.

The command returns one of the following values, depending on the outcome of the execution:

- 1 The command executed successfully.
- 0 The command failed.
- 1 Request was not sent because the client or the FINS protocol is busy.
- 2 One or more of the request parameters is invalid.
- 3 Invalid source memory area.

4 Request was sent, but no response from the remote server was received within the timeout period.

5 An error response code was received from the remote server.

4.2.6 ModbusTCP protocol

Modbus is a serial communication protocol published by Modicon. Versions of this protocol exist for serial port and for Ethernet connection over TCP/IP. Trajexia supports ModbusTCP as a slave, which means Trajexia can respond to communication requests, but it cannot initiate the communication itself.

A subset of the Modbus communication functions is implemented in Trajexia. The functions supported are shown in the table below.

Function number		Function name
Decimal	Hexadecimal	
1	1	Read Coils
2	2	Read Discrete Inputs
3	3	Read Holding Registers
5	5	Write Single Coil
6	6	Write Single Register
16	10	Write Multiple Registers
23	17	Read/Write Multiple Registers

When the Modbus Discrete Input functions are used, Trajexia accesses the digital inputs. When the Modbus Coil functions are used, Trajexia accesses the digital outputs. When the Modbus Holding Registers functions are used, Trajexia accesses the VR or TABLE memory area. Which memory area accessed is defined by a parameter of the **ETHERNET** command. Refer to section 3.2.112 for more information on this command.

To access the VR memory area, execute the command **ETHERNET(1,-1,9,0)**. This is the default setting at power-up. To access the TABLE memory area, execute the command **ETHERNET(1,-1,9,1)**.

Trajexia can exchange data in the holding registers via the ModbusTCP protocol. Trajexia supports 16-bit signed integer values and 32-bit IEEE floating point values. The data format used is defined by a parameter of the **ETHERNET** command. To exchange holding registers values as 16-bit signed integers, execute the command **ETHERNET(1,-1,7,0)**. This is the default setting at power-up. To exchange holding registers values as 32-bit IEEE floating point, execute the command **ETHERNET(1,-1,7,1)**.

More information on the Modbus protocol and the communication messages format can be found in the MODBUS APPLICATION PROTOCOL SPECIFICATION document, which can be downloaded at <http://www.Modbus-IDA.org>.

4.3 Serial protocol

The TJ1-MC__ TJ1-MC__ has a DB-9 connector that contains two serial ports:

- Port 1: RS232
- Port 2: RS422 or RS485, depending on the switch settings

See the Trajexia Hardware Reference manual for details.

Both ports can independently support these protocols:

- Host Link master
- Host Link slave
- User defined protocol

You can use these BASIC commands:

BASIC command	Description
HLM_COMMAND	HLM_COMMAND executes a specific Host Link command to the slave.
HLM_READ	HLM_READ reads data from the Host Link slave to either VR or TABLE memory.
HLM_STATUS	HLM_STATUS gives the status of the last command of the Host Link master.
HLM_TIMEOUT	HLM_TIMEOUT defines the Host Link master timeout time.
HLM_WRITE	HLM_WRITE writes data to the Host Link slave from either VR or TABLE memory.
SETCOM	SETCOM configures the serial communication port and enables the Host Link protocols.



Note

The serial port (port 1) CANNOT be used for programming the unit.

4.3.1 Host Link master

If the TJ1-MC__ is the Host Link master, you can send BASIC commands to a Host Link slave, for example a PC. When you send a BASIC command to a Host Link slave, the execution of the next BASIC command waits until the Host Link slave sends a response.

Commands

These Host Link commands are supported for the Host Link Master protocol:

Type	Header code	Name	Function
I/O memory reading	RR	CIO AREA READ	Reads the specified number of words beginning with the designated CIO/IR word.
	RL	LR AREA READ	Reads the specified number of words beginning with the designated LR word.
	RH	HR AREA READ	Reads the specified number of words beginning with the designated HR word.
	RD	DM AREA READ	Reads the specified number of words beginning with the designated DM word.
	RJ	AR AREA READ	Reads the specified number of words beginning with the designated AR word.
	RE	EM AREA READ	Reads the specified number of words beginning with the designated EM word.

Type	Header code	Name	Function
I/O memory writing	WR	CIO AREA WRITE	Writes the specified data in word units beginning with the designated CIO/IR word.
	WL	LR AREA WRITE	Writes the specified data in word units beginning with the designated LR word.
	WH	HR AREA WRITE	Writes the specified data in word units beginning with the designated HR word.
	WD	DM AREA WRITE	Writes the specified data in word units beginning with the designated DM word.
	WJ	AR AREA WRITE	Writes the specified data in word units beginning with the designated AR word.
	WE	EM AREA WRITE	Writes the specified data in word units beginning with the designated EM word.
CPU unit status	SC	STATUS WRITE	Changes the operating mode of the CPU unit.
Testing	TS	TEST	Returns, unaltered, a single block that was sent from the master.
PC model code reading	MM	PC MODEL READ	Reads the model code of the CPU unit
Host Link communications processing	XZ	ABORT (command only)	Aborts the operation that is performed by a Host Link command, and returns to the initial status.
	**	INITIALIZE (command only)	Initializes the transfer control procedures for all Host Link units.
	IC	Undefined command (response only)	This is the response when the command header code is invalid.

**Note**

The Host Link protocol supports only C commands. It does not support FINS.

The Host Link Master protocol supports the commands only in single frame. The following table shows how you can use the Host Link protocol with the BASIC commands, and for which CPU unit operating mode (RUN, MON or PROG) the command is valid.

Header code	Name	BASIC command required	RUN	MON	PRG
RR	CIO AREA READ	HLM_READ	Valid	Valid	Valid
RL	LR AREA READ	HLM_READ	Valid	Valid	Valid
RH	HR AREA READ	HLM_READ	Valid	Valid	Valid
RD	DM AREA READ	HLM_READ	Valid	Valid	Valid
RJ	AR AREA READ	HLM_READ	Valid	Valid	Valid
RE	EM AREA READ	HLM_READ	Valid	Valid	Valid
WR	CIO AREA WRITE	HLM_WRITE	Not valid	Valid	Valid
WL	LR AREA WRITE	HLM_WRITE	Not valid	Valid	Valid
WH	HR AREA WRITE	HLM_WRITE	Not valid	Valid	Valid
WD	DM AREA WRITE	HLM_WRITE	Not valid	Valid	Valid
WJ	AR AREA WRITE	HLM_WRITE	Not valid	Valid	Valid
WE	EM AREA WRITE	HLM_WRITE	Not valid	Valid	Valid
SC	STATUS CHANGE	HLM_COMMAND	Valid	Valid	Valid
TS	TEST	HLM_COMMAND	Valid	Valid	Valid
MM	PC MODEL READ	HLM_COMMAND	Valid	Valid	Valid
XZ	ABORT (command only)	HLM_COMMAND	Valid	Valid	Valid
**	INITIALIZE (command only)	HLM_COMMAND	Valid	Valid	Valid

Header code	Name	BASIC command required	RUN	MON	PRG
IC	Undefined command (response only)	-	Valid	Valid	Valid

**Caution**

You must execute the Host Link master commands from one program task only to avoid any multi-task timing problems.

**Caution**

The Host Link master commands provide the tools to exchange data with the Host Link slave. The user program must contain proper error handling routines to deal with communication failure and perform retries if necessary.

End codes

These are the end codes defined in the **HLM_STATUS** parameter:

End code	Description	Probable cause	Solution
\$00	Normal completion	No problem exists.	N/A
\$01	Not executable in RUN mode	The command that was sent cannot be executed when the PC is in RUN mode.	Check the relation between the command and the PC mode.
\$13	FCS error	The FCS is wrong.	Influence from noise, transfer the command again.

End code	Description	Probable cause	Solution
\$14	Format error	<ul style="list-style-type: none"> The command format is wrong. A command that cannot be divided has been divided. The frame length is smaller than the minimum length for the applicable command. 	Check the format and transfer the command again.
\$15	Entry number data error	The data is outside the specified range or too long.	Correct the command arguments and transfer the command again.
\$18	Frame length error	The maximum frame length of 131 bytes is exceeded.	Check the command and transfer the command again.
\$19	Not executable	You did not obtain access rights.	Obtain access rights.
\$21	Not executable due to CPU error.	The command cannot be executed because a CPU error has occurred.	Cycle the power supply of the CPU.
\$100	Host Link slave ACK timeout	-	-
\$200	IC command address error	-	-

Set up

You need the **SETCOM** command to set up the serial port of the TJ1-MC for the Host Link Master protocol. Set the command as follows:

SETCOM(baudrate, data_bits, stop_bits, parity, port, 6)

After you have set this command, you can use the **HLM_READ**, **HLM_WRITE** and **HLM_COMMAND** commands to read and write data using Host Link.

Timeout

The timeout mechanism is implemented to prevent that the BASIC task pauses for a long time due to bad or no communication. The **HLM_TIMEOUT** parameter specifies the timeout period. This period is the maximum time the program task waits after it has sent the command to receive a response.

If the timeout period elapses, the **HLM_STATUS** contains the status of the command, and the BASIC task continues.

The **HLM_TIMEOUT** parameter specifies the timeout period for all commands and for all ports.

Status

The **HLM_STATUS** parameter contains the status of the last Host Link master command sent to the specified port. The parameter indicates the status for the **HLM_READ**, **HLM_WRITE** and **HLM_COMMAND** commands. The status bits are:

Bit	Name	Description
0-7	End code	<p>The end code is:</p> <ul style="list-style-type: none"> the end code defined by the Host Link slave, when a problem occurred in the data string of the sent command, or an end code defined by the Host Link master, when a problem occurred in the data string of the received response.
8	Timeout error	A timeout error occurs if no response is received within the timeout period. This indicates that the communication is lost.
9	Command not recognised	This status indicates that the slave did not recognise the command and has returned an IC response.

The **HLM_STATUS** has value 0 when no problems occurred. In case of a non-zero value you need to program an appropriate action such as a retry or emergency stop in the user BASIC program. Each port has an **HLM_STATUS** parameter. You need the **PORT** modifier to specify the port.

Examples

In these examples we assume this set-up:

- A Trajexia system with a TJ1-MC__.
- A slave PC, with node address 13.
- A connection from the serial port of the TJ1-MC__ to the PC. The serial port uses RS422 communication.

		Result	<ul style="list-style-type: none"> • LR address = 0: value = 701 (hex) • LR address = 1: value = 702 (hex)
		Example	Send TS (test) command to PC using HLM_COMMAND .
		BASIC code	HLM_COMMAND(HLM_TEST,2,13)
		Host Link communication	<ul style="list-style-type: none"> • From Host Link master to Host Link slave: @13TSMCW151 TEST STRING2A* • From Host Link slave to Host Link master: @13TSMCW151 TEST STRING2A*
Example	Reading data from the PC using HLM_READ .	Result	HLM_STATUS PORT(2) = 0 , which implies correct communication.
BASIC code	<pre>' Set up Host Link master for port 2 SETCOM(9600,7,2,2,2,6) 'Source address: CIO/IR 002 'Amount of data: 2 words 'Destination address: VR(0) HLM_READ(2,13,PLC_IR,2,2,MC_VR,0)</pre>	Example	Set PC in MON mode using HLM_COMMAND .
		BASIC code	HLM_COMMAND(HLM_STWR,2,13,2)
Host Link communication	<ul style="list-style-type: none"> • From Host Link master to Host Link slave: @13RR0002000242* • From Host Link slave to Host Link master: @13RR000101010241* 	Host Link communication	<ul style="list-style-type: none"> • From Host Link master to Host Link slave: @13SC0250* • From Host Link slave to Host Link master: @13SC0052*
Result	<ul style="list-style-type: none"> • VR address = 0: value = 257.0000 • VR address = 1: value = 258.0000 	Result	The PC runs in MON mode. Note that this is necessary for writing data to the PC using HLM_WRITE .
Example	Writing data to the PC using HLM_WRITE .	Example	Reading PC model code using HLM_COMMAND (timeout).
BASIC code	<pre>'Source address: TABLE(18) 'Amount of data: 2 words 'Destination address: LR 014 TABLE(18,\$0701,\$0702) HLM_WRITE(2,13,PLC_LR,14,2,MC_TABLE,18)</pre>	BASIC code	HLM_TIMEOUT=500 'Destination address: VR(100) HLM_COMMAND(HLM_MREAD,2,13,MC_VR,100)
Host Link communication	<ul style="list-style-type: none"> • From Host Link master to Host Link slave: @13WL0014070107025F* • From Host Link slave to Host Link master: @13WL0059* 	Host Link communication	<ul style="list-style-type: none"> • From Host Link master to Host Link slave: @13MM42* • From Host Link slave to Host Link master: no response
		Result	Because the master has not received a response from the PC, HLM_STATUS PORT(2) has value 256 (bit 8 is set) after 500 servo cycles.

4.3.2 Host Link slave

If the TJ1-MC__ is the Host Link slave, a Host Link master (for example, a programmable terminal) can read data from the TJ1-MC__ and write data to it. The mapping between the slave and the master is:

TJ1-MC__ memory	Host Link mapping	Address range
VR	CIO	0 to 1023
TABLE	DM	0 to 63999

You can use these BASIC commands:

BASIC command	Description
SETCOM	SETCOM configures the serial communication port, and it enables the Host Link protocols.
HLS_NODE	HLS_NODE defines the slave unit number for the Host Link Slave protocol.
HLS_MODEL	HLS_MODEL defines the TJ1-MC__ model code for the Host Link Slave protocol.

Commands

The commands supported for the Host Link Slave protocol are given in the table below. The protocol supports single frame transfer and multiple frame transfer.

Type	Header code	Name	Function
I/O memory reading	RR	CIO AREA READ	Reads the specified number of words from VR memory beginning with the designated word.
	RD	DM AREA READ	Reads the specified number of words from TABLE memory beginning with the designated word.

Type	Header code	Name	Function
I/O memory writing	WR	CIO AREA WRITE	Writes the specified data in word units to VR memory beginning with the designated word.
	WD	DM AREA WRITE	Writes the specified data in word units to TABLE memory beginning with the designated word.
Testing	TS	TEST	Returns, unaltered, a single block that was sent from the master.
PC model code reading	MM	PC MODEL READ	Reads the model code of the TJ1-MC__ as specified by the HLS_MODEL parameter.
I/O memory area registration and reading	QQMR	REGISTER I/O MEMORY	Registers the I/O TABLE with the contents of the actual I/O configuration
	QQIR	READ I/O MEMORY	Reads the registered I/O memory words/bits all at once.
Host Link communications processing	XZ	ABORT (command only)	Aborts the operation that is performed by a Host Link command, and returns to the initial status.
	**	INITIALIZE (command only)	Initializes the transfer control procedures for all Host Link units.
	IC	Undefined command (response only)	This is the response when the command header code is invalid.

End codes

These are the response end codes that are returned in the response frame:

End code	Description	Probable cause	Solution
0	Normal completion	No problem exists.	N/A

End code	Description	Probable cause	Solution
13	FCS error	The FCS is wrong.	Check the FCS calculation method. If there was influence from noise, transfer the command again.
14	Format error	<ul style="list-style-type: none"> • The command format is wrong. • A command that cannot be divided has been divided. • The frame length is smaller than the minimum length for the applicable command. 	Check the format and transfer the command again.
15	Entry number data error	The data is outside the specified range or too long.	Correct the command arguments and transfer the command again.
18	Frame length error	The maximum frame length of 131 bytes is exceeded.	Check the data and transfer the command again.
19	Not executable	An I/O memory batch was executed when items to read were not registered.	Register items to read before attempting batch read.
A3	Aborted due to FCS error in transmission data	An FCS error occurred in the second or later frame.	Correct the command data and transfer the command again.
A4	Aborted due to format error in transmission data	The command format did not match the number of bytes in the second or later frame.	Correct the command data and transfer the command again.
A5	Aborted due to entry number data error in transmission data	There was an entry number data error in the second or later frame or a data length error.	Correct the command data and transfer the command again.

End code	Description	Probable cause	Solution
A8	Aborted due to frame length error in transmission data	The length of the second or later frames exceeded the maximum of 128 bytes.	Correct the command data and transfer the command again.

Set up

You need the **SETCOM** command to set up the serial port of the TJ1-MC__ for the Host Link Slave protocol. Set the command as follows:

SETCOM(baudrate, data_bits, stop_bits, parity, port, 5)

After you have set this command, the TJ1-MC__ responds to Host Link commands from the master with the specified node number. You can set this node number with the **HLS_NODE** parameter.

Example

In this example we assume this set-up:

- A Trajexia system with a TJ1-MC__.
- An NS8 programmable terminal.
- A connection from the serial port of the TJ1-MC__ to the programmable terminal. The serial port uses RS232C communication.

Example Configuration of the Host Link slave.

BASIC code

```
' Define Host Link slave node
HLS_NODE = 15
' Define Host Link slave model code
HLS_MODEL = $FA
' Set up Host Link slave for port 1
SETCOM(9600,7,2,2,1,5)
```

Result The TJ1-MC__ can communicate with the programmable terminal.

4.3.3 User-defined protocol

You can implement a user-defined communication protocol with these commands:

BASIC command	Description
SETCOM	SETCOM configures the serial communication port, and it enables the Host Link protocols.
GET	GET assigns the ASCII code of a received character to a variable.
INPUT	INPUT assigns numerical input string values to the specified variables.
KEY	KEY returns TRUE or FALSE , when a character has been received or has not been received.
LINPUT	LINPUT assigns the ASCII code of received characters to an array of variables.
PRINT	PRINT outputs a series of characters to a serial output device.

Example

Assume a set-up with:

- A Trajexia system with a TJ1-MC__.
- An OMRON Vision system F500.
- A connection from the serial port of the TJ1-MC__ to the F500. The serial port uses RS232 (port 1) communication.

This program sends a Vision command through the serial port, reads the response from the Vision system, writes it to VR variables and prints the results in the Terminal window of Trajexia Tools.

```
' In the STARTUP program
' Setting RS232 port for the vision system
SETCOM(38400,8,1,0,1,0)
' In the application program
loop:
    ' Trigger, rising edge in virtual system
    WAIT UNTIL IN(30)=0
```

```
WAIT UNTIL IN(30)=1
' Clear screen
PRINT CHR(27);"[2J"

' Clear buffer
GOSUB clear_buffer

' Send command to the serial port according to VR(10)
IF vision_command=v_measure THEN
    PRINT #1, "M"
    PRINT ">> M"
ELSEIF vision_command=v_date THEN
    PRINT #1, "DATE"
    PRINT ">> DATE"
ELSEIF vision_command=v_scene THEN
    PRINT #1, "SCENE ";scene_n
    PRINT ">> SCENE"
ENDIF

' Check response
GOSUB read_buffer

GOTO loop
read buffer:
count=0
resp_status=0
k=-1
TICKS=5000
REPEAT
    IF KEY#1 THEN
        count=count+1
        GET#1, k
        'PRINT k;count
        TABLE(count,k)
        'PRINT count
    ENDIF
UNTIL TICKS<0 'OR k=13
```

```

PRINT "Received ";count[0];" characters"
FOR i=1 TO count
    IF TABLE(i)<>13 THEN
        PRINT CHR(TABLE(i))
    ELSE
        PRINT "'cr'"
    ENDIF
NEXT i
IF TICKS<0 THEN
    PRINT "Timeout in the communication with the F500"
    resp_status=3
ELSEIF TABLE(count-2)=79 AND TABLE(count-1)=75 THEN
    PRINT "Response OK"
    resp_status=1
ELSE
    PRINT "Response Uncorrect"
    resp_status=2
ENDIF
PRINT "Response Status is :";resp_status[0]
RETURN
clear_buffer:
PRINT "Clearing..."
WHILE KEY#1
    GET#1,k
    PRINT k
WEND
PRINT "Cleared!!"
RETURN

```

4.4 PROFIBUS

4.4.1 Introduction

PROFIBUS is an international open fieldbus standard. The Trajexia TJ1-PRT enables the Trajexia system to communicate with a PROFIBUS network. It exchanges data between the PROFIBUS master and the TJ1-MC__. For this, it uses the Trajexia VR variables.

4.4.2 Communication set-up

The TJ1-PRT has two node number selectors. You can use the node number selectors to assign a PROFIBUS network address to the TJ1-PRT. You must assign an address to the TJ1-PRT before you set the power of the Trajexia system on.

To initialise the TJ1-PRT, use the BASIC **PROFIBUS** command:

PROFIBUS(unit_number, 2, 1, output_start, output_count, input_start, input_count)

where:

- **unit_number** is the number of the TJ1-PRT unit.
- **output_start** is the start address of the output data range of VR variables.
- **output_count** is the number of VR variables in the output data range, maximum 122 variables.
- **input_start** is the start address of the input data range of VR variables.
- **input_count** is the number of VR variables in the input data range, maximum 122 variables.

After you have executed the command **PROFIBUS(unit_number, 2, ...)**, data arrays are automatically exchanged. The data exchanged between the TJ1-PRT and the PROFIBUS master is in 16-bit integer format. Each word exchanged ranges from -32768 to 32767.

A VR variable can hold a 24-bit number, and it can also hold fragments. The exchange with the PROFIBUS master does not support values outside the range -32768..32767 and fragments.

An example sequence to configure the TJ1-PRT unit, is as follows:

1. Set the unit number with the two rotary switches of the TJ1-PRT unit.

2. Switch on the power to the system. The **RUN** LED lights. The **ERH** LED flashes.
3. Create a BASIC Program containing the command **PROFIBUS(2,2,1,10,7,150,3)**. In this example the system initializes a TJ1-PRT unit with unit number 2. The system sends seven output words from the master to the VR's 10 to 16 and three input words from the VR's 150 to 152 to the master.
4. If the configuration is successful, the **RUN** LED lights and the **COMM** LED lights. Communication is now active.

To configure the CJ1-PRM21 with the CX-PROFIBUS, do these steps:

1. Start the CX-PROFIBUS software tool.
2. Right-click the MyNetwork tree.
3. Select **Add Device....**
4. Select the PROFIBUS master board.
5. Click **OK**.

fig. 5





fig. 6



fig. 7



6. Open the **Device Catalogue** from the **View** menu.

7. Click **Install GSD Files....** The GSD file is on the Trajexia Tools CD. It can also be found in the Download Center on the OMRON website.
 8. Click **Update**. The TJ1-PRT shows in the list.
 9. Select the OMRON TJ1-PRT from the list and click **Add Device**.

fig. 8





fig. 9

Device Catalogue			
	Device	Version	Date
[+]	C200HW-PRM21	V1.04	1998-10-01
[+]	C200HW-PRT21	V1.0	2000-04-20
[+]	CJ1W-PRM21 PROF...	V2.xx	2005-08-09
[+]	CJ1W-PRM21 PROF...	V1.xx	2005-08-09
[+]	CPM1A-PRT21	V1.0	2002-03-12
[+]	COM1-PRT21	V1.0	2000-04-20
[+]	CS1W-PRM21 PROF...	V2.xx	2005-08-09
[+]	CS1W-PRM21 PROF...	V1.xx	2005-08-09
[+]	F150-PRT	V1.0	2002-01-14
[+]	OMRON CJ1W-PRT21	V2.2	2004-11-25
[+]	OMRON PRT1-SCU11	V3.4	2005-02-22
[+]	OMRON TJ1-PRT	V1.0	2005-08-25
[+]	OMRON TJ1-PRT	V1.0	2005-10-24
[+]	PRT1-COM	V1.1	1999-12-09

10. Double-click the TJ1-PRT slave module in the MyNetwork tree.
11. Set the node number in the **Station Address** field.
12. Add (**Insert**) input and output modules to the configuration list below.
13. Make sure that the quantity of input words and output words in the selected modules are equal to the quantity selected with the PROFIBUS command.
14. Click **OK**.


To configure the CJ1W-PRM21 with the CX-PROFIBUS, do these steps:

fig. 10




1. Double-click the master module in the MyNetwork tree.
2. Set the **Station Address** and **Unit Number**.

fig. 11




3. Select the **Slave area** tab.
4. Set the **Start Address** field of **Output Area 1** and **Input Area 1**.
5. Save the project.

fig. 12



6. Click the **Device Online/Offline (Toggle)** toolbar button to go on-line.
7. Click the **Device Download** toolbar button to download the parameters.

fig. 13



4.4.3 Communication Status

TJ1-PRT can provide status information to the TJ1-MC___. You can retrieve the status information in BASIC with the command **PROFIBUS** (unit_number,4,0). The result provides the following information:

Bit	Value	Description
0	0	Failed configuration of I/O data exchange
	1	I/O data exchange configured successfully
1	0	I/O data not available
	1	I/O data available
2	0	Data exchange active in OPERATE mode
	1	Data exchange active in CLEAR mode

4.5 DeviceNet

4.5.1 Introduction

DeviceNet is an international open fieldbus standard based on the CAN protocol. The TJ1-DRT enables the Trajexia system to communicate to a DeviceNet network. It exchanges data between a DeviceNet master and the TJ1-MC___. For this, it uses the Trajexia VR variables.

4.5.2 Communication set-up

The TJ1-DRT has two node number selectors. You can use the node number selectors to assign a node number to the TJ1-DRT.

The DeviceNet node numbers range from 0 to 63. If you select a node number with the node number selectors that exceeds this range, you will select the node number that is set by software. The nodes that enable software setting are 64 to 99.

To initialise the TJ1-DRT, use the BASIC **DEVICENET** command:

```
DEVICENET(unit_number, 2, 1, output_start, output_count, input_start,  
input_count)
```

where:

- **unit_number** is the number of the TJ1-DRT unit.
- **output_start** is the start address of the output data range of VR variables.
- **output_count** is the number of VR variables in the output data range, maximum 32 variables.
- **input_start** is the start address of the input data range of VR variables.
- **input_count** is the number of VR variables in the input data range, maximum 32 variables.



Note

If you use an OMRON DeviceNet master, it is advised to select either **input_count** or **output_count** with a value of 4,8,16, or 32 for the VR variables.

After you have executed the command **DEVICENET(unit_number, 2, ...)**, data arrays are automatically exchanged. The data exchanged between the TJ1-DRT and the DeviceNet master is in 16-bit integer format. Each word exchanged ranges from -32768 to 32767.

A VR variable can hold a 24-bit number, and it can also hold fragments. The exchange with the DeviceNet master does not support values outside the range -32768 to 32767 or fragments.

Configure the DeviceNet network

To configure the OMRON CJ1W/CS1W-DRM21 DeviceNet master to exchange VR variables with the Trajexia system, do these steps:

1. Start the CX-Integrator in the CX-ONE software tool.
2. Select Network from the Insert menu.
3. Select DeviceNet from the Select Network screen. The Network view shows.

4. Select CJ1W-DRM21 from the OMRON Communication adapter list.

fig. 14





fig. 15



5. Drag and drop the CJ1W-DRM21 to the Network window.





fig. 16

6. Install the **EDS** file from the CX-Integrator.
 7. Select No from the dialog window. The icon is not needed.



8. Register the slave to the master, right click on the #01TJ1-DRT icon.
9. Double click on the Master Icon.
10. Select the TJ1-DRT device.

11. Click Advanced Setup.
12. Click Connection tab.
13. Click User Setup.
14. Click Use Poll Connection.
15. Select Con.Path.
16. Select the number of variables that has been selected for the DeviceNet communication.
17. Click OK to confirm all dialog boxes.
18. Select Work Online from the Network menu.
19. Select Parameter from the Component menu.
20. Right click on the Master icon.
21. Select Parameter Download.

fig. 17





fig. 18



4.5.3 Communication Status

TJ1-DRT can provide status information to both the TJ1-MC__ and the DeviceNet master. You can retrieve the status information in BASIC with the command DeviceNet (unit_number,4,0). The result provides the following information:

Bit	Value	Description
0	0	DeviceNet (unit_number, 2, ...) not executed yet
	1	DeviceNet (unit_number, 2, ...) executed without error
1	0	No DeviceNet I/O connection
	1	DeviceNet I/O connection running
2	0	VR variables in the output data range have been updated
	1	VR variables in the output data range have not been updated yet
3	0	DeviceNet I/O connection size matches the DeviceNet(unit_number,2,...) command
	1	DeviceNet I/O connection size does not match the DeviceNet(unit_number,2,...) command
4-7	0	Always zero
8	0	Network power OK
	1	Network power failure
9	0	No BUSOFF occurred
	1	BUSOFF occurred
10	0	No node address duplication error
	1	Node address duplication error
11-	0	Reserved

You can retrieve the status information in the DeviceNet master by selecting a connection path that includes status information. The status information includes one bit. Bit 2 indicates that the network voltage has dropped below

the level set in the TJ1-DRT DeviceNet parameters. You can set the TJ1-DRT DeviceNet parameters using a DeviceNet configurator. The default level is 11V.

4.6 CANopen

CANopen is a networking system based on the CAN (Controller Area Network) serial bus. The Trajexia CANopen Master Unit (TJ1-CORT) is an interface between the Trajexia system and up to 8 CANopen devices. It operates as the NMT (Network Management) master in the network. The TJ1-CORT can communicate up to 8 PDOs (Process Data Objects) in each direction.

4.6.1 Communication setup



Note

To set up the CANopen communication, the user must have a basic knowledge of CANopen systems.

The TJ1-CORT is identified in the CANopen network by its node number. The node number can range from 1 to 99. The node number of the TJ1-CORT is set with the two node number selectors.

To initialize the TJ1-CORT, execute the **CAN_CORT** commands given below.



Note

The execution order of the **CAN_CORT** commands given below is important. Execute the commands in the order given below. If not, initialization errors can occur.

1. Initialize the TJ1-CORT: execute the command
CAN_CORT(unit,5,bit_rate).
2. Add the slave nodes to the network.
To add a slave node to the TJ1-CORT, execute the command
CAN_CORT(unit,6,node_ID,mandatory_flag).
3. Add the TPDOs (Transmit PDOs) and RPDOs (Receive PDOs), and map them to the TJ1-MC__ memory.
To configure an RPDO, execute the command
CAN_CORT(unit,7,PDO_number,area_type,start_address,COB_ID, obj_type, obj_type,...)

To configure a TPDO, execute the command
CAN_CORT(unit,8,PDO_number,area_type,start_address,COB_ID, inhibit_time,event_timer,obj_type, obj_type,...)

4. The write operations defined with the command
CAN_CORT(unit,9,node_ID,index,subindex,byte1,byte2,...) are executed at each network startup. Note the following:
 - Execute this command for each CANopen object that must be configured.
 - Do the configuration for the TJ1-CORT first, before the configuration of the CANopen slaves.
 - Group the configuration commands for the CANopen slaves together per node.
 - It is possible that certain non-default settings are required for the TJ1-CORT or the CANopen slaves in the network. An example is to initialize the heartbeat consumption and production object entries.

- It is highly recommended that the TJ1-CORT acts as the heartbeat consumer for all connected CANopen devices. Otherwise, the communication status will be incorrect.
5. Start the CANopen network and the mapping of the Trajexia memory to RPDOs and TPDOs: execute the command **CAN_CORT(unit,10)**.
An example is the configuration given in the figure.

Connection	PDO	COB-ID	Size	Mapping
(1)	TPDO0	\$202	1 Byte	VR(100)
(2)	RPDO0	\$1e3	1 Byte	VR(0)

This results in the following script:

```

tot_result = TRUE
result = TRUE

' -----
' Initialise
' -----

result = CAN_CORT(0,5,4)
tot_result = tot_result AND result

IF tot_result = FALSE THEN
    PRINT "Initialise Fail"
    STOP
ENDIF


' -----
' Add Nodes
' -----

' Node ID 2
result = CAN_CORT(0,6,$2,1)
tot_result = tot_result AND result

' Node ID 63
result = CAN_CORT(0,6,$63,1)
tot_result = tot_result AND result

```

fig. 19



```

IF tot_result = FALSE THEN
    PRINT "Add Nodes Fail"
    STOP
ENDIF

'-----
' Add TPDO / RPDO
'-----
' Map TPDO 0 to VR(100)
result = CAN_CORT(0,8,0,1,100,$202,0,0,5)
tot_result = tot_result AND result

' Map RPDO 0 to VR(0)
result = CAN_CORT(0,7,0,1,0,$1e3,5)
tot_result = tot_result AND result

IF tot_result = FALSE THEN
    PRINT "Add TPDO / RPDO Fail"
    STOP
ENDIF

'-----
' Slave Config Settings
'-----

' Node 9 (TJ1-CORT)
' Set Heartbeat consumption
result = CAN_CORT(0,9,$9,$1016,1,0,$2,0,$D0)
tot_result = tot_result AND result
result = CAN_CORT(0,9,$9,$1016,1,0,$63,0,$D0)
tot_result = tot_result AND result

' Node 2
' Set Heartbeat production
result = CAN_CORT(0,9,$2,$1017,0,0,$C8)
tot_result = tot_result AND result

' Additional settings
result = CAN_CORT(0,9,$2,$2001,1,$f)
tot_result = tot_result AND result

' Node 63
' Set Heartbeat production
result = CAN_CORT(0,9,$63,$1017,0,0,$C8)
tot_result = tot_result AND result

IF tot_result = FALSE THEN
    PRINT "Slave Config Settings Fail"
    STOP
ENDIF

'-----
' Start Network
'-----
result = CAN_CORT(0,10)
tot_result = tot_result AND result

IF tot_result = FALSE THEN
    PRINT "Start Network Fail"
    STOP
ENDIF

NIO = 64

```

4.6.2 Communication status

The TJ1-CORT can give status information to the TJ1-MC__. To retrieve this status information, use the BASIC command **CAN_CORT(unit,4,0)**. The result value of this command is given in the table below.

Bit	Value	Description
0	0	Mandatory slave is in correct state
	1	Mandatory slave is in unexpected state
1	0	Optional slave is in correct state
	1	Optional slave is in unexpected state
2	0	Input data does not contain valid data
	1	Input data contains valid data
3	0	No emergency messages received.
	1	One or more emergency message received
4	0	No fatal network error
	1	Fatal network error
5	0	No PDO length error
	1	PDO length error
8	0	No network power problem
	1	Network power lost
9	0	No CAN bus problem
	1	CAN bus in BUS OFF state
10	0	No duplicate node number in network
	1	Duplicate node number in network
12	0	No CAN bus error detected
	1	CAN bus error detected

4.6.3 Communication operation

When the communication is in progress, specific data can be exchanged with the **CAN_CORT** command.

1. To set the CANopen network state to pre-operational or operational, execute the command **CAN_CORT(unit,11,mode)**.
2. To read the value of an object of a CANopen node with an SDO (Service Data Object) command, execute the command **CAN_CORT(unit,12,node_ID,index,subindex,VR_address)**. Each byte of the return value occupies one VR address. The first address (**VR_address**) contains the SDO response byte. The data read starts at **VR_address + 1**. When the SDO response is not 0, the error information from the node unit starts at **VR_address + 1**.
3. To write a value to an object of a CANopen node with an SDO command, execute the command **CAN_CORT(unit,13,node_ID,index,subindex,VR_address,data_len)**. Each VR address is interpreted as one byte of the value that is written.
4. To read the EMCY (emergency message from a node, execute the command **CAN_CORT(unit,14,node_ID,VR_address)**. Each byte of the 8 bytes occupies 1 VR address.

4.7 MECHATROLINK-II

The MECHATROLINK-II protocol is a serial bus that is made to control motion in a deterministic way.

The number of MECHATROLINK-II devices determines the data exchange cycle time:

- For 1 to 4 devices the cycle time can be 0.5 ms, 1 ms or 2 ms.
- For 5 to 8 devices the cycle time can be 1 ms or 2 ms.
- For 9 to 16 devices the cycle time is 2 ms.

The cyclic transmission has two stages:

- The TJ1-ML__ sends the reference command to the MECHATROLINK-II slaves.
- The slaves send feedback and status information to the TJ1-ML__.

The MECHATROLINK-II uses a synchronization clock and broadcast messaging to make sure that all the slaves execute the commands at the same time.

In addition, other information is transferred at a lower rate, for example the reading and writing of parameters.

There are specific BASIC commands to address MECHATROLINK-II slave units directly.

- **DRIVE_CLEAR:** This command resets one alarm in a MECHATROLINK-II Servo Driver via a MECHATROLINK-II message.
- **OP(45,ON):** This command sets to on one output in a remote MECHATROLINK-II I/O module.

4.8 GRT1-ML2 I/O mapping

The GRT1-ML2 SmartSlice I/O Unit is an interface for data exchange between a TJ1-ML__ MECHATROLINK-II Master Unit and SmartSlice I/O Units.

If you plan data exchange that requires strict control of the I/O timing, refer to appendix A. This appendix also contains some useful examples.

4.8.1 Unit numbers

The GRT1-ML2 must have a MECHATROLINK-II address to be identified on the MECHATROLINK-II network. With this address, the TJ1-MC__ connected to the TJ1-ML__ can exchange I/O data with the GRT1-ML2.

4.8.2 SmartSlice I/O mapping

The I/O data of the SmartSlice I/O Units is transferred to the TJ1-MC__ controller. Then the data is automatically mapped in the I/O memory of the TJ1-MC__. The mapping is determined by:

- The type of the SmartSlice I/O Unit
- The order of the SmartSlice I/O Units

The I/O data from GRT1-ML2 units is mapped in the TJ1-MC__ in order of the GRT1-ML2 addresses. For example, the I/O data of a GRT1-ML2 unit with address 67 hex is mapped before the I/O data of a GRT1-ML2 unit with address 68 hex.

The TJ1-MC__ allocates digital I/O points in blocks of 32 points.



Note

The GRT1-ML2 does not support the on-line configuration of SmartSlice I/O Units. However, other communications units can change the parameters of a SmartSlice I/O Unit and store this configuration in the SmartSlice I/O Unit.



Note

If the GRT1-ML2 configuration contains non-supported SmartSlice I/O Units or SmartSlice I/O Units configured to consume a non-default amount of I/O data, the MECHATROLINK-II connection to the GRT1-ML2 is refused, and it cannot be operated.



Note

The automatic I/O mapping of SmartSlice I/O Units in the examples given below assumes that each SmartSlice I/O Unit has the default I/O memory settings.

I/O mapping example 1


With a MECHATROLINK-II network as shown in the figure, the response of the system when the network is initialized¹ is:

GRT1-ML2: 67(32/8/6/0/2/0/2)

where:

- 67 is the GRT1-ML2 address (hexadecimal)
- 32 is the start address of the digital I/O
- 8 is the number of digital inputs
- 6 is the number of digital outputs
- 0 is the start address of the analog inputs
- 2 is the number of analog inputs
- 0 is the start address of the analog outputs
- 2 is the number of analog outputs

fig. 20



1. To initialize the network, execute the command **MECHATROLINK(unit,0)**, reset the system, or turn the power on.

I/O mapping example 2

The configuration of the GRT1-ML2 units in the example above is:

GRT1-ML2: 63(32/8/0/0/0/6)

where:

- 63 is the GRT1-ML2 address (hexadecimal)
- 32 is the start address of the digital I/O
- 8 is the number of digital inputs
- 0 is the number of digital outputs
- 0 is the start address of the analog inputs
- 0 is the number of analog inputs
- 0 is the start address of the analog outputs
- 6 is the number of analog outputs

GRT1-ML2: 67(64/0/16/0/2/6/4)

where:

- 67 is the GRT1-ML2 address (hexadecimal)
- 64 is the start address of the digital I/O
- 0 is the number of digital inputs
- 16 is the number of digital outputs
- 0 is the start address of the analog inputs
- 2 is the number of analog inputs
- 6 is the start address of the analog outputs
- 4 is the number of analog outputs

GRT1-ML2: 69(96/12/8/2/4/10/0)

where:

- 69 is the GRT1-ML2 address (hexadecimal)
- 96 is the start address of the digital I/O
- 12 is the number of digital inputs
- 8 is the number of digital outputs
- 2 is the start address of the analog inputs
- 4 is the number of analog inputs

fig. 21

63 hex GRT1-ML2	#1 ID4	#2 ID4	#3 DA2	#4 DA2	#5 DA2			
67 hex GRT1-ML2	#1 OD8	#2 OD8	#3 AD2	#4 DA2	#5 DA2			
69 hex GRT1-ML2	#1 ID8	#2 ID4	#3 OD4	#4 ROS2	#5 ROS2	#6 AD2	#7 AD2	

- 10 is the start address of the analog outputs
- 0 is the number of analog outputs

Depending on the actual GRT1-ML2 configurations, gaps are introduced in the available digital I/O ranges. In the example above, the range of distributed digital inputs and outputs is [32–127], but there are gaps in the digital inputs in the ranges [40–95] and [108–127], and there are gaps in the digital outputs in the ranges [32–63], [80–95] and [104–127]. These digital inputs and outputs are virtual. Virtual digital inputs always have value 0 (OFF). Virtual outputs can be set ON or OFF and they can be used in programming, but they do not have a physical representation and cannot activate a device.

4.8.3 GRT1-ML2 status word

The GRT1-ML2 status flags give the status of the connection between the GRT1-ML2 and the SmartSlice I/O Units, and the status of the SmartSlice I/O Units. The status flags are 1 word in size. Their information is transferred to the TJ1-MC as part of the input data.

The table below gives the meaning of the bits in the status word.

Bit	Flag	Description
0	SmartSlice I/O Bus Communication Error	Monitors the status of SmartSlice I/O communication
1	-	Reserved
2	SmartSlice I/O Unit Warning 0: Normal 1: Error detected	Indicates a minor SmartSlice I/O Unit error. This flag goes ON when there is an error in any one of the connected SmartSlice I/O Units.
3	-	Reserved
4	SmartSlice I/O Unit Alarm 0: Normal 1: Error detected	Indicates a major SmartSlice I/O Unit error. This flag goes ON when there is an error in one of the connected SmartSlice I/O Units.
5-11	-	Reserved
12	Unit Maintenance 0: Normal 1: Error (monitor value reached)	Monitors the operating time threshold that is set with the Unit power ON time monitor function
13	Automatic Restore Monitor 0: Restore successful 1: Restore failed	Indicates whether or not the automatic parameter restore to the SmartSlice I/O Units was completed successfully
14	Communication Unit Error 0: Normal 1: Error occurred	This flag is ON if one of the other flags (bits 0 to 13) is ON
15	I/O Refreshing 0: I/O communication stopped 1: I/O communication normal	Indicates whether I/O data is exchanged normally

To read the status word, use the command

MECHATROLINK(unit,36,station,vr)

where:

- **unit** is the number of the MECHATROLINK-II Master Unit in the Motion Controller system
- **station** is the station address of the GRT1-ML2 set with the rotary switches
- **vr** is the VR memory address where the read status word is put. Use -1 to print the status word to the Command Line Terminal interface.

Every servo cycle the status word is checked and a bitwise AND is performed with the status word and the status error mask. If the result of this AND operation is not 0, the WDOG is switched off. This can be used to detect particular errors in GRT1-ML2 and stop the controller operation if they occur.

To set the status error mask, use the command

MECHATROLINK(unit,37,station,value)

where:

- **unit** is the number of the MECHATROLINK-II Master Unit in the Motion Controller system
- **station** is the station address of the GRT1-ML2 set with the rotary switches
- **value** is the value of the status error mask that must be set.

The status error mask value can be read back by means of the command

MECHATROLINK(unit,39,station,vr)

where the arguments of the command are the same as for the command **MECHATROLINK(unit,36,station,vr)**. The default value of the status error mask after the controller is turned on or reset is 4000 hex. This triggers the

WDOG when an error occurs in the GRT1-ML2. 4000 hex equals 0100 0000 0000 0000 binary. Bit 14 is the overall error bit, which is set to 1 when an error occurs.

4.8.4 Table registration

The table registration function registers the configuration of the SmartSlice I/O Units that are connected to the GRT1-ML2 in a table in the GRT1-ML2.

This allows for a comparison of the actual configuration when the power is turned on with the registered configuration.

- To enable the registered table, make sure that unit dipswitch 1 (REGS) is set to ON before the power is turned on.
- To disable the registered table, make sure that unit dipswitch 1 (REGS) is set to OFF before the power is turned on. In this case, the GRT1-ML2 automatically detects the actual I/O configuration and starts the communication.

Create a new registration table

To register the table, make sure the power of the GRT1-ML2 and the SmartSlice I/O Units is on, and set unit dipswitch 1 (REGS) on the GRT1-ML2 from OFF to ON. If the registration table is refreshed, the old registration table is erased.



Note

It is recommended to register the I/O configuration table when all SmartSlice I/O Units are communicating, that is, when the TS LED is lit green.

The configuration information that is registered contains these items:

- The order of the SmartSlice I/O Units connected to the GRT1-ML2.
- The I/O size (input or output, number of bits) of each SmartSlice I/O Unit.

The configuration information does not contain the model numbers of the SmartSlice I/O Units.


Comparison of the actual configuration and the registered table

When unit dipswitch 1 is set to ON, an I/O configuration table is registered in the GRT1-ML2, and the GRT1-ML2 is turned on, the GRT1-ML2 automatically compares the actual I/O configuration and the registered table. If a registered SmartSlice I/O Unit cannot participate in the I/O communication, or if the GRT1-ML2 detects an unregistered SmartSlice I/O Unit, a verification error occurs. In this case, the concerned SmartSlice I/O Units do not participate in the I/O communication. The I/O communication starts with the other SmartSlice I/O Units.

The tables above give an example of a mismatch between the registered table and the actual configuration. The I/O data sizes of the third unit do not match. Therefore, a verification error occurs and the third unit does not participate in the communication.

The TS LED flashes red when a verification error occurs.

fig. 22



5 Trajexia Tools interface

5.1 Introduction

Trajexia Tools is the software tool that allows to program the Trajexia system. This software allows the Application Engineer to handle Trajexia projects and to edit programs. It includes some useful tools described later in this chapter as, Run/Stop/Step individual programs, add breakpoints, execute direct commands read/write variables, Oscilloscope functions and program the Servo Drivers.

The connection to the TJ1-MC__ is via Ethernet. It is necessary to set the communication settings before connecting to a unit.

The Trajexia Tools software tool has been designed to work on-line with one TJ1-MC__.

The Trajexia Tools includes:

- The Software Tool for the TJ1-MC__ (Motion Perfect 2)
- CX-Server
- CX-Drive to program and setup the Servo Drivers and Inverter.

The Trajexia Tools can be used to program, via serial communication, other OMRON motion controllers: C200HW-MC402E, R88A-MCW151-E and R88A-MCW151-DRT-E.

5.2 Specifications and connections

5.2.1 PC Specifications

The PC specification for the use of Trajexia Tools are:

Description	Minimum specification	Recommended specification
CPU	Pentium 300MHz	Pentium, 1GHz
RAM	64 MB	256 MB
Hard drive space	140 MB	140 MB
Operating system	Windows TM 98	Windows XP

Description	Minimum specification	Recommended specification
Display	800 x 600 256 colours	1024 x 768 24-bit colour
Communications	Ethernet 10BaseT	Ethernet 100BaseT
Internet	Explorer V5.0	Explorer V6.0

Use the most recent version of Trajexia Tools. Updates are available from your local distributor. The software is also available from the Trajexia web site: www.trajexia.com.

5.2.2 Install the Trajexia Tools software

1. Insert the Trajexia Tools CD into the CD-ROM drive of the PC.
2. The Trajexia Tools Setup program starts automatically.
3. If the Trajexia Tools Setup program does not start automatically, start it manually: execute **setup.exe** in the root directory of the CD.
4. Select the language you want to use from the drop-down list. Click **OK**.

5. The Trajexia Tools Setup window shows. Click **Next**.

fig. 1




fig. 2



6. Click **Yes** to accept the licence agreement and continue.

fig. 3



7. Type your name in the **Name** field.
 8. Type your company name in the **Company** field.
 9. Type your user licence number in the **Licence** fields. Your user licence number is on the label attached to the jewel case of the Trajexia Tools CD.
 10. Click **Next**.

11. Click **Yes**.




fig. 5




12. Click Next.

fig. 6




13. Click Next.

fig. 7



14. Click **Next**.


fig. 8



15. Click **Next**.


16. The Trajexia Tools Setup program copies files to your PC. This can take a few minutes.

fig. 9



17. Click **Finish**. The CX-Drive Readme File window shows. Close this window.

fig. 10



5.2.3 Connection to the TJ1-MC__


You need a patch or crossover Ethernet cable to connect the PC to the TJ1-MC__.


Note

If you work off line the simulator can be used. Simulation allows the Trajexia tools to connect to a virtual controller. This is the way to program offline. The "Simulator" does not recognise all the specific commands for the TJ1-MC__.

1. Connect the Trajexia system to the mains power supply.
2. If you need to see the IP address and the subnet mask of the TJ1-MC__ again, set the power of the Trajexia system off and then again on.
3. Connect the Ethernet cable to the Ethernet port of the PC.
4. Connect the Ethernet cable to the Ethernet port of the TJ1-MC__. The IP address of the TJ1-MC__ shows 4 times in the LED display.
5. When you start Trajexia tools software, it tries to communicate with the controller. When you start Trajexia Tools for the first time the communication settings are not the suitable ones so you have to cancel (see fig. 12) and set your communication settings.

fig. 11



6. Start the Trajexia Tools program on your PC. Select from the Windows Start menu:

- Programs
- OMRON
- Trajexia Tools
- Trajexia Tools

7. The **Trajexia Tools** startup screen shows. Wait until the **Cancel** button is visible. Then click **Cancel**.


fig. 12



8. Select the menu:


- Options
- Communications

fig. 13




9. Make sure **ENet0** in the list is selected.
10. Click **Configure**.

fig. 14




11. Type **192.168.0.250** in the **Server name/IP address** field.
12. Click **OK**.

fig. 15



13. Click **OK**.

fig. 16



14. Open the Windows Control Panel on your PC.
15. Double-click on the **Network Connections** icon.
16. Right-click on the **Local Area Connection** icon. Click on the **Properties** menu.

fig. 17



17. Click on the **General** tab.
18. Select **Internet Protocol (TCP/IP)** in the list.
19. Click **Properties**.

fig. 18



20. Click on the **General** tab.
21. Select **Use the following IP address**.
22. Type **192.168.0.251** address in the **IP address** field.
23. Type **255.255.255.0** in the **Subnet mask** field.
24. Click **OK**.
25. Click **OK**.
26. Close the Network Connections screen.

5.3 Projects

5.3.1 Trajexia Tools Projects

Projects makes the design and development process of an application easier. A hard disk copy of all the programs, parameters and data is available on the PC that is used to program the system.

The user defines a project, Trajexia Tools keeps the consistency between the project on the PC and the Trajexia system.

Programs that are edited are automatically duplicated on the PC.

A Trajexia Tools project consists of a **project.prj** that contains the Trajexia configuration, the Servo Driver parameters and a set of **.bas** programs. Those files are stored in a folder with the same name or the **.prj** file.



Note

A program that is made on one computer cannot be correctly opened in another. To avoid this problem, copy the complete project directory from one computer to the other.

fig. 19





fig. 20



5.3.2 Check Project window

Trajexia Tools starts the Check Project window when connected to the Trajexia system. A comparison is made between the program files in the Trajexia system and the program files on the PC.

If the program files are different the Check Projects window shows:

- **Save**
- **Load**
- **Change**
- **New**
- **Resolve**
- **Cancel**

Save

Uploads the project that is in the Trajexia system to the PC.

A project of the same name on the PC is overwritten. Before you save to the PC make sure that the program on the PC has a back-up copy first.

Load

Downloads the project that is in the PC to the Trajexia system.


The project on the Trajexia system is overwritten. Before you load to the Trajexia system, make sure that the program on the Trajexia system has a back-up copy first.

Change

Lets you open a project that is on your PC that is different to the default project.

If the project on the Trajexia system and the PC are not the same, you can use **Change** to select a different project on the PC. Trajexia Tools again checks both projects. This is needed when working on multiple applications with different projects.

fig. 21



New

Deletes the project that is on the Trajexia system and starts a new project on the PC. Trajexia Tools makes a new directory with the project name that contains the new project file. The name of the directory must be the same as the name of the project, else the project cannot open.

Resolve

Compares the project that is on the Trajexia Tools with the project that is on the PC. This option offers the possibility to **Save**, **Load** or **Examine** the differences individually for each individual program inside the project. This option allows a modification of a program off line using the simulator and a download of the same program to the TJ1-MC__. This option also allows more than one person work on the same project at the same time.

Cancel

Stops the connection process. The Trajexia Tools starts in disconnected mode.

5.4 Trajexia Tools application window

The Trajexia Tools application window has these parts:

1. Control panel
2. Menu bar
3. Toolbar
4. Workspace
5. Status bar

5.4.1 Control panel

The control panel allows a quick and easy way of accessing to the most commonly used controls to handle and commission a project.


5.4.2 Menu bar

The menu bar has these items:

- Project
- Controller
- Program
- Tools
- External
- Options
- Window
- Help

The menus are described in detail in section 5.5.

fig. 22



5.4.3 Toolbar

	Connect	Connects the Trajexia Tools to the Trajexia system. Refer to Connect in "Controller menu" (p. 258).		Watch variables	Not implemented in Trajexia.
	Disconnect	Disconnects the Trajexia Tools from the Trajexia system. Refer to Disconnect in the menu "Controller menu" (p. 258).		Simulator	Not fully implemented in Trajexia.
	Terminal	Command line editor. Refer to Terminal in the "Tools menu" (p. 264).		Trajexia Tools Help	Opens Trajexia Tools Help.
				Trio BASIC Help	Opens Trio BASIC Help.
	Axis Parameters	Refer to Axis parameters in the "Tools menu" (p. 264).			
	Intelligent drives	Refer to Intelligent drives in the "Tools menu" (p. 264).			
	Oscilloscope	The software oscilloscope can be used to trace axis and motion parameters. This helps to program development and system commissioning. Refer to oscilloscope in the "Tools menu" (p. 264).			
	Keypad	Not implemented in Trajexia.			
	Jog Axis	This window allows the user to manually move the axes on the Trajexia. Refer to Jog Axis in the "Tools menu" (p. 264).			
	Digital IO	Refer to Digital IO Status in the "Tools menu" (p. 264).			
	Analog input	Refer to Analog input in the "Tools menu" (p. 264).			
	TABLE values	Refer to the TABLE and VR values in the "Tools menu" (p. 264).			
	VR values	Refer to the TABLE and VR values in the "Tools menu" (p. 264).			

5.5 Menu descriptions

5.5.1 Project menu

The **Project** menu lets you create, load and save Trajexia Tools projects.

New project

Deletes the project that is on the Trajexia system and starts a new project on the PC. Trajexia Tools makes a new directory with the project name that contains the new project file. The name of the directory must be the same as the name of the project, else the project can not open.

Load project

Opens a project that is on the PC. Trajexia Tools downloads the project that is in the PC to the Trajexia system.

The project on the Trajexia system is overwritten. Before you load to the Trajexia system, make sure that the program on the Trajexia system has a back-up copy first.

Save project as...

Uploads the project that is in the Trajexia system to the PC and saves as to a directory on the hard-drive of the PC.

Check project


A check is made between the Project on the Trajexia system and the PC. The checksums and program content are compared.

Revert to backup...

Whenever Trajexia Tools connects to the MC16 it compares the project in the controller and on the PC and then makes a backup copy. **Revert to backup** can be used when you want to cancel all modifications done to the project and BASIC programs while connected to the controller.

By doing so the BASIC programs will be changed to the versions in the backup directory.

fig. 23



Modify STARTUP program

The **Startup** program checks the number of nodes in a MECHATROLINK-II system to the project. Use the **Modify STARTUP** program to change a startup program that is made by the **Intelligent Drives** window.

Load table

A list of table values can be loaded from an external file with the extension ***.lst** or ***.bas**. It imports the values and stores it in TABLE values.

Save table file...

Saves a ***.lst** or ***.bas** file from TABLE values to the project directory.

Load program file

Loads a file that contains code that can be executed in a task.

Save program file

Saves the program file as in **.txt** format.


Recent projects

You can open the recent projects that have been edited by the Trajexia Tools software.

Exit

Closes the Trajexia Tools application.

fig. 24



5.5.2 Controller menu

The Controller menu lets you set the communication between the PC and the Trajexia system, and control the Trajexia system.

Connect

Connect to the Trajexia system and starts the project manager. Available if the Trajexia Tools is disconnected from the system.

Disconnect

Disconnects from the Trajexia system. Available when the Trajexia Tools is connected to the system.

Connect to simulator

Not fully implemented for Trajexia.


Reset the controller

Do a software reset on the Trajexia system. The Trajexia Tools application disconnects from the Trajexia system.

Recover project from EPROM

Resets the Trajexia system and restores the programs that are on the EPROM to the PC.

fig. 25



Controller configuration

Shows the hardware configuration screen of the controller hardware that is connected to the PC.

Controller: The PC is connected to a Trajexia Motion Controller (TJ1-MC____) with 1.64 Dev. 94 software. The servo period is 1000µs.

Axis: Shows the axes that are available.


Comms: The communication capability of the Trajexia Motion Controller.

I/O: The type and range of the digital, analog and virtual inputs and outputs.

CANIO

Not implemented for Trajexia.

fig. 26



Ethernet configuration

Lets you change the Ethernet configuration and IP address of the controller hardware.

Slot: Always -1 for Trajexia.

IP address: The IP address of the Trajexia Motion Controller. This is not the same as the IP address of the PC.

Subnet Mask: The subnet mask for the Trajexia Motion Controller and the PC must be the same.

Default gateway: A node on the network that serves as an entrance to another network. This is only required if Trajexia is needed to communicate with a device on another subnet.

MAC address: Media Access Control address, a hardware address that uniquely identifies each node of the network. This address is read-only.

Normal Communications Port Number: The TCP port used to communicate with Trajexia Tools.

Token Communications Port Number: The TCP port used to communicate with PC Motion ActiveX control.

Enable features

Not implemented for Trajexia.

Enable editing

Sets the Trajexia to work with the RAM version of the programs. In this mode the programs can be edited.

Trajexia keeps the programs stored in RAM (and global variables) using the backup battery. This option changes internally the **POWER_UP** parameter.


If **POWER_UP** is set to 0, at start-up Trajexia uses the programs stored in RAM by the back-up battery, even if the programs were saved in flash. This feature is only available when **POWER_UP=1**.

Fix project into EPROM

Copy the programs on the controller to the flash EPROM. All programs that are currently in the EPROM are overwritten. This feature changes

POWER_UP to 1, the RAM is overwritten with the contents of the EPROM after power up. In this mode the programs cannot be edited. This feature is only available when **POWER_UP=0**.

fig. 27



Load System Software

Trajexia has a flash EPROM to store both the user programs and the system software. Use Load System Software to upgrade the system software to a newer version.

A dialog window opens that makes sure you make a back-up copy of the project and that you wish to continue.

A standard file selector opens. Select the file you need.



Note

OMRON recommends that you load a new version of the system software only when you are advised to do so by your distributor or by OMRON.



Caution

Do not load software that is not specified for the Trajexia motion controller. Only load versions that are specifically designed for use with Trajexia.

All other versions do not work.

A windows dialog box opens to make sure you wish to continue.

Press OK to start. The flash EPROM process will take approximately 7 minutes.



Caution

Do not stop the software upgrade process.

A break in the communication process will damage the Trajexia unit. If you cannot recover the Trajexia unit after the flash EPROM process, contact your sales representative.

When the download is complete, a check sum confirms that the flash EPROM process is successful.

To complete the process, select **Yes** in the dialog confirmation window.

Open the **Controller Configuration** window to check the new system version.

Full directory

Use to check the contents and file structure of the TJ1-MC__ directory.


Lock/Unlock

Lock the Trajexia system to prevent unauthorised access.

When the Trajexia system is locked, it is not possible to list, edit or save any of the Trajexia programs. The Trajexia system is not available through the Trajexia Tools software, although the terminal and unlock dialog boxes are available.

Type a 7 digit number to lock the system. Use the same number to unlock the system.

fig. 28



5.5.3 Program menu

The program menu contains menu items to enable programming a Trajexia project.

New

Creates a new program.

Edit

Opens a project for editing.


You can also launch the editor from the control panel. From the program menu you will first be prompted with a program selector dialog to confirm the file you wish to edit.

The Trajexia Tools Editor is designed to operate in a similar manner to any simple text editor found on a PC. Standard operations such as block editing functions, text search and replace and printing are all supported and conform to the standard Windows short-cut keys. In addition it provides BASIC syntax highlighting, program formatting and program debugging facilities.

Debug

Checks the syntax of a program and gives possible solutions.

fig. 29



The program is opened in a special trace mode that executes line by line. You can set breakpoints in the program to run the program until the breakpoint is reached. The current line of code is highlighted in the debug window.

When program runs in debug mode, any open editor is set to debug mode and becomes read-only.

Copy

Copies the contents of a program to another program.

Rename

Changes the name of a program.

Delete

Deletes the program from the file structure.

Delete all

Deletes all the programs from the file structure.

Compile

Compiles the current program in the project.

Compile all

Compiles all programs in the project.

Run

Executes the current program in the specified process.

Start stepping

Execute the current program in the specified process in the step mode (line by line).

Stop

The Stop command stops the program in the TJ1-MC__ controller. This is not the same as Motion Stop. The program stops at the end of the CPU cycle. The servo motors maintain position.

Stop all

The Stop all command stops all programs in the TJ1-MC__ controller. This is not the same as Motion Stop. The programs stop at the end of the CPU cycle. The servo motors maintain position.

Set power up mode

It is possible to make the programs in the TJ1-MC__ run automatically when the system starts up. Select **Set Powerup Mode** to open the **Run On Power Up** dialog window.

Select the program you want to run automatically. A small drop down menu appears to the right of the window. If you want Trajexia to allocate the process to run in, choose default as the process number. You can also specifically select the process.


fig. 30



5.5.4 Tools menu

The Trajexia Tools tools can be accessed by the Tools Menu or the Toolbar button.

fig. 31



Axis parameters

The Axis Parameters window lets you monitor and change the motion parameters for any axis on the Trajexia system.

The window contains the parameters in two banks:

- Bank 1 (the upper half of the window): contains parameters that can be changed by the user.
- Bank 2 (the lower half of the window): contains parameters that are set by the system software of the Trajexia system as the system processes commands and monitors the status of external inputs.

The separator that divides the two banks of data can be moved by the mouse.

When the user changes a unit parameter, all parameters that use this parameter value are re-read and adjusted by this factor.

Examples of the types of parameters that are affected by this parameter are:


- **SPEED**
- **ACCEL**
- **MPOS**

The parameter **axistatus** shows the status of the axis. The colour of the characters in the parameter value indicates the status:

- Green: No error
- Red: Error

char	Description
w	Warning FE range
a	Drive Comms Error
m	Remote Drive Error
f	Forward limit
r	Reverse limit
d	Datum input
h	Feed Hold Input
e	Following Error
x	Forward Soft Limit

fig. 32



char	Description
y	Reverse Soft Limit
c	Cancelling Move
o	Encoder Error

The options for the Axis Parameter window are:

Axes: Selects the axes for which the data is displayed.

Refresh: To reduce the load on the Trajexia system, the parameters in bank 1 are only read when the screen is first displayed or when the parameter value is set. If a parameter value is changed, the value displayed may be incorrect. The refresh button forces Trajexia Tools to read the complete selection again.



Note

If you change a parameter value, you must refresh the display before making another change.

Intelligent drives

The Intelligent drives gives access to the configuration and start-up programs for each of the drives that can be configured.

The intelligent drives tool shows the Trajexia configuration detected at power up. Clicking on the unit, the next tab appear.

At the top of the window the TJ1-MC__ with its different units is displayed. In the example:


- TJ1-MC__ with unit number -1
- TJ1-ML__ with unit number 0
- TJ1-PRT with unit number 1
- TJ1-FL02 with unit number 2.

If more than one TJ1-ML__ exists in the system, more tabs are displayed.

Modify STARTUP program creates a STARTUP program for the detected configuration.

In the tab corresponding to the TJ1-ML__ you can see the information corresponding to the detected MECHATROLINK-II slaves (including Inverter and I/O modules).

fig. 33




Clicking the **Config** button (only available for servo and Inverter), the next window appears:

Status tab:

- **Drive ID/Motor ID/Firmware Version:** Shows information of the Servo Driver & servo motor.
 - **Drive Status**, shows the contents of the **DRIVE_STATUS** word for that axis.
 - **Drive I/O**, shows the contents of the **DRIVE_INPUTS** word for that axis.
 - **Drive Clear** executes **DRIVE_CLEAR** (Servo Driver alarm clear) for that axis.
 - **Drive Reset** executes **DRIVE_RESET** (Software power on) for that axis.
 - **Drive monitor**, selects the monitor to be updated in **DRIVE_MONITOR**.
 - **Axis Type** selects the **ATYPE** for this axis. The value here will be included in the STARTUP program.
 - **Drive Mode:** Run or Commission.
 - When the axis is set to Run, its Run status and movements are fully controlled by the programs running in the TJ1-MC ____.
 - When the axis is set to Commission, the run and movements are controlled externally via FINS, this mode is implemented for use with the Jog feature and setup from CX-Drive. This is to avoid conflicts with the programs. During commissioning the axis is considered as a virtual axis by the programs.
- It is possible to read and write parameter from the drive at the same time from either the programs or via FINS, independently of the mode.

fig. 34



- Launch CX-Drive: From Trajexia Tools it is only possible to read and write parameters of a Servo Driver. If more Servo Driver functionality is needed, for example Read alarm code, Jog, Set rigidity, Autotuning, it is necessary to launch CX-Drive. Clicking this button starts CX-Drive connected to the current axis via the TJ1-ML__.

The only Servo Driver functionality not supported from CX-Drive through MECHATROLINK-II is the Trace functionality, but the Trajexia Tools oscilloscope can be used instead.

If you change any parameter of the Servo Driver through CX-Drive, the Trajexia Tools does not notice automatically. Be careful to avoid having a different parameter on the Servo Driver and in the project.

Configuration tab.

The **Configuration** tab shows a parameter editor window identical to that in CX-Drive. For further details, check the information in CX-Drive.

New functionality is:

Save button: Store the current servo parameters in the Trajexia project (in the *.prj file).

Cancel Registration Mode: When the registration in the Servo Driver is active, to obtain a quick and reliable response, it is not possible to write parameters. This is the same as executing **REGIST(-1)**.

Launch CX-Drive: same as the button explained in the Status tab.

fig. 35





fig. 36



Oscilloscope

The software oscilloscope can be used to trace axis and motion parameters.

This is an aid to program development and system commissioning.

There are four channels, each capable of recording 1 sample per **SERVO_PERIOD** with manual cycling or program linked triggering.

The controller records the data at the selected frequency and uploads the information to the oscilloscope to be displayed. If a larger time base is used, the data is retrieved in sections and the graphic is plotted in section across the display. The moment the controller starts to record the required data depends if the controller is in manual or program trigger mode.

- **Program mode:** The oscilloscope starts to record data when a trigger instruction from the program on the controller is sent.
- **Manual mode:** The oscilloscope starts to record data immediately.

Oscilloscope channels

Each channel of the oscilloscope has controls for all four channel control blocks. Each channel control block has a colour border to indicate the colour of the display for that channel. The controls are as follows:

Parameter to display: The parameters that the oscilloscope can record and display are selected from the drop-down menu in the upper left corner of each channel control block.

The parameter type sets the next label between axis (Ax) and channel (Ch). To plot the points stored in the controller TABLE, select the TABLE parameter and select the channel that has the first and last points configured by the advanced options dialog box.


If the channel is not needed, select NONE in the parameter list box.

Axis/Channel number: A drop down list box to enable the selection of the axis or channel for a motion parameter or channel for a digital or analog input/output parameter.

Y range down/Y range UP: The vertical scale is selected for each channel and can be configured for either automatic or manual mode. In automatic mode the oscilloscope calculates the appropriate scale when it has completed the recording before the oscilloscope displays the trace. When the oscilloscope runs with continuous triggering, the oscilloscope is unable to select a suitable vertical scale. The oscilloscope must be stopped and restarted.

In manual mode the user selects the most appropriate scale.

fig. 37



Y Shift: The vertical offset value is used to move a trace vertically on the display. This control is useful when two or more traces are identical.

Reset Y: This button clears the Y shift value.

Enable/Disable cursor bars: When the oscilloscope has stopped running, and a trace is shown, the cursor bars can be enabled. The cursor bars are two vertical bars, the same colour as the channel trace. These mark the maximum and minimum trace location points. The values that the bars represent are shown below the oscilloscope display.

The cursor bars are enable and disabled by pressing the cursor button. The cursor bars can be selected and moved by the mouse cursor.

General controls

The general controls are located at the bottom left of the oscilloscope screen. There controls are as follows:

Time base: The time base value is the time value of each horizontal division of the oscilloscope. The time base is selected by the up/down scale buttons either side of the current time base value box. If the time base is greater than a pre-defined value, the data is retrieved from the controller in sections and not as a continuous trace of data.

The sections of data are plotted on the display as they are received. The last point is a white spot.

X shift: When the trace is completed while the time base is changed to a faster value, only part of the trace is displayed. Use the X shift scroll bar to view the complete trace.

If the oscilloscope is configured to record both motion parameters and plot table data, the number of points plotted across the display can be determined by the motion parameter. Additional table points that are not visible can be made visible with the scroll bar. The motion parameter trace cannot be moved.

Single/continuous trigger: In single mode, the oscilloscope runs until the oscilloscope is triggered and one set of data recorded by the controller is retrieved and displayed.

In continuous trigger mode, the oscilloscope continues to run and retrieve data from the controller each time the oscilloscope is triggered and new data recorded. The oscilloscope continues to run until the trigger button is clicked for a second time.

Trigger / halt data capture: When the trigger button is clicked the oscilloscope is enabled. If it is in manual mode the controller immediately commences recording data. If it is in program mode it waits until it encounters a trigger command in a running program.

After the trigger button has been pressed, the text on the button changes to 'Halt'. If the oscilloscope is in the one-shot mode, then after the data has been recorded and plotted on the display, the trigger button text returns to 'Trigger', indicating that the operation has been completed. The oscilloscope can be halted at any time when it is running, and the trigger button is displaying the 'Halt' text.

Clear configuration: The current scope configuration (the state of all the controls) is saved when the scope window is closed, and retrieved when the scope window is next opened.

The configuration reset button (located at the bottom right hand side of the scope control panel) resets all controls to their default values.

The status indicator: The status indicator is located in between the options and configuration reset buttons. This lamp changes colour according to the current status of the scope, as follows:

- Red: Oscilloscope stopped.
- Black: The controller waits for the oscilloscope to complete the recording of the acquired data.
- Yellow: Data is being retrieved from the controller.

Set capture options: When this option button is clicked the advanced oscilloscope configuration settings dialog box is displayed.

Advanced Oscilloscope options

General information



Note

Displaying Controller Table Points:

If the oscilloscope is configured for both table and motion parameters, then the number of points plotted across the display is determined by the time base (and samples per division). If the number of points to be plotted for the table parameter is greater than the number of points for the motion parameter, the additional table points are not displayed, but can be viewed by scrolling the table trace using the horizontal scrollbar. The motion parameter trace does not move.



Note

Data Upload from the controller to the oscilloscope

If the overall time base is greater than a pre-defined value, then the data is retrieved from the controller in blocks, hence the display can be seen to be updated in sections. The last point plotted in the current section is seen as a white spot.

If the oscilloscope is configured to record both motion parameters, and also to plot table data, then the table data is read back in one complete block, and then the motion parameters are read either continuously or in blocks (depending upon the time base).

Even if the oscilloscope is in continuous mode, the table data is not re-read, only the motion parameters are continuously read back from the controller.



Note

Enabling/Disabling of oscilloscope controls

Whilst the oscilloscope is running all the oscilloscope controls except the trigger button are disabled. Hence, if it is necessary to change the time base or vertical scale, the oscilloscope must be halted and re-started.



Note

Display accuracy

The controller records the parameter values at the required sample rate in the table, and then passes the information to the oscilloscope. Hence the trace displayed is accurate with respect to the selected time base. However, there is a delay between when the data is recorded by the controller and when it is displayed on the oscilloscope due to the time taken to upload the data via the communication link.

Samples per division: The oscilloscope defaults to recording five points per horizontal (time base) grid division. This value can be adjusted using the adjacent scroll bar.

To achieve the fastest possible sample rate reduce the number of samples per grid division to 1, and increase the time base scale to its fastest value (1 servo period per grid division).

Table range used for data capture: The controller records the required parameter data values as table data prior to uploading these values to the window. By default, the lowest oscilloscope table value used is zero.


However, if this conflicts with programs running on the controller which might also require this section of the table, the lower table value can be changed. The upper oscilloscope table value is subsequently automatically updated based on the number of channels in use and the number of samples per grid division. If you enter a lower table value which causes the upper table value to exceed the maximum permitted value on the controller, then the original value is used by the oscilloscope.

Table Data Graph: It is possible to plot controller table values directly, the table limit text boxes enable the user to enter up to four sets of first/last table indices.

Parameter checks

If analogue inputs are being recorded, then the fastest oscilloscope resolution (sample rate) is the number of analogue channels in msec (i.e. 2 analogue inputs infers the fastest sample rate is 2msec). The resolution is calculated by dividing the time base scale value by the number of samples per grid division.

fig. 38



It is not possible to enter table channel values in excess of the controller maximum TABLE size, nor to enter a lower oscilloscope table value.

Increasing the samples per grid division to a value which causes the upper oscilloscope table value to exceed the controller maximum table value is also not permitted.

If the number of samples per grid division is increased, and subsequently the time base scale is set to a faster value which causes an unobtainable resolution, the oscilloscope automatically resets the number of samples per grid division.

Digital IO status

This window allows the user to view the status of all the IO channels and toggle the status of the output channels. It also optionally allows the user to enter a description for each I/O line.

Digital inputs: This shows the total number of input channels on the Trajexia.

Digital outputs: This shows the total number of output channels on the Trajexia.

Display: The display is divided up into banks containing 8 indicators, representing blocks of 8 inputs or outputs:

- **Input Bank (In)**

These represent the status of the digital inputs. In(0) to In(15) are the digital inputs built-in in TJ1-MC__. Additional Digital inputs in the system are mapped automatically starting from In(32).


- **Output Banks (Out)**

These represent the status of the digital outputs. OP(8) to OP(15) are the digital outputs built-in in TJ1-MC__. Additional Digital outputs in the system are mapped automatically starting from OP(32).

- **Input / Output Banks (I/O)**

These represent virtual I/Os that you can use inside the program as user flags. Setting one of those virtual outputs, makes the corresponding virtual input to be set too. If an indicator is grey then its corresponding input or output is off. If it is coloured (yellow, green, orange, red, cyan or magenta) then its corresponding input or output is on. Different colours are used to represent different types of input and output.

fig. 39



- Clicking on an indicator representing an output (or linked input and output) results in that output changing state. Clicking on an indicator representing an input has no effect.
- Some output circuits require an external power source. In this case the input state of internally linked I/O is not indicated correctly if the external supply is not present because, even if an output is on, the input state does not change. The same situation exists if an output goes into a current limit due to a fault or overload.
 - Show description: Checking the Show Description check box will toggle between descriptions on, and descriptions off. Descriptions are stored in the project file.

Keypad

Not applicable for Trajexia.

Jog Axes

This window allows the user to move the axes on the Trajexia.

This window takes advantage of the bi-directional virtual I/O channels (16 to 27) on the Trajexia to set the jog inputs. The forward, reverse and fast jog inputs are identified by writing to the corresponding axis parameters and are expected to be connected to NC switches. This means that when the input is on (+24 V applied) then the corresponding jog function is DISABLED and when the input is off (0 V) then the jog function is ENABLED.


The jog functions implemented here disable the fast jog function, which means that the speed at which the jog will be performed is set by the JOGSPEED axis parameter. What is more this window limits the jog speed to the range 0..demand speed, where the demand speed is given by the SPEED axis parameter.

Before allowing a jog to be initiated, the jog window checks that all the data set in the jog window and on the Trajexia is valid for a jog to be performed.

Jog reverse: This button will initiate a reverse jog. In order to do this, the following check sequence is performed

- If this is a SERVO axis and the servo is off the warning message is set.
- If the WatchDog is off the warning message is set.
- If the jog speed is 0 the warning message is set.
- If the acceleration rate on this axis is 0 the warning message is set.
- If the deceleration rate on this axis is 0 the warning message is set.

fig. 40



- If the reverse jog input is out of range the warning message is set.
- If there is already a move being performed on this axis that is not a jog move the warning message is set.

Jog forward: This button initiates a forward jog. A check identical to jog reverse is performed.

If there were no warnings set, then the message “**Forward jog set on axis?**” is set in the warnings window, the **FAST_JOG** input is invalidated for this axis, the **creep** is set to the value given in the jog speed control, and finally the **JOG_FWD** output is turned off, thus enabling the forward jog function.

Jog speed: This is the speed at which the jog will be performed. This window limits this value to the range from zero to the demand speed for this axis, where the demand speed is given by the **SPEED** axis parameter. This value can be changed by writing directly to this control or using the jog speed control. The scroll bar changes the jog speed up or down in increments of 1 unit per second.

Jog inputs: These are the inputs which will be associated with the forward / reverse jog functions.

They must be in the range 8 to the total number of inputs in the system as the input channels 0 to 7 are not bi-directional and so the state of the input cannot be set by the corresponding output.

The input is expected to be on for the jog function to be disabled and off for the reverse jog to be enabled. In order to respect this, when this is set to a valid input number, the corresponding output is set on and then the corresponding **REV_JOG** axis parameter is set.

Axes: This displays an axis selector box which enables the user to select the axis to include in the jog axes display. By default, the physical axes fitted to the controller will be displayed.

fig. 41




TABLE viewer

The TABLE and VR Editor tools are very similar. A range of values in memory is shown in a spread sheet style interface and can be modified. To modify a value, click on the existing value with the mouse and type in the new value and press return. The change will become active immediately and can be made whilst programs are running.

Options:

- **Range**

Both tools have the option to set the start and end of the range to view.


In the TABLE view tool the max value displays the highest readable value (this is the system parameter **TSIZE**).

If the range of values is larger than the dialog box can display, then the list will have a scroll bar to enable all the values to be seen.

- **Refresh Button**

This screen does not update automatically, so if a TABLE or VR is changed by the program you will not see the new value until the display is refreshed.

fig. 42



Watch variables

Not implemented for Trajexia.

Analog inputs

Monitors the value present in the remote analogue inputs module. The inputs are automatically added to the system starting from AIN0 when one or more AN2900 module is detected.

Terminal

The terminal window is a text editor that gives a direct connection to the Trajexia system. Most of the functions that must be performed during the installation, programming and commissioning of a system with a Trajexia have been automated by the options available in the Trajexia Tools menu options. However, if direct communication is required the terminal window may be used.

Select channel. When Trajexia Tools is connected to the controller the terminal tool will show a dialog to select the communications channel.

Channel 0 is used for the Trajexia command line and channels 5, 6 and 7 are used for communication with programs running on the Trajexia.

Select the required channel and press **OK** to start a terminal tool on the selected channel. Only one terminal tool (or keypad tool) can be connected to a channel at one time.

fig. 43





fig. 44



5.5.5 Options menu

In the **Options** menu the system options for the Trajexia system are set:




fig. 45

Communications

Allows to set and view the communication settings. The settings can only be changed offline. The different options are:

- Serial for other OMRON motion controllers (C200HW-MC402-E and R88-MCW151-E).
- USB is not used.
- Simulation. Used to work offline, a virtual motion control system is simulated.
- Ethernet is the option used for Trajexia.
- PCI is not used.




fig. 46

Editor

Edits the different options of the text editor.

General Options

Allows to set various options of the system.

fig. 47




CAN Drive

Not implemented in Options.

Diagnostics

Allow to select the events to be stored in a **.log** file for diagnostics.

fig. 48



Terminal Font

Selects the font to be displayed in the terminal window. Very useful for commissioning.

Program Compare

Allows to compare programs

CX-Drive Configuration

Allow to select the directory of the CX-Drive Database.

FINS Configuration

Selects the port and the timeout for the FINS communication.


Language

At the moment only English has been implemented.

5.5.6 Windows Menu

- Restore Last desktop/Restore Saved Desktop/Save Desktop/Clear Desktop: Those are tools to quickly handle and configure your desktop according to the user needs.
- Clear Controller Messages: Clear the **Controller Messages** window.


fig. 49



5.5.7 Help Menu

- Motion Perfect: Help of the Trajexia Tools.
- Trio BASIC Language: Help of the BASIC commands and parameters.
- About Motion Perfect 2: Shows the version of Trajexia Tools.

fig. 50



6 Examples and tips

This chapter gives 2 categories of examples and tips:

- How-to's.
- Practical examples.

6.1 How-to's

6.1.1 Startup program

The purpose of this program is to compare the detected MECHATROLINK-II configuration with the expected one (the expected configuration is the configuration existing in the moment you create the program).

The STARTUP program does these actions:

- Checks the number of nodes in the system.
- Checks that the node numbers agrees.
- Checks if all devices are connected and have power.
- Any non agreement, the program stops.
- Sets the correct **ATYPE** as selected in the intelligent axis window.
- Sets the mode, **Run** or **Commissioning**.

How to use the Startup program

The recommended way to use the **STARTUP** program is as follows:

1. Click the **Intelligent drives** button (A).




fig. 1

2. Click the **Modify STARTUP program** button.
3. At the end of the section created automatically, put your own application code. Typically variable initialisation and axes parameters.
4. At the end of the STARTUP program, run your application programs. It is recommended to run the "SHELL" program (see section 6.2.1).
5. Set the STARTUP program to run at power on.

**Note**

OMRON recommends that the statement **RUN “your_program”** is used at the end of the Startup program to start your application program. The application program starts when the startup program is executed successfully and without errors.

If you set an application program to “Run at startup” there is a risk that the machine starts if there is an error on the MECHATROLINK-II bus.




fig. 2

Example

```
'=====
'THE FIRST PART OF THE PROGRAM IS GENERATED
'AUTOMATICALLY BY THE INTELLIGENT AXIS WINDOW IN
'TRAJEXIA TOOLS. IT CONSISTS OF A CHECK SEQUENCE TO
'VERIFY THAT THE DETECTED AXIS CONFIGURATION IS THE
'EXPECTED ONE.

'IF YES, THE PROGRAM FINISHES AND STARTS "SHELL".
'IF NOT, THE PROGRAM STOPS AND NO OTHER PROGRAM STARTS.
'THIS PROGRAM MUST BE SET TO RUN AT POWER UP IN 'A LOW
'PRIORITY TASK (1 IN THIS EXAMPLE)
'=====

'Start MECHATROLINK Section
' Check detected devices
' Unit 0
IF NOT MECHATROLINK(0,3,0) THEN
    PRINT "Error getting device count for unit 0"
    STOP
ELSE
    IF VR(0) <> 3 THEN
        PRINT "Incorrect device count for unit 0"
        STOP
    ENDIF
ENDIF
IF NOT MECHATROLINK(0,4,0,0) THEN
    PRINT "Error getting address for unit 0, station 0"
    STOP
ELSE
    IF VR(0) <> 65 THEN
        PRINT "Incorrect address for unit 0, station 0"
        STOP
    ENDIF
ENDIF
IF NOT MECHATROLINK(0,4,1,0) THEN
    PRINT "Error getting address for unit 0, station 1"
    STOP
ELSE
```

```
IF VR(0) <> 66 THEN
    PRINT "Incorrect address for unit 0, station 1"
    STOP
ENDIF
ENDIF
IF NOT MECHATROLINK(0,4,2,0) THEN
    PRINT "Error getting address for unit 0, station 2"
    STOP
ELSE
    IF VR(0) <> 67 THEN
        PRINT "Incorrect address for unit 0, station 2"
        STOP
    ENDIF
ENDIF
' Set axis types
' Unit 0
ATYPE AXIS(0)=40
ATYPE AXIS(1)=40
ATYPE AXIS(2)=40
' Set drives into run mode
' Unit 0
MECHATROLINK(0,20,65)
MECHATROLINK(0,20,66)
MECHATROLINK(0,20,67)
'Stop MECHATROLINK Section
'=====
'THIS SECTION MUST BE MANUALLY SET BY THE USER
'ACCORDING TO THE APPLICATION. TYPICAL ACTIONS ARE
'VARIABLE INITIALIZATION, SERVO/AXIS SETTING, NAMING
'GLOBAL VARIABLES AND START THE "SHELL" PROGRAM.
'=====
'Define Names for global variables
GLOBAL "project_status",100
GLOBAL "alarm_status",101
GLOBAL "action",102
'Initialize variables
VR(0)=0
```

```
project_status=0
alarm_status=0
action=0
'Start SHELL program
RUN "SHELL", 2
STOP
```

6.1.2 Gain settings

The gain setting is related to the mechanical system to which the motor is attached. There are three main concepts:

- Inertia ratio
- Rigidity
- Resonant frequency.

These concepts are described in the Hardware Reference Manual in the chapter System Philosophy.

This section shows example parameter values for:

- Speed Loop Gain
- Proportional position gain
- Velocity Feed Forward gain.

The example values for the program and motion parameters in the Trajexia system are given below. Note that they are appropriate for 13-bit encoders.

Drive Parameter value	Description
Pn103 = 716	Inertia ratio
Pn110 = 0012	No autotuning
Pn202=1	Gear ratio numerator
Pn203=1	Gear ratio denominator

Motion Parameter values	Description
UNITS =1	Working in encoder counts


Motion Parameter values	Description
SPEED=200000	Speed setting
ACCEL=1000000	Acceleration setting
DECCEL=1000000	Deceleration setting
MOVEMENT=81920	10 Turns

Speed mode examples

In this mode the position loop is closed in Trajexia and the Speed loop is closed in the Servo Driver. The **Speed** axis parameter is sent to the Servo Driver, and reads the position feedback.

```
BASE(0)
ATYPE=44 'Servo axis encoder mode
SERVO=1
WDOG=1
DEFPOS(0)
loop:
    MOVE(81920)
    WAIT IDLE
    WA(100)
    DEFPOS(0)
GOTO loop
```

fig. 3



Example 1

Only proportional gain has a set value, the Following Error is proportional to the speed.

The parameter values for the example are:

Motion Parameter values
P_Gain=131072
VFF_GAIN=0
Fn001=4

**Note**

The colours and scale of the oscilloscope for speed mode are as follows:

Red: MSPEED (Measured Axis speed). Units is 50 units/ms/division

Blue: FE (Following Error). Units is depending on the graph

Green: MPOS (Measured Axis position). 50000 units/division

Example 2

The value for rigidity is increased. The error magnitude remains the same but the ripple, the speed stability and overshoot are better.

The parameter values for the example are:

Motion Parameter values
P_Gain=131072
VFF_GAIN=0
Fn001=6

fig. 4





fig. 5




Example 3

The parameter **P_GAIN** is increased further. The Following Error decreases proportionally.

The parameter values for the example are:

Motion Parameter values
P_Gain=200000
VFF_GAIN=0
Fn001=6

fig. 6




Example 4

The value of the parameter **P_GAIN** two times the value in example 1. The Following Error is half, but there is vibration due to the excessive gains.

The parameter values for the example are:

Motion Parameter values
P_Gain=262144
VFF_GAIN=0
Fn001=6

fig. 7



Example 5

The value of the parameter **P_GAIN** is set to the value in example 1. The value of **VFF_GAIN** is increased. The Following Error is reduced without a reduction to the stability. The Following Error is not proportional to the speed.

The parameter values for the example are:

Motion Parameter values
P_Gain=131072
VFF_GAIN=1400000
Fn001=6

Example 6

With this value of **VFF_GAIN** the Following Error is proportional to the acceleration, and smaller than with just proportional gain (the scaling is 20 units/division). The Following Error approaches zero during constant speed. The negative effect of this set of values is the overshoot and undershoot when the acceleration changes; this can be reduced but not eliminated by increasing the speed loop gain, if the mechanical system can cope with a high gain.

The parameter values for the example are:

Motion Parameter values
P_Gain=131072
VFF_GAIN=1573500
Fn001=6

fig. 8





fig. 9



Example 7

The value of the rigidity is increased from 6 to 8. The overshoot/undershoot is smaller but the motor has more vibration.

The parameter values for the example are:

Motion Parameter values
P_Gain=131072
VFF_GAIN=1573500
Fn001=8

Example 8

Opposite to the P_GAIN, where the higher, the better (the limit is when the mechanical system starts vibrating), for the VFF_GAIN there is an optimum value (the one in test 6), values higher than this value has an error proportional to the speed/acceleration but with different sign. The required correction is too large.

The parameter values for the example are:

Motion Parameter values
P_Gain=131072
VFF_GAIN=1650000
Fn001=6

fig. 10





fig. 11



Position mode examples

In this mode the position and speed loop are closed in the Servo Driver. The TJ1-ML__ sends the position command through the MECHATROLINK-II network to the Servo Driver, and reads the position feedback.

Note that this system has no sample delay as compared to the position loop in the Servo Driver, the Demand_Position in cycle "n" with the Measured_Position in cycle "n".

The Trajexia, for the internal handling, continues to use its own position loop, so the Following Error that read in the Axis parameter in Trajexia is not the real one in the Servo-drive. To read the correct Following Error use DRIVE_MONITOR.


Adjust the rigidity of the servo, the speed loop gain and the position loop gain at the same time using just proportional position gain. The results are similar to the MECHATROLINK-II Speed mode with the advantages:

- The tuning is more simple, only the rigidity (Fn001) and, if necessary, the feedforward gain (Pn109) needs to be set.
- The position loop in the servo is faster (250 μ s) than in Trajexia and it is turned together with the speed loop.
- There is no sample time delay between "Target position" and "Measured position".

To do a finetune the different gain parameters can be changed individually.

```
BASE(0)
ATYPE=41 'MECHATROLINK Position mode
SERVO=1
DRIVE_CONTROL=2 'To monitor the Following Error in
                 'DRIVE_MONITOR
WDOG=1
DEFPOS(0)
loop:
  MOVE(81920)
  WAIT IDLE
  WA(100)
  DEFPOS(0)
GOTO loop
```

fig. 12



Example 1

The Following Error is proportional to the speed. There is a "soft profile" due to the low rigidity setting (low gain).

**Note**

The colours and scale of the oscilloscope for position mode are as follows:

Red: MSPEED (Measured Axis speed). Units is 50 units/ms/division

Blue: DRIVE_MONITOR (set as Following Error in the Servo Driver). Units is depending on the graph

Green: MPOS (Measured Axis position). 50000 units/division

The parameter values for the example are:

Motion Parameter values
Fn001=4
Pn109=0

Example 2

The Following Error reduces as the rigidity increases.

The parameter values for the example are:

Motion Parameter values
Fn001=6
Pn109=0

fig. 13





fig. 14




Example 3

With high gain the motor starts to vibrate but the profile is more stable than in MECHATROLINK-II Speed mode.

The parameter values for the example are:

Motion Parameter values
Fn001=8
Pn109=0

fig. 15




Example 4

The effect of the Feedforward gain is that the Following Error is reduced and the effect is proportional to the acceleration.

The parameter values for the example are:

Motion Parameter values
Fn001=6
Pn109=95

fig. 16




Example 5

With the feedforward set to 100%, the Following Error is very small and proportional to the acceleration. The optimum value of 100% correction is the maximum value that can be set. The parameter value of Pn109 is easier to set than the parameter value of VFF_GAIN.

The parameter values for the example are:

Motion Parameter values
Fn001=6
Pn109=100

fig. 17



6.1.3 Setting the **UNITS** axis parameter and gear ratio

In controlling the mechanical axis with the Trajexia TJ1-MC__, a Servo Driver and a servo motor, the only measurement units that the hardware understands are encoder counts. All commands to the driver to move an axis are expressed in encoder counts. All feedback information about axis positions is also expressed in encoder counts. When writing programs in BASIC to achieve movements or a sequence of movements, a user can prefer to work with user defined units, such as millimeter, centimeter, meter, degree of angle, "product", "rotation", "stations". The **UNITS** axis parameter contains the conversion factor between encoder counts and user defined units. All axis parameters related to motion and arguments of axis commands that determine the amount of motion are expressed in these user units. This parameter enables the user to define the most convenient units to work with. For example, for a moving part that makes a linear motion, you can prefer mm, or fraction of mm. For a moving part that makes a rotation motion, you can prefer a degree of angle or its fraction. For more information on the **UNITS** axis parameter, see section 3.2.276.

However, the user must be aware that not only the **UNITS** axis parameter matters in the conversion between encoder counts and user defined units. Certain Servo Driver parameters and some characteristics of the mechanical

system are also important. The following sections describe which Servo Driver parameters are important for this conversion. We also give examples of how to set those parameters and the **UNITS** axis parameter, taking the characteristics of the mechanical system into account.

Conversion between encoder counts and user defined units

Two very important parameters of the Servo Drivers for conversion of encoder counts into user units are the electronic gear ratio numerator and the electronic gear ratio denominator. The table below gives these parameters for the Servo Drivers.

Servo Driver	Numerator	Denominator
Sigma-II	Pn202	Pn203
Sigma-V	Pn20E	Pn210
Junma	Pn20E	Pn210



Note

The remainder of this section uses the parameters of the Sigma-II Servo Driver, that is, Pn202 and Pn203. If you use a Sigma-V or a Junma Servo Driver, you must use the corresponding parameters.

If a servo motor with an absolute encoder is used, setting parameter Pn205 (Multiturn limit) is also necessary.

Parameter Pn202 is the electronic gear ratio denominator (G1). Parameter Pn203 is the electronic gear ratio numerator (G2). The servo motor rotates using the value of the position command signal sent by the TJ1-MC__, multiplied by the electronic gear (Pn202, Pn203). On the output (servo motor) side, the signal is expressed in number of encoder pulses. For more information on Servo Driver parameters Pn202 and Pn203, see the Sigma-II Servo Driver manual.

The **UNITS** axis parameter effectively expresses the ratio between user units that the user wants to use in the program and the position sent to the Servo Driver via the MECHATROLINK-II bus. Taking the electronic gear setting into account, the equation expressing the relation between user units, the **UNITS** parameter, parameters Pn202 and Pn203, encoder pulses and mechanical measurement units is:

$$\frac{Pn202}{Pn203} \cdot UNITS = \frac{y \cdot \text{encoder_counts}}{x \cdot \text{user_units}}$$

where y is the number of encoder counts and x is the amount in user units.

Example 1

The mechanical system consists of a simple rotary table. A servo motor with 13-bit incremental encoder is used. The gear ratio of the gearbox is 1:10. The desired user units are degree of angle. This system can be described with the following equations:

$$1 \cdot \text{motor_revolution} = 2^{13} \cdot \text{encoder_counts}$$

$$10 \cdot \text{motor_revolution} = 1 \cdot \text{machine_cycle}$$

$$1 \cdot \text{machine_cycle} = 360^\circ$$

The combination of these equations results in:

$$\frac{Pn202}{Pn203} \cdot UNITS = \frac{2^{13} \cdot \text{encoder_counts}}{1 \cdot \text{motor_revolution}} \cdot \frac{10 \cdot \text{motor_revolution}}{1 \cdot \text{machine_revolution}} \cdot \frac{1 \cdot \text{machine_revolution}}{360^\circ} = \\ \frac{2^{13} \cdot 10 \cdot \text{encoder_counts}}{360} \cdot \text{degree}$$

fig. 18





fig. 19



And therefore:

$$\frac{Pn202}{Pn203} \cdot \text{UNITS} = \frac{2^{13} \cdot 10}{360}$$

From this equation, we can derive the values for Pn202, Pn203 and **UNITS**, given the following restrictions and recommendations:

1. Pn202 and Pn203 are integers.
2. UNITS must not have an infinite number of decimal digits. This can create rounding errors that result in small position errors that add up to large accumulative position errors.
3. For reasons of stability, it is necessary to avoid situations where Pn202/Pn203 is less than 0.01 or greater than 100. It is recommended that Pn202/Pn203 is approximately 1.

We can now rewrite the last equation to:

$$\text{UNITS} \cdot \frac{Pn202}{Pn203} = 2^{13} \cdot \frac{10}{360}$$

One solution to this equation is:

$$\text{UNITS} = 2^{13} = 8192$$

$$\text{Pn202} = 10$$

$$\text{Pn203} = 360$$

When we consider the third recommendation from the above list (avoid situations where Pn202/Pn203 is less than 0.01 or greater than 100), we can rewrite the last equation to:

$$\text{UNITS} \cdot \frac{Pn202}{Pn203} = 2^{13} \cdot \frac{10}{360} = 2^8 \cdot \frac{2^5}{36} = 2^8 \cdot \frac{32}{36}$$

This gives us the solution:

UNITS = 2^8 = 256

Pn202 = 32

Pn203 = 36

With these values, the command **MOVE(28)** rotates the table 28 degrees in positive direction.

Absolute encoder setting

The absolute encoder keeps the current motor position, even if there is no power supplied. The absolute encoder gives the position within one turn (that is, a fraction from 0 to and excluding 1), and it has a multturn counter.

You can set the multturn behaviour of the absolute encoder with the parameter Pn205 of the Sigma-II Servo Driver. This parameter adjusts the maximum number of turns that the counter counts before it has an overflow.

For more information on Servo Driver parameter Pn205, see the Sigma-II Servo Driver manual. Taking this parameter value into account, the maximum position value the encoder can signal is:

```
max_encoder_count_value = (Pn205 + 1) · encoder_counts - 1
```

which makes it Pn205 complete turns, plus the position within one turn (the fraction from 0 to and excluding 1). When the MECHATROLINK-II connection is established with the drive, the absolute encoder position is read from the drive and the value is written in **MPOS** (after the conversion: **UNITS** × Pn202/Pn203). When the mechanical system has a limited travel distance to move, like in a ball screw, the value of the parameter Pn205 should be set large enough to have an overflow of the counter out of the effective position. This is called limited axis or finite axis. A typical example of a limited axis is a ball screw, as shown in fig. 24. When the mechanical system always moves in the same direction, it reaches the overflow of the multturn counter. In this case, the value of Pn205 must guarantee that the overflow always occurs in the same position with respect to the machine. This is called unlimited axis and a typical example of it is a turntable shown in fig. 20. It can be achieved with the following equation: the smallest value of *m* such that:

$$n \cdot \text{machine_cycles} = m \cdot \text{motor_revolution}$$

Because n and m are integers: $\text{Pn205} = m - 1$. This setting is explained in the following example.

Example 2

The mechanical system consists of simple rotary table shown in the figure. A servo motor with 16-bit absolute encoder is used. The gear ratio of the gearbox is 1:10. The desired user units are degree of angle. The rotary table is divided in six sections of 60 degrees each. Therefore the machine_cycle is 60 degrees.

When we apply the last equation to the above, we get:

$$10 \cdot \text{motor_revolution} = 1 \cdot \text{machine_revolution} = 6 \cdot \text{machine_cycle}$$

Simplification of this equation gives:

$$5 \cdot \text{motor_revolution} = 3 \cdot \text{machine_cycle}$$

This results in:

$$\text{Pn205} = 5-1 = 4$$


We calculate the parameters as we did in example 1. This gives:

$$\text{UNITS} = 2^{11} = 2048$$

$$\text{Pn202} = 32$$

$$\text{Pn203} = 36$$

To guarantee the correct overflow both in Trajexia and in the Servo Driver, we must set two additional axis parameters: **REP_DIST** = 60, and **REP_OPTION** = 1. With these settings, the command **MOVE(35)** rotates the table 35 degrees in positive direction. The range of possible **MPOS** and **DPOS** values is from 0 degrees to 60 degrees.



**Caution**

You must initialize the absolute encoder before you use it for the first time, when the battery is lost during power off and when the multiturn limit setting in the parameter Pn205 is changed. The initialization can be done on the display of the Servo Driver or with the software tool. For more detail on initialising absolute encoder, please see the Sigma-II Servo Driver manual.

**Caution**

It is possible to reset the multiturn counter, but it is not possible to reset the position within one turn (the fraction from 0 to and excluding 1). To adjust zero offset, use the parameter Pn808. For more details see the NS115 MECHATROLINK-II Interface Unit manual.

**Caution**

At power up, the absolute encoder position is read from the motor and written to **MPOS** using the following conversion:

- For **MPOS**:

$$\text{Absolute_MPOS} = \text{abs_position_encoder} \cdot \frac{1}{\text{UNITS}} \cdot \frac{\text{Pn203}}{\text{Pn202}}$$

- This is correct if

$$(\text{Pn205} + 1) \cdot \frac{\text{Pn203}}{\text{Pn202}} \cdot \text{encoder_counts} < 2^{24}$$

- If this value is greater than 2^{24} , **MPOS** can have incorrect values at start-up. To avoid this problem, add the program code **DEFPOS = ENCODER/UNITS** after all **UNITS** initializations.

**Caution**

To make sure that the absolute position is always correct, you must make sure that

$$(Pn205 + 1) \cdot \text{encoder_resolution} < 2^{32}$$

and that

$$(Pn205 + 1) \cdot \text{encoder_resolution} \cdot \frac{Pn203}{Pn202} < 2^{32}$$

Note that this is not obvious for the high-resolution encoders of the Sigma-V motors.

Example 3

The mechanical system uses a servo motor with an 17-bit absolute encoder. The mechanical gear ratio of the gearbox is 1:6.31. One rotation of the pulley moves the moving part on the belt 320 mm. The total length of the belt, and therefore the total moving range of the motion part, is 4160 mm. The mechanical measurement units must be mm. This means that all axis parameters and commands given to Trajexia are expressed in mm. Using the same procedure as in example 1, the equation expressing the relationship between user units and encoder counts is:


$$\frac{Pn202}{Pn203} \text{ UNITS} = \frac{2^{17} \cdot \text{encoder_counts}}{1 \cdot \text{motor_revolution}} \frac{6.31 \cdot \text{motor_revolution}}{1 \cdot \text{pulley_revolution}} \frac{1 \cdot \text{pulley_revolution}}{320\text{mm}} =$$

$$\frac{2^{17} \cdot 6.31}{320} \frac{\text{encoder_counts}}{\text{mm}}$$

Therefore:

$$\frac{Pn202}{Pn203} \text{ UNITS} = \frac{2^{17} \cdot 6.31}{320} = \frac{2^{17} \cdot 631}{2^5 \cdot 1000} = 2^{12} \frac{631}{8.125} = 2^{12} \frac{631}{2^3 \cdot 125} = 2^9 \frac{631}{125}$$

One solution is:



$$\text{UNITS} = 2^9 = 512$$

$$\text{Pn202} = 631$$

$$\text{Pn203} = 125$$

Note that we have not used the pulley radius in the calculation. This is to avoid the use of π , which cannot be expressed as a fractional number). In toothed pulleys, the number of teeth and mm per tooth is commonly used. The calculation of the multiturn limit setting is:

$$m \cdot \text{motor_revolution} = n \cdot \text{machine_cycle}$$

$$\begin{aligned} m \cdot \text{motor_revolution} &= n \cdot \text{machine_cycle} \cdot \frac{4160 \cdot \text{pulley_revolution}}{320 \cdot \text{machine_cycle}} = n \cdot 13 \cdot \text{pulley_revolution} \\ &= n \cdot 13 \cdot \frac{6 \cdot 31 \text{ motor_revolution}}{1 \text{ pulley_revolution}} = n \cdot 82.03 \cdot \text{pulley_revolution} \end{aligned}$$

$$m = n \cdot 82.03$$

The smallest integer m for which this equation is valid is 8203. This results in Pn205 = 8202.

In addition, to limit the motion units range to the moving range of the motion part, the following axis parameters must be set: **REP_DIST = 4260**, and **REP_OPTION = 1**. With these settings, executing **MOVE(38)** moves the moving part 38 mm in forward direction. The range of possible **MPOS** and **DPOS** values is 0 mm to 4160 mm.

Example 4

The mechanical system uses a servo motor with a 17-bit absolute encoder. The mechanical gear ratio of the gearbox is 1:12.24. The mechanical measurement units must be tenths of an angle degree. Therefore the total repeat distance for the full turn of the moving part is 3600 tenths of an angle degree.

With the same procedure as in example 1, we have:

$$\begin{aligned} \frac{\text{Pn202}}{\text{Pn203}} \text{ UNITS} &= \frac{2^{17} \cdot \text{encoder_counts}}{1 \cdot \text{motor_revolution}} \frac{12.24 \cdot \text{motor_revolution}}{1 \cdot \text{machine_revolution}} \frac{1 \cdot \text{pulley_revolution}}{3600 \text{ tenth of degree}} = \\ &= \frac{2^{17} \cdot 12.24}{3600} \frac{\text{encoder_counts}}{\text{tenth of degree}} \end{aligned}$$

Therefore:

$$\text{UNITS} = \frac{\text{Pn202}}{\text{Pn203}} = 2^{17} \frac{1224}{360000}$$

One solution is:


$$\begin{aligned} \text{UNITS} &= 2^{17} = 131072 \\ \text{Pn202} &= 1224 \\ \text{Pn203} &= 360000 \end{aligned}$$

Because the greatest common divisor of Pn202 and Pn203 must be 1, we get: Pn202 = 17 and Pn203 = 500. Therefore, the parameters are:

$$\begin{aligned} \text{UNITS} &= 131072 \\ \text{Pn202} &= 17 \\ \text{Pn203} &= 500 \\ \text{Pn205} &= 16 \\ \text{REP_DIST} &= 3600 \\ \text{REP_OPTION} &= 1 \end{aligned}$$

To calculate the multiturn limit setting Pn205, we have:

$$m \cdot \text{motor_revolution} = n \cdot \text{machine_cycle} = n \cdot 12.24 \cdot \text{motor_revolution}$$



The evident solution is: $n = 100$ and $m = 1224$. Or, when we simplify the factors: $n = 25$ and $m = 306$. Therefore: $Pn205 = m - 1 = 305$. With these settings, executing **MOVE(180)** moves the moving part 180 tenths of an angle degree or 18 angle degrees in forward direction.


Example 5

The mechanical system uses a servo motor with a 17-bit absolute encoder. The mechanical gear ratio of the gearbox is 1:10. The pulley has got 12 teeth, and each two are 50 mm apart. One complete turn of the pulley equals 144 stations on the main wheel. The distance between two stations is 50 mm. The mechanical measurement units must mm. Total repeat distance must be the distance between two stations, 50mm.

With the same procedure as in example 1, we have:

$$\frac{Pn202}{Pn203} \text{ UNITS} =$$

$$\frac{2^{17} \cdot \text{encoder_counts}}{1 \cdot \text{motor_revolution}} \cdot \frac{10 \cdot \text{motor_revolution}}{1 \cdot \text{pulley_revolution}} \cdot \frac{1 \cdot \text{pulley_revolution}}{12 \cdot \text{station}} \cdot \frac{1 \cdot \text{station}}{50 \text{mm}} = \\ = \frac{2^{17} \cdot 10}{12 \cdot 50} \frac{\text{encoder_counts}}{\text{mm}}$$



Therefore, if we use the mechanical system to set the electronic gear ratio, we have:

$$\text{UNITS } \frac{Pn202}{Pn203} = \frac{2^{17}}{50} \frac{10}{12}$$

One possible solution is:

$$\text{UNITS} = \frac{2^{17}}{50}$$

$$\begin{aligned} Pn202 &= 5 \\ Pn203 &= 6 \\ Pn205 &= 4 \end{aligned}$$

Because $2^{17}/50$ is a number with an infinite number of decimal digits, we can choose the following:

$$\text{UNITS} \frac{\text{Pn202}}{\text{Pn203}} = 2^{17} \frac{10}{50 \cdot 12} = 2^{17} \frac{10}{600} = 2^{17} \frac{1}{60} = 2^{17} \frac{1}{2^2 \cdot 15} = 2^{15} \frac{1}{15}$$

Therefore, the parameters are:

$$\begin{aligned}\text{UNITS} &= 2^{15} = 32768 \\ \text{Pn202} &= 1 \\ \text{Pn203} &= 15 \\ \text{Pn205} &= 4 \\ \text{REP_DIST} &= 50 \\ \text{REP_OPTION} &= 1\end{aligned}$$

With these settings, executing **MOVE(50)** moves the moving part 50 mm, or one station.

Example 6

The mechanical system consists of a ball screw. It uses a servo motor with a 17-bit absolute encoder. The mechanical gear ratio of the gearbox is 1:3. The screw pitch of the ball screw is 10mm per revolution. The total travel distance of the ball screw is 540 mm. The mechanical measurement units must be mm.


With the same procedure as in example 1, we have:

$$\begin{aligned}\frac{\text{Pn202}}{\text{Pn203}} \text{ UNITS} &= \frac{2^{17} \cdot \text{encoder_counts}}{1 \cdot \text{motor_revolution}} \frac{3 \cdot \text{motor_revolution}}{1 \cdot \text{ballscrew_revolution}} \frac{1 \cdot \text{ballscrew_revolution}}{10 \text{mm}} = \\ &= \frac{2^{17} \cdot 3}{10} \frac{\text{encoder_counts}}{\text{mm}}\end{aligned}$$

Therefore:

$$\frac{\text{Pn202}}{\text{Pn203}} \text{ UNITS} = 2^{17} \frac{3}{10} = 2^{17} \frac{3}{2 \cdot 5} = 2^{16} \frac{3}{5}$$

One solution is:



UNITS = 2^{16} = 65536

Pn202 = 3

Pn203 = 5

The calculation of the multiturn limit setting parameter Pn205 is not needed in this case because the ball screw is a system with a fixed (limited) axis. It is enough to set this value large enough to have the overflow of the counter out of the effective position. Also, because of the axis is finite, it is not important to set the **REP_OPTION** parameter, because **REP_DIST** must be set large enough so it is outside of the maximum effective position (540 mm). One solution is: **REP_DIST** = 1000 and **REP_OPTION** = 0.

With these setting, executing **MOVE(17)** moves the ball screw 17 mm in forward direction.

6.1.4 Mapping Servo Driver inputs and outputs



Caution

Mapping Servo Driver inputs and outputs is changed in Trajexia firmware version V1.6652. The differences with previous firmware versions are listed below for each supported Servo Driver.

- Sigma-II
Backwards compatible. Only virtual inputs 28 (IO12) to 31 (IO15) were allowed in previous versions.
- Sigma-V
Was not supported in previous versions.
- Junma
Not backwards compatible, because the /DEC signal is now mapped to IN18. In previous versions the /DEC signal is mapped to IN26.

The Trajexia controller has got a digital I/O space that consists of 256 digital inputs and 256 digital outputs.

The digital outputs range has four parts:

- Digital outputs 0 - 7.
These outputs do not physically exist on the TJ1-MC__. If you write these outputs, nothing happens. If you read these outputs, they return 0.
- Digital outputs 8 - 15.
These outputs physically exist on the TJ1-MC__. You can physically access them on the 28-pin screwless connector on the front side of the TJ1-MC__ (see the Hardware Reference Manual for details). If you write these outputs, they become active and give a 24 VDC signal. If you read these outputs, they return their current status. Use the command **OP** to write and read these outputs.
- Digital outputs 16 - 31.

These outputs are software outputs only. They do not physically exist on the TJ1-MC__, but you can write them and read their correct status. You use these outputs mostly in BASIC programs to accomplish some control sequences that require outputs which do not need to be physical. Use the command **OP** to write and read these outputs.

- Digital outputs 32 - 255.

These outputs are physically present only if additional digital I/O units are connected to the TJ1-MC__ via MECHATROLINK-II bus. Writing and reading them if they do not physically exist (when the I/O units are not connected) has no effect. Use the command **OP** to write and read these outputs.

All outputs are unique to the controller. They are not accessed per axis.

The digital input range has three parts:

- Digital inputs 0 - 15.
These inputs physically exist on the TJ1-MC__. You can physically access them on the 28-pin screwless connector on the front side of the TJ1-MC__ (see the Hardware Reference Manual for details). These inputs are active (ON) when a 24 VDC signal is applied to them. When you read them, they return their current status. Use the command **IN** to read these inputs.
- Digital inputs 16 - 31.
These outputs are software inputs only. They do not physically exist on the TJ1-MC__, but you can read them. You use them mostly in BASIC programs to accomplish some control sequences that require inputs which do not need to be physical. Use the command **IN** to read these inputs.
- Digital inputs 32 - 255.
These inputs are physically present only if additional digital I/O units are connected to the TJ1-MC__ via the MECHATROLINK-II bus. If you read them if they do not physically exist (the I/O units are not connected), they return 0. Use the command **IN** to read these inputs.

All inputs are unique to the controller. They are not accessed per axis.

MECHATROLINK-II Servo Drivers inputs in the Trajexia I/O space

With the BASIC command **IN**, you can access the physically present inputs in a BASIC program. These inputs can be built in the controller or connected via the MECHATROLINK-II bus.

Servo Drivers can have additional inputs that are located on their I/O connectors. These inputs can be used as forward and/or reverse limit switches or origin switches. They are mapped into the Trajexia I/O space. Thus, they can be accessed from BASIC programs. Trajexia only supports this for Servo Drivers connected to the Trajexia system via the MECHATROLINK-II bus. It is not supported for Flexible Axis Servo Drivers.

Trajexia input	Servo Driver input signal			Description
	Sigma-II	Sigma-V	Junma	
16	P_OT	P_OT	P_OT	Forward limit switch
17	N_OT	N_OT	N_OT	Reverse limit switch
18	DEC	DEC	/DEC	Zero point return deceleration
19	PA	PA	Not used	Encoder A phase signal
20	PB	PB	Not used	Encoder B phase signal
21	PC	PC	Not used	Encoder C phase signal
22	EXT1	EXT1	/EXT1	First external latch signal
23	EXT2	EXT2	Not used	Second external latch signal
24	EXT3	EXT3	Not used	Third external latch signal
25	BRK	BRK	/BRK	Brake output
26	Reserved	HBB	E-STP	Emergency stop switch
27	Reserved	Reserved	Not used	
28	IO12	IO12	Not used	Not used
29	IO13	IO13	Not used	Not used
30	IO14	IO14	Not used	Not used
31	IO15	IO15	Not used	Not used

The inputs in the table above are located on the CN1 I/O connector of the respective Servo Driver. The pin arrangement of this connector is different for the respective Servo Drivers. For the Sigma-II and Sigma-V Servo Drivers, the input signals P_OT, N_OT, DEC, EXT1, EXT2, EXT3, BRK, IO12, IO13, IO14 and IO15 can be mapped to pins of the CN1 I/O connector. To do this, you must set the appropriate parameter of the Servo Driver. The table below shows the possible settings and parameter values.

Input signal - Parameter name	Parameter setting	CN1 pin number	
		Sigma-II	Sigma-V
P_OT (active high) - Pn50A.3 N_OT (active high) - Pn50B.0 DEC (active high) - Pn511.0	0	40 (SI0)	13 (SI0)
	1	41 (SI1)	7 (SI1)
	2	42 (SI2)	8 (SI2)
	3	43 (SI3)	9 (SI3)
	4	44 (SI4)	10 (SI4)
	5	45 (SI5)	11 (SI5)
	6	46 (SI6)	12 (SI6)
	7	Always ON	
/P_OT (active low) - Pn50A.3 /N_OT (active low) - Pn50B.0 /DEC (active low) - Pn511.0	8	Always OFF	
	9	40 (SI0)	13 (SI0)
	A	41 (SI1)	7 (SI1)
	B	42 (SI2)	8 (SI2)
	C	43 (SI3)	9 (SI3)
	D	44 (SI4)	10 (SI4)
	E	45 (SI5)	11 (SI5)
	F	46 (SI6)	12 (SI6)

Input signal - Parameter name	Parameter setting	CN1 pin number	
		Sigma-II	Sigma-V
/EXT1 (active low) - Pn511.1 /EXT2 (active low) - Pn511.2 /EXT3 (active low) - Pn511.3	0-3	Always OFF	
	4	44 (SI4)	10 (SI4)
	5	45 (SI5)	11 (SI5)
	6	46 (SI6)	12 (SI6)
	7	Always ON	
	8, 9-C	Always OFF	
EXT1 (active high) - Pn511.1 EXT2 (active high) - Pn511.2 EXT3 (active high) - Pn511.3	D	44 (SI4)	10 (SI4)
	E	45 (SI5)	11 (SI5)
	F	46 (SI6)	12 (SI6)
/BRK (active low) - Pn50F.2	0	Always OFF	
	1	25	1
	2	27	23
	3	29	25
IO12 - Pn81E.0 IO13 - Pn81E.1 IO14 - Pn81E.2 IO15 - Pn81E.3	0	Always OFF	
	1	40 (SI0)	13 (SI0)
	2	41 (SI1)	7 (SI1)
	3	42 (SI2)	8 (SI2)
	4	43 (SI3)	9 (SI3)
	5	44 (SI4)	10 (SI4)
	6	45 (SI5)	11 (SI5)
	7	46 (SI6)	12 (SI6)

For the Junma Servo Driver, all input signals are mapped to a fixed location on the CN1 I/O connector. The table below shows the input signals and pin numbers.

Input signal	CN1 pin number
P_OT (active high)	4
N_OT (active high)	3
DEC (active low)	1
EXT1 (active low)	2
BRK (active low)	13
E-STP (active high)	6

For more information on the CN1 I/O connector pins on the Servo Drivers, refer to the Sigma-II Servo Driver manual, the Sigma-V Servo Driver manual, and the Junma series Servo Driver manual.

Servo Driver inputs that are mapped into the Trajexia I/O space like this are accessed within the program per axis and cannot be accessed in the usual way with the **IN** command. The only way you can use these inputs in the program is to assign them to the axis parameters **DATUM_IN**, **FHOLD_IN**, **FWD_IN** and **REV_IN**. The inputs of the axis Servo Driver are used, depending on the axis of which the parameters are set.

Example: We have a Sigma-II and a Junma driver assigned to controller axes 0 and 3. For the Sigma-II driver, we want to use input signal EXT1 (mapped to CN1-44 if Pn511.2 is set to 4) to serve as reverse limit input for axis 0. For the Junma driver, we want to use input signal EXT1 (CN1-2) as reverse limit for axis 3. We can do this with these commands:

REV_IN AXIS(0) = 22
REV_IN AXIS(3) = 22

Note that even though **REV_IN** parameters for both axes have the same value, the real inputs used are not the same. For axis 0 the input on CN1-44 of the Sigma-II driver (assigned to axis 0) is used, but for axis 3 the input on CN1-41 of the Junma driver (assigned to axis 3) is used. Therefore we say that those inputs are accessed per axis, they are not unique for the whole controller. In general, these two inputs have a different status at the same

time. Also note that neither of these two inputs can be accessed using the command **IN**. For example the command **IN(22)** returns the status of controller software input 22 (unique for all axes), which has a different status than Servo Driver inputs mapped to the same number. However, the command **INVERT_IN(22)** inverts the status of input 22 read by the controller. It affects not only the unique software input 22, which is accessible with the **IN** command, but all axis-specific inputs 22, which in this example are the EXT1 inputs of the connected Servo Drivers.



Note

If a forward limit, reverse limit and origin input signal are used for an axis, it is strongly recommended to use the following settings for the axis:

BASE(axis_number)

DAT_IN=18

' /DEC input in the corresponding Servo Driver is
' assigned

FWD_IN=16

INVERT_IN(16,ON)

' P_OT input in the corresponding Servo Driver is
' assigned. It is necessary to invert the signal
' because a Normally Closed input is expected.

REV_IN=17

INVERT_IN(17,ON)

' N_OT input in the corresponding Servo Driver is
' assigned. It is necessary to invert the signal
' because a Normally Closed input is expected

Also note that **INVERT_IN** inverts the selected input in all axes.

6.1.5 Origin search

The origin search or homing functionality is often seen as a particular sequence of movements of an axis at the start-up phase of the machine. This sequence is done automatically in most cases, without the input from

the operator of the machine. In general, an origin search procedure couples a position to a specific axis. It depends on the encoders used (absolute or relative), on the system used (linear or circular), and on the mechanical construction of the machine. Absolute encoders do not need a movement during the origin search procedure, because the exact positions are transferred directly to the system. For other encoder types, a movement is necessary, since there is no knowledge of the exact position within the system. Basically, this movement is at low speed in some direction until a certain measuring point is reached. Such a measuring point can be scanned from both directions to increase the precision.

At startup, the current positions of the axes using incremental encoders are 0. Because these positions do not match with the mechanical 0 of the machine, it is necessary to execute the homing sequence. If an absolute encoder is used, the absolute position is read at startup from the encoder and homing is not necessary. In this case, a startup sequence must be executed one time during the machine commissioning.

In practice there are several different origin search sequences. They are different in these areas:

- The means used to detect limit positions of the moving part (sensors, switches, etc.)
- Origin (home) position or reference.
- Possible positions of the moving part related to limit positions and origin position.

Trajexia includes some pre-defined basic homing sequences:

- **DATUM(0)**
This is not really an origin search. This command sets **DPOS=MPOS** and cancels the axis errors.
- **DATUM(1)**
This does an origin search in forward direction using the Z mark of an encoder as homing switch.
- **DATUM(2)**
Does an origin search in reverse direction using the Z mark of an encoder as homing switch.
- **DATUM(3)**
Does an origin search in forward direction using the input selected in **DATUM_IN** as homing switch.

- **DATUM(4)**
Does an origin search in reverse direction using the input selected in **DATUM_IN** as homing switch.
- **DATUM(5)**
Does an origin search in forward direction using the input selected in **DATUM_IN** as homing switch and searches the next Z mark of an encoder.
- **DATUM(6)**
Does an origin search in reverse direction using the input selected in **DATUM_IN** as homing switch and searches the next Z mark of an encoder.

For more details on these pre-defined homing sequences, see section 3.2.72.

In some situations, more complex homing sequences are required:

- Absolute switch origin search plus limit switches.
- Origin search against limit switches.
- Origin search against hardware parts blocking movement.
- Origin search using encoder reference pulse "Zero Mark".
- Static origin search, forcing a position from a user reference.
- Static origin search, forcing a position from an absolute encoder.

The figure shows a general origin search scenario. This simple origin search sequence has 3 steps:


1. Search for a signal.
2. Search for another signal.
3. Move the axis to a predefined position.



Note

For safety reasons, limit switches are normally closed. For this reason, in this figure and in the following figures in this section, the low signal level is indicated as ON, and the high signal level is indicated as OFF.

fig. 25



It is important to note that, before any homing procedure is executed, it is necessary to set the axis parameters **UNITS**, **REP_DIST** and **REP_OPTION**, and Servo Driver parameters Pn202, Pn203 and Pn205 properly and in accordance with the mechanical system and desired measurement units used in programming. Those parameters have influence to the origin search, especially if an absolute encoder is used. For more information on setting these parameters, see section 6.1.2.



Absolute switch origin search plus limit switches

The origin search function is performed by searching for an external limit switch that is positioned absolutely and the position of which defines the origin position. The example for this homing procedure is shown in the figure.

The figure shows the possible scenarios for absolute origin search plus limit switches. These scenarios depend on the position of the moving part when the power comes on.

The program example that does this origin search sequence is given below.

```
'Absolute origin switch: IN0
'Left limit switch: IN1
'Right limit switch: IN2
BASE(0)
DATUM_IN=0
FW_IN=2
RV_IN=1
SERVO=ON
WDOG=ON
DATUM(4)
```




```
WA(1)
WAIT UNTIL MTYPE=0 OR IN(1)=OFF
IF IN(1)=ON
    FORWARD
    WAIT UNTIL IN(0)=ON
    WAIT UNTIL IN(0)=OFF
    CANCEL
    DATUM(4)
    WA(1)
    WAIT IDLE
ENDIF
```

Origin search against limit switches

This origin search function is performed by searching for an external sensor using limit switches only. The example for this homing procedure is shown in the figure.

fig. 28



The possible scenarios for origin search against limit switches, depending on the position of the moving part on power on, are shown in the figure. The program example that does this origin search sequence is given below.

```
'Origin and left limit switch: IN0
'Right limit switch: IN1
BASE(0)
DATUM_IN=0
SERVO=ON
WDOG=ON
DATUM(4)
WA(1)
WAIT IDLE
```

Origin search against hardware parts blocking movement

This origin search procedure performs origin search against a physical object and mechanically blocks the movement. There are no limit switches, no absolute position switch and no reference pulses. The origin position is detected by detecting a particular amount of torque against the blocking objects. An adequate torque limit is required in order not to damage the mechanics during the origin search process. The example for this homing procedure is shown in the figure.

The program example that does this origin search sequence is given below.

```
BASE(0)
DRIVE_CONTROL=11 'Monitor torque with DRIVE_MONITOR
SERVO=ON
WDOG=ON
SPEED=CREEP
REVERSE
WA(1)
WAIT UNTIL DRIVE_MONITOR < -100
    'Wait for particular amount of applied torque
CANCEL
DEFPOS(0)
MOVEABS(10) 'This is necessary, otherwise the position
            'is kept pushing the hardware limit of the
```

fig. 29





fig. 30



'machine and the motor trips by overload

Origin search using encoder reference pulse "Zero Mark"

This origin search procedure performs origin search by searching for the "Zero Mark" signal of the encoder. This signal is also known as "marker" or "reference pulse". It appears one time per full encoder revolution. The example for this homing procedure is shown in the figure.

The possible scenarios for origin search using encoder reference pulse "Zero Mark", depending on the position of the moving part on power on, are shown in the figure.

The program example that does this origin search sequence is given below.

```
'Origin and left limit switch: IN0
'Right limit switch: IN1
REV_IN=-1
BASE(0)
DATUM_IN=0
SERVO=ON
WDOG=ON
DATUM(6)
WA(1)
WAIT IDLE
```

Static origin search, forcing a position from a user reference

This origin search procedure performs a static origin search by directly forcing an actual position. It does not perform any physical move.

```
DATUM(0)
```

fig. 31





fig. 32



Static origin search, forcing a position from an absolute encoder

This origin search procedure sets the actual position to the position of an absolute encoder. It does not perform any physical move. It is only possible with an axis with an absolute encoder in a control loop.

6.1.6 Registration

Registration, also called ‘latch’ or ‘print registration’, is about real-time storing of the position of an axis when an external input is activated. The information that is registered, i.e. stored, is processed later, not in real time, by the application program.

Registration is different from processing an interrupt input or signal. With registration, no event is generated when the registration input is activated. Also, the normal execution of the application program is not disturbed or interrupted. Only the position of an axis is stored. This information can be used, like other parameters or values, in a program. The registration information is available to a program immediately after the registration.

The advantage of registration is that it is done very quickly. Therefore, the axis position that is stored is very accurate. To achieve this speed and accuracy, registration is implemented with hardware, and the registration input must be on the same board as the encoder input that provides information on the axis position.

Capturing and storing the axis position is done in real time by the hardware. Processing this information is done not in real time by the application program.

The REGIST axis command

In Trajexia, you do a registration with the **REGIST** axis command. This command takes one argument. This argument determines which external input is registered, whether the registration is executed on the rising edge or on the falling edge of the input signal, whether the windowing function is used, and other options. For more information on the **REGIST** command, refer to section 3.2.224.

The registration differs for different axes depending on their connection to the system. If an axis is connected via the MECHATROLINK-II bus, the registration is done in the Servo Driver hardware. If an axis is connected via the Servo Driver analog interface and the TJ1-FL02, the registration is done in the hardware of the TJ1-FL02.

The different registrations are described below.

Registration in the Sigma-II and Sigma-V Servo Driver

Registration in the Sigma-II and Sigma-V Servo Driver occurs when an axis assigned to this Servo Driver is connected to the Trajexia system via the MECHATROLINK-II bus. There are three registration inputs on these Servo Drivers, but only one hardware latch, so only one input can be used at a time. For Sigma-II Servo Drivers the physical inputs are in pins CN1-44, CN1-45 and CN1-46 on the 50-pins CN1 connector. For Sigma-V Servo Drivers the physical inputs are in pins CN1-10, CN1-11 and CN1-12 on the 26-pins CN1 connector. Trajexia uses logical inputs EXT1, EXT2 and EXT3 to associate the physical inputs to logical ones. This association is done by setting the parameter Pn511 of the Servo Driver. For more information on setting this association and Pn511 parameter, refer to section 3.2.224, table 1. The input used for registration is determined by the argument of the **REGIST** command.


The delay in the capture in the Sigma-II Servo Driver is about 3 μ s. As the encoder information is refreshed every 62.5 μ s, it is necessary to make interpolation to obtain the right captured position value (see the picture). Since the motor speed cannot change much during 62.5 μ s, the resulting accuracy is very high.

The delays in transmission of the information are:

- Delay in triggering the registration: 0.625 ms to 4 ms.
- Delay in receiving the registration: 3.5 ms.
- Delay in capturing the registration: 3 μ s.

It is also possible to use the encoder Z-mark to register an axis position. This is also done with the argument of the **REGIST** command.

fig. 33



Registration in the Junma Servo Driver

Registration in the Junma Servo Driver is the same as registration in the Sigma-II Servo Driver, with one difference: There is only one physical input and one logical latch too, so no settings of Servo Driver parameters are necessary. The physical input is associated to logical latch EXT1, and only the rising signal edge can be used for registration.

Registration in the TJ1-FL02

The TJ1-FL02 has two physical registration inputs, and two latch circuits per encoder input, which can be used independently. Therefore two independent registration inputs can be used at the same time. For more information on how to use both registration inputs of the TJ1-FL02 at the same time, refer to sections 3.2.174, 3.2.175, 3.2.222, 3.2.223 and 3.2.224.

The delay in the capture is 0.5 µs. Because the encoder position is read continuously from the line-drive encoder input, interpolation is not necessary. The delay for the transmission of the captured information is just one **SERVO_PERIOD** cycle.

Using registration in application programs

There is one axis command (**REGIST**), and two axis parameters (**MARK** and **REG_POS**). With these commands and parameter, you can control and use the registration functionality in BASIC programs.

- **REGIST** captures the axis position when a registration signal is detected. The available settings depend on the axis type. Refer to section 3.2.224.
- **MARK** is a flag that signals whether the position has been captured or not. For the second registration input of the TJ1-FL02, the parameter **MARKB** is also available. For more information, refer to sections 3.2.174 and 3.2.175.
- **REG_POS** holds the captured axis position. Only if the **MARK** flag signals that the position was captured successfully, you can regard the **REG_POS** value as valid. For the second registration input of the TJ1-FL02, the parameter **REG_POSB** is also available. For more information, refer to sections 3.2.222 and 3.2.223.

The picture gives the sequence of executing the commands and the registrations of the sample program below.

```

BASE(N)
REGIST(0)
WAIT UNTIL MARK=0
loop:
    WAIT UNTIL MARK=-1
    PRINT "Position captured in: "; REG_POS
    REGIST(0)
    WAIT UNTIL MARK=0
GOTO loop

```

Registration and windowing function

The windowing function enables for registration to occur only within a specified range of axis positions. This function is selected by giving the right value as an argument for the **REGIST** command. The windowing function is controlled by two axis parameters, **OPEN_WIN** and **CLOSE_WIN**. For more information on **REGIST**, **OPEN_WIN** and **CLOSE_WIN**, refer to sections 3.2.53, 3.2.202 and 3.2.224.

There are two types of windowing:

- Inclusive windowing allows the registration to occur only within the specified window of axis positions. With this windowing function, registration events are ignored if the axis measured position is less than the **OPEN_WIN** axis parameter or greater than the **CLOSE_WIN** parameter.
- Exclusive windowing allows the registration to occur only outside the specified window of axis positions. With this windowing function, the registration events are ignored if the axis measured position is greater than the **OPEN_WIN** axis parameter or less than the **CLOSE_WIN** parameter.

When the windowing function is used, the internal process is as follows:

1. **REGIST** + window is executed in the program.
2. **MARK = 0** and the latch is triggered.

fig. 34





fig. 35



3. The position is captured and transmitted to the Trajexia processor.
4. Is the captured position inside the inclusive window or outside the exclusive window?
 - If yes, **MARK** = -1 and **REG_POS** is updated.
 - If not, return to point 2 (trigger the latch again transparently to the user).


The figure shows the sequence of execution of the above commands and the occurrence of registration events when you use inclusive windowing.

There are delays between these events:

- Trajexia receives the latch.
- Trajexia decides to trigger the latch again.
- The latch is triggered.

Because of these delays, there is an uncertainty in the edges of the window when marks may be detected near the edges. This is more notable for axes connected to the system via the MECHATROLINK-II bus due to bus delays. To compensate for these delays, a user must set the window margins large enough.


fig. 36



Example: Correcting the position of an axis

The picture shows the vertical fill and seal machine for packaging products into bags. The bag material comes from a plastic film coil that is unwound, then it is shaped into the tube by a mechanical mandrel and at the same time the tube is sealed vertically. The feeder movement is intermittent and the feed length corresponds with the bag length. Once the bag is fed, the horizontal sealer closes the bag, so it can be filled with the product. After that, the process starts again, feeding the new bag.

fig. 37



Examples and tips

The feeder can work in two modes: without registration mark; and with registration mark. Working without the registration mark is a simple point-to-point incremental movement. In this case, there is no guarantee that the feeder moves exactly the same distance as the design pattern. For example, suppose the bag length that needs to be fed is 200 mm, but the real pattern is 200.1 mm. With simple point-to-point incremental movement without correction, an error of 0.1 mm per bag is accumulated. With a small number of bags the difference is not visible, but after 500 bags the error is 50 mm, which is a 25% of the bag length.

When working with registration marks, the motion controller executes an incremental movement to a certain position. If during the positioning the registration mark is detected, the target position is changed on the fly in order to finish the movement at a defined position after the registration mark. Therefore, the same distance in respect to the registration mark is always guaranteed.

fig. 38





fig. 39



The motion profile and its modification due to the registration mark are shown in fig. 39.

The BASIC program for this example is:

```

DEFPOS (0)
REGIST(3)          'Trigger the mark registration
MOVE(bag_length)   'Move to the theoretical distance
WA(1)
WAIT UNTIL MARK OR MTYPE=0
IF MARK THEN
    end_position=REG_POS+distance_after_mark
    MOVEMODIFY(end_position)
    'Correct the distance according to the mark
ENDIF

```

Example: Starting a slave axis in precise position of a master axis

The picture shows a flying shear cutting the "head" of wood tables. When the wood comes, the edge of the wood is detected by the photocell and, at the exact moment, the movement of the flying shear starts to be synchronized with the right position on the wood.

If the movement is started by the program, upon detecting a signal from the photocell, there is always at least one **SERVO_PERIOD** of time of uncertainty. Instead, the movement is started using the **MOVELINK** command with **link_option=1**, which means that the link to the master axis starts when the registration event occurs on link (master) axis.

The corresponding program sequence is:

```

REGIST(2) AXIS(master)
MOVELINK(dst,lnk_dst,lnk_acc,lnk_dec,master,1) AXIS(slave)
For more information on the MOVELINK command and the link_option
argument, refer to section 3.2.184.

```

fig. 40






fig. 41



The picture shows how the position of the slave axis is corrected using the registration event on the master axis to start the movement of the slave axis. The influence of **SERVO_PERIOD** and the fact that the registration event can happen at any time inside the **SERVO_PERIOD** is completely eliminated.

fig. 42



6.1.7 Tracing and monitoring

Oscilloscope functionality in Trajexia Tools

The software oscilloscope is a standard part of Trajexia Tools. The oscilloscope can be used to trace and graphically represent axis and system parameters. This can help you with development, commissioning and troubleshooting of the motion system. For more information on the software oscilloscope and its features and capabilities, refer to section 5.5.4.

You can trigger the oscilloscope to start tracing given axis and system parameters in two ways: manually or by a program. Triggering manually is done using the oscilloscope tool. The parameters are stored in the Table memory of the controller. The range of the Table memory where the parameters are stored can be set from the **Oscilloscope Configuration** window (see section 5.5.4). With manual triggering, the user can see the changes of axis and system parameters in real time, as the system runs. A change in parameter values is graphically represented as soon as the change happens. The limitation of manual triggering is that it requires user

interaction, which means that the start of tracing is not synchronized with the movement that is analyzed. Also, with manual triggering the tracing range is limited to 200 samples per channel.

Using the oscilloscope

The alternative, triggering by a program, does not have the limitations of manual triggering of the tracing. Triggering by a program stores the axis and system parameters in the memory of the TJ1-MC__. Later, the parameters are given to the oscilloscope for graphical representation. The axis and system parameters are stored in the Table memory. The memory range used is defined by the parameters of the **SCOPE** command. When the parameters are in the Table memory, the oscilloscope can be configured to show a range of Table memory locations instead of axis and system parameters. The exact moment when the tracing is started can be exactly determined because it is controlled by the **TRIGGER** command. This means the start of tracing is synchronized with the movement. There is no limitation of 200 samples per channel, the oscilloscope shows as many samples (Table entries) as configured in the **Oscilloscope Configuration** window.


Example

This section gives you a practical example on the use of the **SCOPE** and **TRIGGER** commands, and how to use them in combination with the oscilloscope to monitor axis parameters and troubleshoot the system. For more information on the **SCOPE** and **TRIGGER** commands, refer to sections 3.2.242 and 3.2.271.

Suppose the motion system consists of two axis, **AXIS(0)** and **AXIS(1)**. **AXIS(0)** is the master axis. It makes a simple forward movement. **AXIS(1)** is the slave axis. It must follow the master axis in accordance to cosine rule:

$$x_1 = \text{end_pos} \cdot \frac{1}{2} \left(1 - \cos \left(\frac{2\pi \cdot x_0}{999} \right) \right)$$

where x_0 is the position of the master **AXIS(0)**, and x_1 is the position of the slave **AXIS(1)**. You can link the two axis with the **CAMBOX** command. For more details, refer to section 3.2.45. Suppose furthermore that the



parameter **end_pos** is not constant, but it can change due to different conditions of the motion system. The part of the program that creates the CAM table is:

```
'Initial CAM values
VR(end_pos)=15
current_end_pos=VR(end_pos)
FOR i=0 TO 999
    TABLE(i, VR(end_pos)*(1-COS(2*PI*i/999))/2)
NEXT i
...
loop:
IF VR(end_pos)<>current_end_pos THEN
'Recalculate the CAM Table
    FOR i=0 TO 999
        TABLE(i, VR(end_pos)*(1-COS(2*PI*i/999))/2)
    NEXT i
    current_end_pos=VR(end_pos)
ENDIF
...
GOTO loop
```

The **VR(end_pos)** value can be changed from some other program or externally from another controller using FINS messaging. In this case, the **CAM** table must be recalculated.

The creation of the CAM table is complete. The initialization of the desired axis and system parameters for tracing is:

```
'Initializations
FOR i=0 TO 1
    BASE(i)
    ATYPE=40
    UNITS=8192
    REP_DIST=20
    REP_OPTION=1
    FE_LIMIT=1
    DRIVE_CONTROL=11
```

```
SPEED=8
ACCEL=50
DECEL=50
DEFPOS(0)
SERVO=ON
CANCEL

NEXT i
WDOG=ON
BASE(1)

'Scope settings:
'1 sample each 2 servo cycles
'Information stored in TABLE(1000) to TABLE(4999)
'Because we capture 4 channels, we have 1000 samples per channel.
'MPOS AXIS(0) is stored in TABLE(1000) to TABLE(1999)
'DPOS AXIS(1) is stored in TABLE(2000) to TABLE(2999)
'Torque reference for AXIS(1) is stored in
'TABLE(3000) to TABLE(3999)
'MSPEED AXIS(1) is stored in TABLE(4000) to TABLE(4999)
'The capture covers 1000 samples * 2ms / sample = 2seconds
SCOPE(ON,2,1000,4999,MPOS AXIS(0),DPOS,DRIVE_MONITOR,MSPEED)
FORWARD AXIS(0) 'Move the master axis forward
TRIGGER 'Start tracing and storing of parameters
WHILE NOT MOTION_ERROR
    'Cambox that will start in AXIS(0) position 1
    CAMBOX(0,999,UNITS,10,0,2,1)
    WAIT UNTIL MPOS AXIS(0)<1
    'The capture will start when the master axis is in
    'a position Between 0 and 1. Additional conditions
    'are:
    '- The previous capture has finished
    '(SCOPE_POS=1000)
    '- We have the permission (VR(activate_trigger)=ON)
IF SCOPE_POS=1000 AND VR(activate_trigger)=ON THEN
    TRIGGER
    PRINT "Triggered"
ENDIF
WAIT IDLE
```

WEND
HALT

To view the capture result in the oscilloscope of Trajexia Tools, you must make the settings in the **Oscilloscope Configuration** window as given in the figure.

You must also disable further capturing to avoid mixing the results of two different captures in the same Table memory entries.

The capture result is given in the figure.

In the example given above, the value of the **UNITS** parameter is set to encoder counts. The position of the master axis **MPOS AXIS(0)** is given in red (Table Block 0, Table(1000) to Table(1999), see the settings in the **Oscilloscope Configuration** window). The position increases linearly, because the speed of the master axis is constant.

The demanded position of the slave axis **DPOS AXIS(1)** is given in blue (Table Block 1, Table(2000) to Table(2999), see the settings in the **Oscilloscope Configuration** window). This graph is a cosine curve. It corresponds to the created CAM table.

The measured speed of the slave axis **MSPEED AXIS(1)** is given in yellow (Table Block 3, Table(4000) to Table(4999), see the settings in the **Oscilloscope Configuration** window). This graph is a sinusoidal curve, because the speed is a derivative of the position, and the derivative of the cosine is the sine. At high speeds, there are some ripples.

fig. 44





fig. 45



The green graph is the torque of the motor for the slave axis set with **DRIVE_COMMAND=11** as a percentage of the nominal torque. The torque is proportional to the acceleration. Because the acceleration is a derivative of the speed and the speed is sinusoidal curve, the acceleration (and also the torque) is a cosine curve. There is one peak at the start and another peak at the stop because there is a discontinuity in the acceleration. There is also a high frequency oscillation in the torque curve, suggesting a resonance frequency that can be eliminated using the notch filter settings in the Sigma-II Servo Driver. The high frequency is reinforced, because it is also reflected in the speed curve. For more information on notch-filter settings, refer to the Sigma-II Servo Driver manual.

Troubleshooting with the oscilloscope

When the desired data is captured and recorded into the Table memory entries, you can use the oscilloscope to visualize this data. This can help you when you commission and troubleshoot the system. This section gives an example of how a bug, which is difficult to analyze, can be clearly explained and solved using the captured data and the oscilloscope.

The parameter **end_pos**, which defines the values in the CAM table, depends on external conditions of the system. Therefore a program that runs in another task or even a controlling device using FINS communication, can change it while the main program that links two axis runs. Suppose that these changes in conditions, which result in a change of the **end_pos** parameter, happen most of the time when the axes are not linked, i.e. when the **CAMBOX** command is not executed. Suppose furthermore that very rarely the condition changes when the axes are linked. The change of the **end_pos** parameter triggers the recalculation of the CAM table while the **CAMBOX** command is executed. The consequence is that the part of the demanded position of the slave axis follows the profile before the change, and the other part follows the profile after the change. In the end this leads to a discontinuation of the profile, which causes an indefinite speed of the axis and ends up with this error: the WDOG goes off, and all axes stop.

The scenario above is hard to analyze when you do not know what happens. The only thing that the user sees is that the slave axis has an error once every few hours or even less often. But the oscilloscope can clearly show where the problem is. In order to be able to use the oscilloscope, all desired

parameters must be captured at the time of an error. This can be achieved by arranging the application programs in a certain way. The good programming practice suggests to have a separate start-up program that is set to run automatically on power-up of the system and checks the integrity of the system, whether all the expected devices are connected and initialized. For an example of a start-up program see section 6.1.1. It is recommended to let the start-up program, when it is finished, start only one program that takes care of the safety and integrity of the application and execution of all other application programs. This program is usually referred to as a SHELL program. For more information on designing a SHELL program, see section 6.2.1.

Suppose that program is designed in a way the it contains a following fraction of code:


```
'When there is an error, we stop all programs. No new
'oscilloscope captures are done. And we have stored in
'the selected TABLES the last data trace in which the
'error has occurred. Therefore, we can recover this
'trace and analyze it.
```

```
loop:
    IF MOTION_ERROR<>0 THEN HALT
    GOTO loop
```

This programming code causes all the programs and tracing to stop when an error happens on any axis. The data is already captured in the Table memory, and we can start using the oscilloscope to see the status of the desired parameters at the moment the error occurred. Following the scenario described above, with the oscilloscope settings as in fig. 44, the result is given in fig. 46.

The measured position of the master axis, given in red, does not seem to be the cause, because there is no discontinuity on it. We discard a mechanical problem as well, because the torque, given in green, has low values. An the moment of the problem the speed of the slave axis, given in yellow, was smooth and low, therefore this is no problem either.

fig. 46



The next step is to analyze the CAM table, to see which values were used for demanding the position of the slave axis. To do that, we change the oscilloscope configuration to show a block of values from Table(0) to Table(999) in red, because these Table memory entries are where the CAM table is created (see the part of the program that creates the CAM table above). The changed configuration is shown in the figure.

fig. 47





fig. 48



The result is given in the figure. The red graph clearly shows a discontinuity in the position values that the slave axis must follow. Because the speed is a derivative of the position, at the point of discontinuity of the position curve the speed gets a high value. (This value equals infinity in theory, in practice the value is just very big). This causes the error. The red graph shows where the root of the problem is. The amplitude of the cosine curve, and therefore the **end_pos** parameter, has been changed during the execution of the **CAMBOX** command. The solution is simple: A change of the **end_pos** parameter during **CAMBOX** execution must be prevented. To do this, either modify the programs in Trajexia, or in some other controller (if the parameter is changed outside of the scope of the application programs, for example by a FINS message).

**Note**

The time base of the CAM TABLE points is not the same as the capture of the other signals. The discontinuity in the CAM (red graph) coincides in time with the interruption of the movement. To analyze this, check the position values individually with a spreadsheet program. To analyze the point values in detail, you can export the TABLE points to a spreadsheet program for a more complex analysis.

6.2 Practical examples

6.2.1 Shell program


Good programming practice requires a good SHELL program. A SHELL program starts, stops and resets the application programs. The SHELL program is not necessary, but gives structure to the applications and makes the method to program the motion controller more effective.

Find below an example of a SHELL program. Make sure that you modify the program to the specific needs of the application. Check the correct operation before you rely on the safe operation of the program. This program is typically set to run at power-up at low priority.

Example

```
'=====
'CONSTANT & GLOBAL DEFINITION
'-----
'Starting from "base_address" we reserve:
' 10 VR's for project status
' 2 VR's per axis for error diagnostics
'-----
base_address=900
'"status_word" reports about the status of the system
' =0 during initialization
' =1 application stopped with no error
' =2 errors in the system
' =3 application running
GLOBAL "status_word",base_address+0
'VR(status_bits) reports next status
' Bit0   Alarm flag
' Bit15  ML communication error with one slave
CONSTANT "status_bits",base_address+1
'"action" send messages to the upper controller
' =0 during initialization
' =1 Push RESET to restart
' =2 Resetting
' =3 System healthy
```

fig. 49



```
GLOBAL "action",base_address+2
'VR(diag01) gives feedback of the MECHATROLINK initialisation
' Bit0 Could not get the ML slave number
' Bit1 Slave number is uncorrect
CONSTANT "diag01",base_address+3
'VR(diag02) gives feedback of the MECHATROLINK Slaves
' Bitn Slave n not detected
CONSTANT "diag02",base_address+4
CONSTANT "diag03",base_address+5
'SYSTEM_ERROR
GLOBAL "sys_error",base_address+8
'"first_error" gives the axis number causing a motion error
GLOBAL "first_error",base_address+9
'VR(servostatus+axis_n*2) stores AXISSTATUS to report to upper controller
CONSTANT "servostatus",base_address+10
'VR(servocalarm+axis_n*2) stores the alarm code of the servo
CONSTANT "servocalarm",base_address+11
'VR(axismonitor) stores one monitor per axis
CONSTANT "axismonitor",116 'base_address+12
CONSTANT "max_axis",15

'MYCONSTANTS
GLOBAL "cut_lenght",501

'Variable initialization
VR(0)=0
a93=1
run_ant=READ_BIT(0,0)
run_act=READ_BIT(0,0)
stop_ant=READ_BIT(1,0)
stop_act=READ_BIT(1,0)
res_ant=READ_BIT(2,0)
res_act=READ_BIT(2,0)

'At least the right system needs to be properly detected once
GOSUB system_detection
```

```
'Stop all potential programs movements
GOSUB stop_all
status_word=1

loop:
    IF alarm_bit THEN

        action=1 ' Alarm, push RESET to restart

        IF status_word<>2 THEN
            PRINT "Stop with Alarm"
            GOSUB stop_all
            status_word=2 'Programs stopped with error
        ENDIF

        IF res_bit=1 THEN
            action=2 'Resetting
            PRINT "Resetting"
            GOSUB reset_all
            status_word=1 'Programs stopped NO error
        ENDIF

    ELSE

        action=3 'OK

        IF run_bit=1 AND status_word<>3 THEN
            PRINT "Start application"
            GOSUB start_application
            status_word=3 'Application running
        ENDIF

        IF stop_bit=1 AND status_word=3 THEN
            PRINT "Stop by command"
            GOSUB stop_all
            status_word=1
        ENDIF

    ENDIF
```

```
ENDIF

'Evaluates rising edge in RUN, STOP & RESET bits
GOSUB sequence
'Checks for alarms in the system and monitors the system status
GOSUB alarm_sequence
'Upgrade values for showing in the HMI & PLC
GOSUB monitoring
'Reports and reset warnings in servodrive
GOSUB warning_seq
GOTO loop

sequence:
'Define here your signals to STOP/START/RESET
'Run
    run_ant=run_act
    run_act=READ_BIT(0,0)
    run_bit=run_act AND NOT run_ant
'Stop
    stop_ant=stop_act
    stop_act=READ_BIT(1,0)
    stop_bit=stop_act AND NOT stop_ant
'Reset
    res_ant=res_act
    res_act=READ_BIT(2,0)
    res_bit=res_act AND NOT res_ant
RETURN

alarm_sequence:
'Alarm notification
IF SYSTEM_ERROR=0 AND MOTION_ERROR=0 AND READ_BIT(15,diag01)=1 THEN
    alarm_bit=0
ELSE
    IF MOTION_ERROR<>0 THEN
        SET_BIT(0,status_bits) 'Motion error flag
        first_error=ERROR_AXIS
```

```

        ENDIF
        alarm_bit=1
    ENDIF

    'Mechatrolink axis alarm monitoring
    FOR i=0 TO max_axis
        BASE(i)
        VR(servostatus+i*2)=AXISSTATUS
        'if stopped by alarm, notify the alarm code
        IF ATYPE>=40 AND ATYPE<=42 THEN
            IF status_word=2 THEN
                'if no response, notify "communication alarm"
                IF (AXISSTATUS AND 4)<>0 THEN
                    VR(servocalarm+i*2)=$E6
                ELSEIF NOT DRIVE_ALARM(servocalarm+i*2) THEN
                    VR(servocalarm+i*2)=$E6
                ELSEIF VR(servocalarm+i*2)=0 THEN
                    VR(servocalarm+i*2)=$bb
                ENDIF
                'if no alarm, notify RUN=$99 or BaseBlock=$BB
                ELSEIF(DRIVE_STATUS AND 8) THEN
                    VR(servocalarm+i*2)=$99
                ELSE
                    VR(servocalarm+i*2)=$bb
                ENDIF
            ENDIF
        NEXT i

        sys_error=SYSTEM_ERROR
    RETURN

stop_all:
    STOP "APPLICATIONDATA"
    STOP "APPLICATION"
    WDOG=0
    FOR i= 0 TO max_axis
        BASE(i)

```

```
IF MARK=0 THEN
    REGIST(-1)
    WAIT UNTIL MARK
ENDIF
AXIS_ENABLE=0
SERVO=0
CANCEL(1) 'Cancel NTYPE
WA(1)
CANCEL(1) 'Cancel possible program buffer
NEXT i
RAPIDSTOP 'Cancel MTYPE
RETURN

start_application:
RUN "APPLICATIONDATA"
RUN "APPLICATION"
RETURN

reset_all:
'Uncorrect system setting
IF READ_BIT(15,diag01)=0 THEN GOSUB system_detection

'Mechatrolink axes reset sequence
FOR i=0 TO max_axis
    BASE(i)
    IF ATYPE>=40 AND ATYPE<=42 THEN
        'Reset sequence for MECHATROLINK communication error
        IF (AXISSTATUS AND 4)<>0 THEN
            PRINT "Resetting ML alarm"
            MECHATROLINK(0,0)
            GOSUB system_detection
            'EX
        ENDIF
        'Reset sequence for DRIVE errors
        IF (AXISSTATUS AND 8)<>0 THEN
            IF VR(servor_alarm+i*2)=$81 OR VR(servor_alarm+i*2)=$CC THEN
                GOSUB absencoder
            ENDIF
        ENDIF
    ENDIF
ENDFOR
```

```

    ELSE
        'Pending to handle differently those alarms that cannot
        'be resetted with DRIVE_CLEAR
        DRIVE_CLEAR
    ENDIF
ENDIF
ENDIF

NEXT i
'Reset sequence for AXIS error
DATUM(0)
CLEAR_BIT(0,status_bits)

'Mechatrolink devices reset sequence (NOT APPLICABLE IN YOUT DEMO)
IF (SYSTEM_ERROR AND $40000)<>0 THEN
    IF MECHATROLINK(0,5,$6E,-1)<>0 THEN
        MECHATROLINK(0,0)
        GOSUB system_detection
        'EX
    ENDIF
    'Same with the other IO devices
ELSEIF SYSTEM_ERROR<>0 THEN
    'Other system error needs initialisation of the system
    EX
ENDIF

RETURN

warning_seq:
    IF READ_BIT(15,diag01) THEN
        'Clear servodrive warning if any
        IF res_bit=1 THEN
            FOR i=0 TO max_axis
                BASE(i)
                IF ATYPE>=40 AND ATYPE<=42 THEN
                    IF (DRIVE_STATUS AND 2)>0 THEN DRIVE_CLEAR
                ENDIF
            NEXT i
        ENDIF
    ENDIF

```

```
a93=0
ENDIF
ENDIF
RETURN

monitoring:
'Other monitoring depending on the application
FOR i=0 TO 2
    BASE(i)
    VR(axis_monitor+i)=MPOS
    VR(axis_monitor+3+i)=DPOS
    VR(axis_monitor+6+i)=DRIVE_MONITOR
NEXT i
RETURN

absencoder:
RUN "absencoder",7
WAIT UNTIL PROC_STATUS PROC(7)=1
WAIT UNTIL PROC_STATUS PROC(7)=0
GOSUB system_detection
RETURN

system_detection:
'THE MISSION IS TO CONFIRM THAT THE DETECTED HARDWARE IS THE EXPECTED ONE
'AND PROGRAM THE SERVODRIVES
status_word=0
action=0
VR(status_bits)=0
VR(diag01)=0
VR(diag02)=0
VR(diag03)=0
'UNIT DETECTION (first)
IF COMMSTYPE SLOT(0)<>31 THEN SET_BIT(0,diag03) 'TJ1-ML16
IF COMMSTYPE SLOT(1)<>33 THEN SET_BIT(1,diag03) 'TJ1-FL02
IF COMMSTYPE SLOT(2)<>34 THEN SET_BIT(2,diag03) 'TJ1-PRT

'MECHATROLINK(0,0)
```

```
' =====
' MECHATROLINK device detection for UNIT 0
' =====
IF NOT MECHATROLINK(0,3,0) THEN
    PRINT "Error getting device count for unit 0"
    SET_BIT(0,diag01)
ELSEIF VR(0) <> 3 THEN
    PRINT "Incorrect device count for unit 0"
    SET_BIT(1,diag01)
ENDIF
IF NOT MECHATROLINK(0,4,0,0) THEN
    PRINT "Error getting address for unit 0, station 0"
    SET_BIT(0,diag02)
ELSEIF VR(0) <> $41 THEN
    PRINT "Incorrect address for unit 0, station 0"
    SET_BIT(0,diag02)
ENDIF
IF NOT MECHATROLINK(0,4,1,0) THEN
    PRINT "Error getting address for unit 0, station 1"
    SET_BIT(1,diag02)
ELSEIF VR(0) <> $42 THEN
    PRINT "Incorrect address for unit 0, station 1"
    SET_BIT(1,diag02)
ENDIF
IF NOT MECHATROLINK(0,4,2,0) THEN
    PRINT "Error getting address for unit 0, station 2"
    SET_BIT(2,diag02)
ELSEIF VR(0) <> $43 THEN
    PRINT "Incorrect address for unit 0, station 2"
    SET_BIT(2,diag02)
ENDIF
VR(0)=0

' =====
' SERVODRIVE PARAMETERS
' =====
IF READ_BIT(0,diag02)=0 THEN
```

```
'-----  
BASE(0)'Circular axis Sigma-II  
'-----  
'Parameter data param_n/param_v/size  
TABLE(0,$202,32,2)  
TABLE(3,$203,45,2)  
TABLE(6,$50A,$8881,2)  
TABLE(9,$50B,$8888,2)  
TABLE(12,$50C,$8888,2)  
TABLE(15,$001,$0010,2)  
TABLE(18,$511,$6540,2)  
TABLE(21,$801,$0003,2)  
TABLE(24,$81E,$4321,2)  
TABLE(27,$110,$0012,2)  
TABLE(30,$103,700,2)  
TABLE(33,-1)  
MECHATROLINK(0,20,$41)  
REGIST(-1)  
WAIT UNTIL MARK  
i=0  
res=0  
WHILE TABLE(i)<>-1  
    IF NOT DRIVE_READ(TABLE(i),TABLE(i+2),1) THEN  
        SET_BIT(0,diag02)  
    ELSEIF VR(1)<>TABLE(i+1) THEN  
        IF NOT DRIVE_WRITE(TABLE(i),TABLE(i+2),TABLE(i+1),1) THEN  
            SET_BIT(1,diag02)  
        ELSE  
            res=1  
        ENDIF  
    ENDIF  
    i=i+3  
WEND  
'Reset drive if necessary  
IF res=1 THEN  
    IF NOT DRIVE_RESET THEN SET_BIT(0,diag02)  
ENDIF
```

```
'Axis Parameter
UNITS=32
REP_OPTION=1
REP_DIST=360
FE_LIMIT=900
FS_LIMIT=10000
RS_LIMIT=-10000
SPEED=3600
CREEP=360
ACCEL=5000
DECCEL=5000
ATYPE=40
DRIVE_CONTROL=11
ENDIF

IF READ_BIT(1,diag02)=0 THEN
'-----
BASE(1)'Belt with absolute encoder & Sigma-II
'-----
'Parameter data param_n/param_v/size
TABLE(0,$202,32,2)
TABLE(3,$203,5,2)
TABLE(6,$205,34,2)
TABLE(9,$50A,$8881,2)
TABLE(12,$50B,$8888,2)
TABLE(15,$50C,$8888,2)
TABLE(18,$001,$0010,2)
TABLE(21,$511,$6540,2)
TABLE(24,$801,$0003,2)
TABLE(27,$81E,$4321,2)
TABLE(30,$110,$0012,2)
TABLE(33,$103,400,2)
TABLE(36,-1)
MECHATROLINK(0,20,$42)
REGIST(-1)
WAIT UNTIL MARK
i=0
```

```
res=0
WHILE TABLE(i)<>-1
    IF NOT DRIVE_READ(TABLE(i),TABLE(i+2),1) THEN
        SET_BIT(1,diag02)
    ELSEIF VR(1)<>TABLE(i+1) THEN
        IF NOT DRIVE_WRITE(TABLE(i),TABLE(i+2),TABLE(i+1),1) THEN
            SET_BIT(1,diag02)
        ELSE
            res=1
        ENDIF
    ENDIF
    i=i+3
WEND
'Reset drive if necessary
IF res=1 THEN
    IF NOT DRIVE_RESET THEN SET_BIT(0,diag02)
ENDIF
'Axis Parameter
UNITS=128
REP_OPTION=1
REP_DIST=700
FE_LIMIT=100
DEFPOS(ENCODER/UNITS)
FS_LIMIT=2000
RS_LIMIT=-2000
SPEED=100
ACCEL=5000
DECEL=5000
ATYPE=40
DRIVE_CONTROL=11
ENDIF

IF READ_BIT(2,diag02)=0 THEN
'-----
BASE(2)'Left belt
'-----
'Parameter data param_n/param_v/size
```

```
TABLE(0,$202,4,2)
TABLE(3,$203,5,2)
TABLE(6,$50A,$2881,2)'POT Enabled
TABLE(9,$50B,$8883,2)'NOT Enabled
TABLE(12,$50C,$8888,2)
TABLE(15,$001,$0010,2)
TABLE(18,$511,$6540,2)
TABLE(21,$801,$0003,2)
TABLE(24,$81E,$4321,2)
TABLE(27,$110,$0012,2)
TABLE(30,$103,400,2)
TABLE(33,-1)
MECHATROLINK(0,20,$43)
REGIST(-1)
i=0
res=0
WHILE TABLE(i)<>-1
    IF NOT DRIVE_READ(TABLE(i),TABLE(i+2),1) THEN
        SET_BIT(1,diag02)
    ELSEIF VR(1)<>TABLE(i+1) THEN
        IF NOT DRIVE_WRITE(TABLE(i),TABLE(i+2),TABLE(i+1),1) THEN
            SET_BIT(1,diag02)
        ELSE
            res=1
        ENDIF
    ENDIF
    i=i+3
WEND
'Reset drive if necessary
IF res=1 THEN
    IF NOT DRIVE_RESET THEN SET_BIT(0,diag02)
ENDIF
'Axis Parameter
UNITS=128
REP_OPTION=1
REP_DIST=700
FE_LIMIT=100
```

```
FS_LIMIT=2000
RS_LIMIT=-2000
SPEED=100
ACCEL=5000
DECCEL=5000
ATYPE=40
DRIVE_CONTROL=11
ENDIF

' -----
BASE(10) 'Auxiliary axis for corrections
' -----

UNITS=32
SPEED=10000
ACCEL=1000000
DECCEL=1000000

'DETECTION OK
IF VR(diag01)=0 AND VR(diag02)=0 AND VR(diag03)=0 THEN
SET_BIT(15,diag01)
RETURN
```

6.2.2 Initialization program

The Initialization program sets the parameters for the axes. These parameters are dependant upon the Motor Encoder resolution and the motor maximum speed.



Note

Refer to the Servo Driver and the motor data sheet for this information.

```
' =====
' EXAMPLE OF INITIALIZATION PROGRAM
' THIS VERSION IS DESIGNED FOR MECHATROLINK-II SERVOS
' ADAPT THIS PROGRAM ACCORDING TO YOUR APPLICATION
' =====
```

```
BASE(x)
restart=0
inertia_ratio=set_load_inertia_ratio

' -----
' EXAMPLE 1
'SGMAH-01AAA61D-OY motor data
' -----
enc_resolution=2^13 '13 bit encoder
max_speed=5000 '5000 rpm max. speed

' -----
' EXAMPLE 2
'SGMAH-01A1A61D-OY motor data
' -----
enc_resolution=2^16 '16 bit encoder
max_speed=5000 '5000 rpm max. speed

' -----
'WRITE PARAMETERS IN THE SERVO
' -----
DRIVE_WRITE($103,2,inertia_ratio) 'Write inertia ratio
DRIVE_READ($110,2,10)
IF VR(10)<>$0012 THEN
    DRIVE_WRITE($110,2,$0012,1)
    'Pn110=0012h (autotuning disabled)
    restart=1
ENDIF
DRIVE_READ($202,2,10)
IF VR(10)<>1 THEN
    DRIVE_WRITE($202,2,1,1)
    'Pn202=1 (gear ratio numerator in the drive. Default is 4)
    restart=1
ENDIF
DRIVE_READ($511,2,10)
IF VR(10)<>$6548 THEN
    DRIVE_WRITE($511,2,$6548,1)
```

```
'Pn511 set the registration inputs in the Servo Driver
restart=1
ENDIF
DRIVE_READ($81E,2,10)
IF VR(10)<>$4321 THEN
    DRIVE_WRITE($81E,2,$4321,1)
    'Pn81E=$4321 To make the Digital inputs in the Servo Driver
    'available for reading through DRIVE_INPUTS word
    restart=1
ENDIF
IF restart=1 THEN DRIVE_RESET

'-----
'Initial gains For MECHATROLINK_SPEED
'-----
'By experience this setting is a good starting point
P_GAIN=INT(214748.3648*max_speed/enc_resolution)
'This is the optimum value. Set if needed
VFF_GAIN=INT(60000*1073741824/enc_resolution/max_speed)

'-----
'Initial gains For MECHATROLINK_POSITION mode
'-----
'Change the rigidity (Fn001) according to the 'mechanical system
'Change feedforward gain Pn109 if required

'-----
'Initial parameter of the AXIS
'-----
'If set to 1 (and Pn202=Pn203=1) the UNITS are 'encoder counts
UNITS=1
'Theoretical FE we will have running the motor at "max_speed"
'without VFF_GAIN in MECHATROLINK SPEED
FE_LIMIT=1073741824/P_GAIN/UNITS
'SPEED is set to 1/3 of "max_speed"
SPEED=(max_speed73)*enc_resolution/60/UNITS
'ACCEL in 200ms from 0 to "max_speed"
```

```
ACCEL=SPEED/0.2
'DECEL in 200ms from "max_speed" to 0
DECCEL=SPEED/0.2
```

6.2.3 Single axis program

This program is a simple program to run one axis only.

Example

```
'GOSUB homing
BASE(0)
DEFPOS(0)
WA(100)
loop:
    MOVE(1440)
    WAIT IDLE
    WA(100)
GOTO loop
```

The units are degrees in this example, therefore:

- 13-bit encoder
- Pn202=32
- Pn203=45
- **UNITS=32**

The graph in the figure is typical for this point-to-point movement with linear acceleration). Note the following:

- During linear acceleration, the graph of the position is parabolic (because the speed is a derivative of the position).
- During constant speed, the graph of the position is straight.
- During linear deceleration, the graph of the position is counter-parabolic.
- During stop, the graph of the position is constant.
- When an overflow occurs (**MPOS>=REP_DIST**), the position jumps to 0 if **REP_OPTION=1** or to **-REP_DIST** if **REP_OPTION=0**.




fig. 50

- The Following Error is proportional to the speed if you use only Proportional Gain in the position loop.
- The torque, which is given by **DRIVE_MONITOR** as a percentage of the nominal torque of the motor when you set **DRIVE_CONTROL=11**) is proportional to the acceleration according to the formula:


$$\text{Torque}_{\text{total}} = J_{\text{total}} \times \alpha + \text{Torque}_{\text{friction}}$$

where $\text{Torque}_{\text{friction}}$ is usually small, α is the angular acceleration, and J the inertia of the system.

6.2.4 Position with product detection

A ballscrew moves forward at a creep speed until it reaches a product, a microswitch (IN(2)) turns on.

The ballscrew is stopped immediately, the position at which the product is sensed is indicated and the ballscrew returns at a rapid speed back to the start position.



Example


start:

```

WAIT UNTIL IN(1)=ON
SPEED=10
FORWARD
WAIT UNTIL IN(2)=ON
prod_pos=MPOS
CANCEL
WAIT IDLE
PRINT "Product Position : "; prod_pos
SPEED=100
MOVEABS(0)
WAIT IDLE
GOTO start

```


fig. 52



6.2.5 Position on a grid

A square palette has sides 1m long. It is divided into a 5 x 5 grid, and each of the positions on the grid contains a box which must be filled using the same square pattern of 100mm by 100mm. A dispensing nozzle controlled by digital output 8 must be turned on when filling the box and off at all other times.

fig. 53




Example

```

nozzle = 8
start:
  FOR x = 0 TO 4
    FOR y = 0 TO 4
      MOVEABS(x*200, y*200)
      WAIT IDLE
      OP(nozzle, ON)
      GOSUB square_rel
      OP(nozzle, OFF)
    NEXT y
  NEXT x
GOTO start
square_rel:
  MOVE(0, 100)
  MOVE(100, 0)
  MOVE(0, -100)
  MOVE(-100, 0)
  WAIT IDLE
  WA(1000)
RETURN

```

fig. 54



6.2.6 Bag feeder program


A bag feeder machine feeds plastic film a fixed distance that is set by the operator. The figure shows a typical bag feeder that is part of the machine.

Bag feeder machines have two modes.

- Without mark: Forward feeds the film a set distance, for films of a flat colour
- With mark: Forward feeds the film to a printed mark on the film.

The program in this section shows the typical code for a bag feeder machine.

fig. 55



Example


```
'=====
'BAG FEEDER program
'=====

'Working with marks, if any mark is missing, feed the
'theoretical distance. But if the mark is missing for
'a number of consecutive bags, stop the operation.
'A digital output is activated a certain time to cut
'the bag.
'=====

'Variable initialisation
start_signal=7
max_fail=3
program_alarm=0
failed=0
feeder_axis=2
BASE(feeder_axis)
'Position counter (MPOS,DPOS) goes from 0 to 999999
'and 0 again
UNITS=27
SPEED=100
ACCEL=1000
DECCEL=1000
REP_DIST=1000000
REP_OPTION=1
SERVO=ON
WDOG=ON

'Main program
loop:
    'Define current position as zero
    DEFPOS(0)

    'Wait for rising edge in Digital Input
    '"start_signal"
```



```
WAIT UNTIL IN(start_signal)=0
WAIT UNTIL IN(start_signal)=1

'Move bag length
MOVEABS(bag_distance)
WAIT UNTIL MTYPE=2 'To verify that the MOVEABS is being executed

'If we work with Mark, activate the trigger
'MARK=FALSE when triggered and TRUE when not triggered
IF work_with_mark AND MARK THEN
    REGIST(1)
    WAIT UNTIL MARK=0
ENDIF

'Wait until movement finished or mark detected
WAIT UNTIL MTYPE=0 OR (MARK AND work_with_mark)

'Working with mark
IF work_with_mark THEN
    IF MARK THEN 'If the mark has been detected, the position is corrected
        MOVEMODIFY(bag_distance-expected_pos+REG_POS)
        failed=0

    ELSE 'If the mark has not been detected
        PRINT "Mark not detected"
        failed=failed+1
        IF failed>max_fail THEN 'After several consecutive misdetection stop the application
            PRINT "Mark definitely lost"
            program_alarm=3
            STOP
        ENDIF
    ENDIF
ENDIF

'Wait until the feed movement has finished
WAIT IDLE
GOTO loop
```

6.2.7 CAM table inside a program

It shows how to create a CAM table inside a program, and use the **CAMBOX** motion command.

The profile used is the COS square one. This is a quite typical profile for feeder-type applications as:

- The motion provides a smooth acceleration without sudden acceleration changes, so the material slip is minimized
- It gives a fast deceleration so the cycle time is reduced. During deceleration there is no material slip and the friction helps to the stop to zero.

Example


```

start:
  GOSUB filltable
  WDOG=1 'Set servos to RUN
  BASE(1)
  SERVO=1 'Enable position loop in axis 1
  BASE(0)
  SERVO=1 'Enable position loop in axis 0
  'The position counter counts from 0 to 11999
  'and then back to 0 again
  REP_OPTION=1
  REP_DIST=12000
  SPEED=200
  FORWARD

  BASE(1)
loop:
  CAMBOX(in_tbl,end_tbl,1,lnk_dst,master,opt,start)
  WAIT IDLE
  GOTO loop

filltable:
  'The shape of the CAM is stored in TABLE(0) to
  'TABLE(360)
  npoints=360

```



```

in_tbl=0
end_tbl=in_tbl+npoints
'Distance of the master to make the CAM
lnk_dst=10000
'Master axis
master=0
'The CAM start exactly when the master reaches
'position "start"
opt=2
start=1000

k=100
'Fill the TABLE with the suitable waveform
FOR i= in_tbl TO end_tbl
    TABLE(i,(k*(COS(PI*i/npoints)-1))^2)
NEXT i
RETURN


```

6.2.8 Flying shear program

An example of the Flying shear program. In this application there are three axes:

- Axis 0, shear_axis, the advancement of the shear.
- Axis 1, flying_axis, is the flying shear.
- Axis 2, line_axis, transports the material.

fig. 58



Example

```
'=====
' FLYING SHEAR program
'=====
'Typical example of a flying shear application.
'One axis (line_axis) transport the material
'Second axis (flying_axis) is the flying shear itself
'Start axis (shear_axis) is the shear advancement
'The distance in synchronization must be long enough
'to allow the cut at maximum speed.
'The return of the flying shear is done at such a
'speed that the wait time is zero (optimization of
'the movement).
'Again it is assumed that everything has been
'calculated to not exceed the maximum motor speed at
'maximum line speed
'=====
cut_counter=0
line_axis=2
shear_axis=0
flying_axis=1


SERVO AXIS(line_axis)=ON
SERVO AXIS(flying_axis)=ON
SERVO AXIS(shear_axis)=ON
WDOG=ON

'FIRST CYCLE

'Make a first material cut
MOVEABS(end_pos) AXIS(shear_axis)
WAIT UNTIL MTYPE AXIS(shear_axis)=2
WAIT IDLE AXIS(shear_axis)

'First time we have a certain wait time because the
'material has been just been cut
wait_distance=cut_length-l_acc/2
```

fig. 59



```
MOVELINK(0,wait_distance,0,0,line_axis) AXIS(flying_axis)
WAIT UNTIL MTYPE AXIS(flying_axis)=22

'We start the line
FORWARD AXIS(line_axis)

loop:

'Update the line speed every cycle
SPEED AXIS(line_axis)=line_speed

'Cutting movement at synchronized speed
line_cut=synch_dist+l_acc+l_dec
shear_cut=synch_dist+l_acc/2+l_dec/2
MOVELINK(shear_cut,line_cut,l_acc,l_dec,line_axis) AXIS(flying_axis)
WAIT UNTIL MPOS AXIS(flying_axis)>l_acc/2

'Activate the shear when it is in synchronization with the line
'Slow speed to cut
SPEED AXIS(shear_axis)=cut_speed
MOVEABS(end_pos) AXIS(shear_axis)
MOVEABS(0) AXIS(shear_axis)
WAIT UNTIL NTYPE AXIS(shear_axis)=2
'Fast speed to return
WAIT LOADED AXIS(shear_axis)
SPEED AXIS(shear_axis)=return_speed

cut_counter=cut_counter+linch

'Return back synchronized with the master in such a way
'that there is no wait time
line_back=cut_length-synch_dist-l_dec-l_acc
shear_cut=l_acc/2+synch_dist+l_dec/2
MOVELINK(-shear_cut,line_back,l_acc/4,l_dec/4,line_axis) AXIS(flying_axis)


GOTO loop
```

The speed-time graph shows the steps of the above example. The steps are:

1. The initial cycle: the slave waits for the right length in the product to cut (`cut_length - distance_to_accelerate / 2`). It is necessary to divide `distance_to_accelerate` when we use the **MOVELINK** command, because when we synchronize, the master moves twice the distance of the slave.
2. The slave accelerates to synchronize with the master. When the acceleration finishes, the relative distance between the edge of the product and the shear is `cut_length`.
3. This is the synchronization part: the relative distance between the edge of the product and the shear remains the same. The cut in the material is made. This gives a new material edge.
4. The deceleration part: the material continues, and the shear stops.
5. Move back at high speed: the distances are calculated such that when the slave reaches its original position, the edge of the product is in the correct position to start a new cut.

A new movement starts (step 2).

fig. 60



6.2.9 Correction program

This application is for a rotary labeller. The constants are:

- The product arrives on a conveyor (master axis) that runs at a constant speed.
- A rotary labeller that is synchronized 1:1 to the conveyor, attaches the labels.
- The distance between products is fixed and mechanically guaranteed.

The distance between labels is never exactly constant so, a correction is needed. This is done by superimposing a virtual axis onto the movement of the labeller.

The difference between the expected position and the actual position is measured with a photocell. This is the correction factor.

Every time a correction is made, the origin position is updated accordingly.

Example

```

conveyor=0
labeller=1
virtual=15
SERVO AXIS(conveyor)=1
SERVO AXIS(labeller)=1
WDOG=1

BASE(labeler)
CONNECT(1,conveyor)
ADDAX(virtual)
FORWARD AXIS(conveyor)
REGIST(1)
WAIT UNTIL MARK=0


```

```

loop:
    WAIT UNTIL MARK
    correction=REG_POS+expected_pos
    MOVE(correction) AXIS(virtual)
    WAIT IDLE AXIS(virtual)
    OFFPOS=-label_length+correction
    REGIST(1)
    WAIT UNTIL MARK=0
    GOTO loop

```

fig. 61



7 Troubleshooting

7.1 Voltage and analysis tools

Check the voltage to the power supply input terminals. Make sure the voltage is within the specified range. If the voltage is outside the specified range, the system can operate incorrectly.

To diagnose errors for the TJ1-MC__ and the TJ1-ML__ and to troubleshoot these units, use the Trajexia Tools software tool.

To diagnose errors for the TJ1-PRT and to troubleshoot this unit, use a PROFIBUS configurator and monitoring tool (for example, **OMRON CX-PROFIBUS**).


Caution

Disconnect all cables before you check if they have burned out. Even if you have checked the conduction of the wiring, there is a risk of conduction due to the return circuit.


Caution

If the encoder signal is lost, the servo motor can run away, or an error can be generated. Make sure that you disconnect the motor from the mechanical system before you check the encoder signal.


Caution

When you troubleshoot, make sure that nobody is inside the machine facilities and that the facilities are not damaged even if the servo motor runs away. Check that you can immediately stop the machine using an emergency stop when the motor runs away.

7.2 TJ1-MC__

7.2.1 System errors

System errors show on the LED display of the TJ1-MC__ as **Enn**, where **nn** is the error code.

Error code	Description	Cause	Solution
E00	BASIC SRAM error	Hardware failure of the TJ1-MC__.	Replace the TJ1-MC__.
E01	System SRAM low word error	Hardware failure of the TJ1-MC__.	Replace the TJ1-MC__.
E02	System SRAM high word error	Hardware failure of the TJ1-MC__.	Replace the TJ1-MC__.
E03	Battery low error ¹	The battery voltage is too low.	Replace the battery.
...	Hardware failure	Hardware failure of the TJ1-MC__.	Replace the TJ1-MC__.

1. Trajexia can work normally without a battery connected, only storage in RAM is not possible.


Note

Please refer to section 3.2.260 for more information.

7.2.2 Axis errors

Axis errors show on the LED display of the TJ1-MC__ as **Ann**.

Error code	Description	Cause	Solution
Ann	Axis error on axis nn	Incorrect or out of range value of axis parameter set	See below
		Error or alarm on Servo Driver assigned to the axis	See below

Incorrect or out of range axis parameter value

If the value of an axis parameter is incorrect or out of range an axis error occurs. No alarm or error shows on the display of the Servo Driver assigned to the axis.

You can see the cause of the error with the **AXISSTATUS** command. In the Trajexia Tools terminal window, type **PRINT AXISSTATUS AXIS(nn)**, where **nn** is the axis number. The return value of the **AXISSTATUS** command contains the axis error code. See the **AXISSTATUS** command.

You can also open the **Axis Parameter** window in Trajexia Tools and check the **AXISSTATUS** field of the axis that caused the error. The bits that indicate the cause of the error show in big red letters. To remove the error, do these steps:

1. Correct the value.
2. Reset the controller, or click the **Axis status error** button.

Error or alarm on Servo Driver assigned to the axis

If an error or an alarm on the Servo Driver assigned to the axis causes an axis error, the drive alarm shows on the LED display of the drive. You can also open the Axis Parameter window in Trajexia Tools and check the **AXISSTATUS** field of the axis that caused the error. The return value of the **AXISSTATUS** command has the second bit (bit **a**: Servo Driver communication error) and/or the third bit (bit **m**: Servo Driver alarm) show in big red letters.

To remove the error, do these steps:

1. Refer to the Servo Driver manual to determine the cause of the error, and solve the error.
2. Reset the controller, or click the **Axis status error** button.

7.2.3 Unit errors

Unit errors show on the LED display of the TJ1-MC__ as **Unn**.

Error code	Description	Cause	Solution
Unn	Unit error on unit nn	Defective unit	See below
		Unit not connected to the Trajexia bus	See below
		An I/O unit or an Inverter on a MECHATROLINK-II unit is lost or disconnected	See below
		No terminator	See below

Defective unit

The error code **U0n** shows on the display, where **n** ranges from 0 to 6 and is the number of the unit that causes the error. To solve the problem, replace the defective unit.

Unit not connected to the Trajexia bus

The error code **U0n** shows on the display, where **n** ranges from 0 to 6 and is the number of the unit that causes the error. To solve the problem, check the bus connector of the unit.

I/O unit or Inverter on a MECHATROLINK-II unit is lost or disconnected

The error code **U0n** shows on the display, where **n** is the number of the TJ1-ML__ to which the MECHATROLINK-II unit that causes the error is connected.

You can set system flags to enable and disable these errors. The errors are enabled by default.

To disable the errors, type **COORDINATOR_DATA(7,1)** in the Trajexia Tools terminal window.

To enable the errors, type **COORDINATOR_DATA(7,0)** in the Trajexia Tools terminal window.

To see the current setting, type **PRINT COORDINATOR_DATA(7)** in the Trajexia Tools terminal window.

To clear the error after repair do these steps:

- Reconnect the lost MECHATROLINK-II I/O unit or Inverter.
- Type **MECHATROLINK(n, 5, station, -1)** in the Trajexia Tools terminal window:
where **n** is the number of the TJ1-ML__ to which the MECHATROLINK-II unit affected, and **station** is the MECHATROLINK-II device number that is lost.

If you want to use the system without the lost device, you can reconnect all available devices on the TJ1-ML__. To do this, type **MECHATROLINK(n, 0)** in the Trajexia Tools terminal window, where **n** is the number of the TJ1-ML__ that reports the error.

No terminator

The error code **U07** shows on the display.

To solve the problem, check the terminator connection or replace the terminator if it is defective.

7.2.4 Configuration errors

Configuration errors show on the LED display of the TJ1-MC__ as **Cnn**.

Error code	Description	Cause	Solution
Cnn	Configuration error caused by unit nn	The system has too many units of the same type, and it does not adhere to the rules for adding units to a system	Change the system so that it adheres to the rules for adding units to a system. See the Hardware Reference manual.
		You have connected too many MECHATROLINK-II stations to the TJ1-ML__	
		There are too many axes in the system	
		There are too many non-axis MECHATROLINK-II stations in the system	

7.2.5 Replace the battery

To replace the backup battery, do these steps:

1. Make sure the Power Supply Unit is set to on for at least five minutes. If not, the capacitor that backs up the memory of the TJ1-MC__ while the battery is not connected is not fully charged, and you can lose data in memory.
2. Pull the top of the lid of the battery compartment away from the unit to open the battery compartment.
3. Pull the red and white wires to pull out the old battery.
4. Make sure you complete the next 2 steps within 30 seconds to prevent data loss in the RAM memory.
5. Disconnect the wires from the old battery.
6. Attach the wires to the new battery.
7. Insert the new battery into the battery compartment.
8. Close the lid of the battery compartment.

7.3 TJ1-PRT

7.3.1 System errors

Indication	Problem	Solution
No LEDs are on or flashing	The power is off.	Turn the power on.
	The TJ1-PRT is defective.	Replace the TJ1-PRT.
ERH LED is on	Communication failure between TJ1-MC__ and TJ1-PRT.	Reset the TJ1-MC__. If this does not help, replace the TJ1-MC__.
ERC LED is on	Unit error. The TJ1-PRT is defective.	Replace the TJ1-PRT.

7.3.2 I/O data communication problems

Indication	Problem	Solution
COMM LED is off and BF LED is on	The PROFIBUS configuration is incorrect, there is no communication with the master.	<ul style="list-style-type: none"> Check that the TJ1-PRT has the same station address as in the configuration of the master. Check that no station address is used twice.
	The PROFIBUS wiring is not correct.	<ul style="list-style-type: none"> Check that the correct pins of the CN1 connector are connected. Check that there are no short circuits or line interruption. Check that you use the correct cable type. Check that the stub lines are not too long.
	You have not properly terminated the PROFIBUS network.	Terminate the PROFIBUS network at the appropriate places.
	The PROFIBUS master unit is defective.	Replace the master unit.
	The TJ1-PRT is defective.	Replace the TJ1-PRT.

Indication	Problem	Solution
COMM LED is off and BF LED is flashing	The PROFIBUS configuration is incorrect, there is no communication with the master.	<ul style="list-style-type: none"> Check that you use the correct GSD file in the master. Check the configuration and the parameter data of the slave. Check that the network has been configured to communicate at the baud rate supported by the TJ1-PRT.
You have not selected configuration data for the slave.	Check the configuration at the master.	
The TJ1-PRT is defective.	Replace the TJ1-PRT.	

7.4 TJ1-DRT

7.4.1 System errors

Indication	Problem	Solution
No LEDs are on or flashing	The power is off.	Turn the power on.
	The TJ1-DRT is defective.	Replace the TJ1-DRT.
ERH LED is on	Communication failure between TJ1-MC__ and TJ1-DRT.	Reset the TJ1-MC__. If this does not help, replace the TJ1-MC__.
ERC LED is on	Unit error. The TJ1-DRT is defective.	Replace the TJ1-DRT.

7.4.2 I/O data communication problems

Indication	Problem	Solution
NOK is flashing and NF LED is off	The DeviceNet master is not communicating with the TJ1-DRT.	<ul style="list-style-type: none"> Configure and start the DeviceNet master.
NOK off and NF LED is on	The node address duplication error.	<ul style="list-style-type: none"> Check node address.
	Network cable error.	<ul style="list-style-type: none"> Check network cables.

7.5 TJ1-CORT

7.5.1 System errors

Indication	Problem	Solution
No LEDs are on or flashing	The power is off.	Turn the power on.
	The TJ1-CORT is defective.	Replace the TJ1-CORT.
ERH LED is on	Communication failure between TJ1-MC__ CPU and TJ1-CORT.	Reset the TJ1-MC__ CPU. If this does not help, replace the CPU.
ERC LED is on	Unit error. The TJ1-CORT is defective.	Replace the TJ1-CORT.

7.5.2 I/O data communication problems

Indication	Problem	Solution
NWST is off	A start-up error or fatal error occurred.	Restart the unit. If the problem persists, replace the TJ1-CORT.

Indication	Problem	Solution
BF flashing	Invalid configuration.	Check downloaded configuration. If necessary re-download it.
BF flashing single flash	Error counter warning limit reached. Possible causes: <ul style="list-style-type: none">• No other nodes on the network.• Network termination incorrect.• Network cables installed incorrect.	Check the network cabling and network nodes.
BF flashing double flash	A heartbeat event occurred. An expected heartbeat message from another node was not received within the timeout interval.	Check the node, which was expected to send the heartbeat message.
BF is ON	The unit is in Bus OFF state Possible cause: Network cable short-circuit.	Check the network cabling.

7.6.2 Bus errors

Indication	Problem	Solution
BF LED is on	Cable failure on the MECHATROLINK-II bus.	Check MECHATROLINK-II cables between stations connected to the unit for interruptions and irregularities (short circuit between communication lines A and B, short circuit of any communication line with shielding).
	MECHATROLINK-II bus terminator is missing or damaged.	Fit a MECHATROLINK-II bus terminator on the last station in the chain or replace it.
	The MECHATROLINK-II station connected to the unit is lost due to power off or MECHATROLINK-II interface failure at the station.	Check the power and MECHATROLINK-II interface of the station that caused the problem. Replace the station if necessary.
	The TJ1-ML__ is defective.	Replace the TJ1-ML__.

7.6 TJ1-ML__

7.6.1 System errors

Indication	Problem	Solution
All LEDs are off	The power is off.	Turn the power on.
	The TJ1-ML__ is defective.	Replace the TJ1-ML__.



Note

After removing the cause of an error, make sure to re-initialise the MECHATROLINK-II bus on the unit on which the error appeared. Type in the Trajexia Tools terminal window:

MECHATROLINK(n, 0)

where **n** is the number of the unit to which the unit that caused the error is connected.

7.7 GRT1-ML2

Some analog I/O Units initialize slower after power on than others. If such an I/O Unit reports its correct status too late to the GRT1-ML2, the status word of the GRT1-ML2 has bit 13 set, which means that there is an error or a warning in the SmartSlice system. The default value of the error mask is set to detect if this bit is on, and thus an error is detected and reported by the

TJ1-MC __. After a short time, the I/O Unit reports its (real) correct status and the status word becomes 8000 hex, but the MC __ has already detected the error, even though there was no real error. Masking this particular bit of the status word with the command **MECHATROLINK(unit,37,station,value)** is not an option, because no command can be sent before the start-up sequence, during which the error is detected, is complete.

The solution to the problem is to use the command

MECHATROLINK(unit,5,station,vr)

where:

- **unit** is the number of the MECHATROLINK-II Master Unit in the Motion Controller system.
- **station** is the station address of the GRT1-ML2 unit set with the rotary switches.
- **vr** is the VR memory address where the read code is put. Use value -1 to print the status word to the Command Line Terminal interface.

This command clears the error of the unit, and enables turning on the WDOG.

If this error and the problem of I/O Units that initialize slower occur, put the command **MECHATROLINK(unit,5,station,vr)** in the start-up program.

7.7.1 Unit power supply errors

The UNIT PWR LED shows if the power supply to the GRT1-ML2 and to the SmartSlice I/O system is enough to start-up and operate correctly.

UNIT PWR	Probable cause	Correction
Not lit	No power supply or not enough power supply to the units ¹	<ul style="list-style-type: none"> • Check whether power is supplied to the unit power supply terminal • Check that the supplied power is in the required range, that is 24 VDC +10% –15% (20.4 to 26.4 VDC)

UNIT PWR	Probable cause	Correction
Flashing	The unit power supply capacity is insufficient	Check the power supply requirement of the entire SmartSlice I/O System and replace the power supply with one that has enough capacity
Lit	No error, the correct power is supplied to the system	

1. The GRT1-ML2 can start with less power than specified. In this case, the UNIT PWR LED can be off, although other LEDs can indicate normal operation. However, in this case the correct operation of the whole SmartSlice I/O system is not guaranteed.

7.7.2 I/O power supply errors

The I/O PWR LED shows if the power supply to the external I/O connected to the SmartSlice I/O Units is enough to drive the external outputs on the individual units.

I/O PWR	Probable cause	Correction
Not lit	No power or not enough power supply to the external I/O of the SmartSlice I/O Units	<ul style="list-style-type: none"> • Check whether power is supplied to the I/O power supply terminal • Check that the supplied power is in the required range, that is 24 VDC +10% –15% (20.4 to 26.4 VDC)
Lit	No I/O power error, the correct power is supplied to the external I/O system	

7.7.3 Unit errors

The GRT1-ML2 starts the initialization when the power is turned on. During the initialization, the RUN LED and the ALARM LED are off. When the initialization completes, the RUN LED goes on.

Possible errors during the initialization are in the table below.

RUN	ALARM	Probable cause	Correction
Not Lit	Not lit	Initialization in progress	N/A
	Flashing	Fatal system error during initialization	Replace the unit
	Lit	Fatal error during operation	Restart the unit. If the problem persists, replace the unit.
Lit	Not Lit	No error	N/A
	Lit	One of these MECHATROLINK-II protocol violations: • Parameter out of range • Communication lost	<ul style="list-style-type: none"> • Restart the TJ1-MC • Execute the command MECHATROLINK(unit,0)

7.7.4 SmartSlice I/O errors

TS	Color	Probable cause	Correction
Not Lit	N/A	No power supply	Refer to section 7.7.1

TS	Color	Probable cause	Correction
Flashing (every second)	Green	Adding SmartSlice I/O Units to the network	Wait until the SmartSlice I/O Units are added to the network
	Green	There can be a break in the connection between individual slices, or one of the SmartSlice sockets is not connected properly to its left neighboring connector. The TS LED on all correctly connected slices are flashing, but the TS LED on the not correctly connected units are off.	Check the connection between slices at the point where the first unit is located with its TS LED off. Make sure that all slices are connected correctly to each other.
	Green	The last unit is not or not properly connected. The SmartSlice communication does not start up. The TS LED on all SmartSlice I/O Units are flashing.	Check the connection of the last unit and make sure that it is correctly connected to the SmartSlice system
Red	Red	SmartSlice bus communication error	Make sure that the base block of the SmartSlice I/O System is connected properly
	Red	When the registration table function is enabled, the actual configuration does not match the registered configuration	Correct the configuration and turn the power on again
	Red	The total number of I/O points in the SmartSlice I/O systems is greater than the maximum	Correct the unit configuration and number of I/O points and turn the power on again
Flashing (every 0.5 seconds)	Green	Restore operation in progress	Wait until the restore operation is complete
	Green	Backup operation in progress	Wait until the backup operation is complete

TS	Color	Probable cause	Correction
Lit	Red	Backup operation failed ¹	Do the backup of the data again
		Restore operation failed ¹	Reinstall the unit in which the restore operation was in progress and turn the power on again
		SmartSlice I/O Unit configuration error	Check these items: <ul style="list-style-type: none"> • Are more than 64 I/O units connected? • Are more than 128 bytes of I/O data used? • Has the I/O configuration changed since the I/O configuration table was registered?
	Green	The Slice bus operates normally	N/A

1. The TS LED is lit for 2 seconds.

7.7.5 MECHATROLINK-II initialization errors

If the GRT1-ML2 configuration contains non-supported SmartSlice I/O Units or SmartSlice I/O Units configured to consume a non-standard amount of I/O data, the MECHATROLINK-II connection to the GRT1-ML2 is refused. If an attempt to connect to the unit is made with the command

MECHATROLINK(unit, 0), the controller responds with the following message in the terminal interface window:

```
INVALID MECHATROLINK MASTER CONFIG FOR SERVO PERIOD:  
INVALID SLICE CONFIGURATION
```

No input or output of the SmartSlice I/O Units connected is mapped into the Trajexia I/O space.

7.8 TJ1-FL02

7.8.1 System errors

Indication	Problem	Solution
All LEDs are off	The power is off.	Turn the power on.
	The TJ1-FL02 is defective.	Replace the TJ1-FL02.
RUN LED is on, A EN or B EN LED is off	The axis for which EN LED is off is not enabled.	Enable the axis: perform WDOG=ON and/or AXIS_ENABLE on the axis.
RUN LED is on, A EN or B EN LED flashes	There is an axis error for the axis for which EN LED flashes.	The TJ1-MC__ indicates the number of the axis with an axis error. Remove the cause of the axis error, and clear the axis error or restart the system.

A GRT1-ML2 timing

This appendix describes the I/O timing issues for the communication between the TJ1-MC__, the GRT1-ML2 and the SmartSlice I/O Units. The information in this section is useful for planning operations that require strict control of the I/O timing.

In this section, the following is assumed:

- All required slaves participate in the communication.
- The TJ1-MC__ and the GRT-ML2 have no error indications.
- The I/O configuration is properly registered.



Note

To register the I/O configuration, use the REGS dipswitch. See the Trajexia Hardware Reference Manual.



Note

If the I/O configuration is not properly registered, the system can operate, but the data exchange is delayed.

- All filter functions in the SmartSlice I/O Units are disabled.

A.1 Timing concepts

A.1.1 Refresh cycles

There are two refresh cycles involved in the timing issues:

- The refresh cycle between the TJ1-MC__ and the GRT1-ML2
- The refresh cycle between the GRT1-ML2 and the SmartSlice I/O Units.

These refresh cycles are independent, they are not synchronized. Therefore a small delay in the communication between the TJ1-MC__ and the SmartSlice I/O Units occurs. The maximum duration of this delay is the longest refresh cycle time. This delay is “quasi-random”, and it is not possible to compensate it. Applications that require more precisely timed I/O must use the onboard I/O of the TJ1-MC__.

A.1.2 Paging

The maximum amount of data that can be transferred in one servo period with the MECHATROLINK-II protocol is 27 bytes. This is called a page. If the GRT1-ML2 transfers more than 27 bytes of input and/or output data, the data is divided into multiple pages. These pages are transferred in multiple servo periods. The transferred I/O data is only used when all pages are transferred.

The contribution of the individual slices to the I/O data size is described in section 2-2-2 of the GRT1 Series SmartSlice I/O Units Operation Manual (W455).



Note

If the number of input pages and the number of output pages are different, the refresh cycle of the input data and the refresh cycle of the output data are also different.


To display the number of pages used, execute the command **MECHATROLINK(unit,38,station,vr)**. This command reads the paging data and stores it in the VR array: first the number of input pages, and then the number of output pages. If **vr** equals -1, the paging data is printed to the Command Line Terminal interface.



Note

A system with at most 6 slices typically produces less than 27 bytes of I/O data, in which case the number of pages is 1.

fig. 1



A.2 Examples

The following time variable and other variable definitions are used:

Variable	Definition
T_{ON}	The ON or OFF delay of the SmartSlice I/O Unit.
T_{OFF}	See the GRT1 Series SmartSlice I/O Units Operation Manual (W455) for more information on input delay times of input units and output delay times of output units.
$T_{ON/OFF}$	Note: T_{ON} is the ON delay, T_{OFF} is the OFF delay, $T_{ON/OFF}$ is both the ON delay and the OFF delay.
T_{SERVO}	The Trajexia servo period Typically 1ms See the BASIC command SERVO_PERIOD in the Trajexia Programming Manual (I52E).
T_{SL}	The refresh cycle of the SmartSlice I/O Units, which is the communication time of the SmartSlice bus. $T_{SL} = 0.66$ + number of input words of SmartSlice Input Units that use words $\times 0.022$ + number of input bits of SmartSlice Input Units that use bits $\times 0.009$ + number of output words of SmartSlice Output Units that use words $\times 0.008$ + number of output bits of SmartSlice Output Units that use bits $\times 0.001$ ms
T_{CU}	The data processing and synchronisation time of the SmartSlice I/O Units.
PDsize	The Process Data size in bytes, which is the number of bytes needed to transfer all input or output data.
Pages	The number of pages used to transfer all data. The minimum is 1.
T_{ML}	The total MECHATROLINK-II communication time for all data. T_{ML} equals Pages $\times T_{SERVO}$.
T_{SYNC}	The servo interval synchronisation time of the Trajexia program.

Variable	Definition
T_{in}	The input response time: the time between these 2 events: <ul style="list-style-type: none"> • The SmartSlice Input Unit receives an input signal. • This signal is available to the TJ1-MC__ for processing. $T_{in} = T_{ON/OFF} + T_{SL} + T_{CUin} + T_{MLin} + T_{SERVO}$, where: <ul style="list-style-type: none"> • $0.1 \text{ ms} \leq T_{CUin} \leq 0.1 + \text{MAX}(T_{SL}, T_{MLin}) \text{ ms}$ • $T_{MLin} = \text{Pages}_{in} \times T_{SERVO}$ • $\text{Pages}_{in} = (\text{PDsize}_{in} + 2) / 27^1$, rounded up to the nearest integer
T_{out}	The output response time: the time between these events: <ul style="list-style-type: none"> • The TJ1-MC__ sets an output signal. • This signal is available to the SmartSlice Output Unit. $T_{out} = T_{SYNC} + T_{MLout} + T_{CUout} + T_{SL} + T_{ON/OFF}$, where: <ul style="list-style-type: none"> • $\pm 0 \leq T_{SYNC} \leq T_{SERVO}$ • $T_{MLout} = \text{Pages}_{out} \times T_{SERVO}$ • $\text{Pages}_{out} = \text{PDsize}_{out} / 27$, rounded up to the nearest integer • $0.1 \text{ ms} \leq T_{CUout} \leq 0.1 + T_{SL} \text{ ms}$


1. Because the GRT1-ML2 produces 2 bytes of input data (the GRT1-ML2 status word), 2 is added to PDsize_{in} .

The following SmartSlice I/O Units, which are used in the examples, have the following ON/OFF delays:

SmartSlice I/O Unit	$T_{ON/OFF}$
GRT1-ID4	$0 \text{ ms} \leq T_{ON/OFF} \leq 1.5 \text{ ms}$
GRT1-OD4	$0 \text{ ms} \leq T_{ON} \leq 0.5 \text{ ms}$
	$0 \text{ ms} \leq T_{OFF} \leq 1.5 \text{ ms}$
GRT1-AD2	$0 \text{ ms} \leq T_{ON/OFF} \leq 2 \text{ ms}$
GRT1-DA2	$0 \text{ ms} \leq T_{ON/OFF} \leq 2 \text{ ms}$

Furthermore, $T_{SERVO} = 1 \text{ ms}$.

fig. 2



A.2.1 Example 1

Setup of the SmartSlice I/O system: GRT1-ID4 – GRT1-OD4.

$$T_{SL} = 0.66 + 4 \times 0.009 + 4 \times 0.001 = 0.7 \text{ ms}$$

GRT1-ID4 input response time

$$(T_{in} = T_{ON/OFF} + T_{SL} + T_{CUin} + T_{MLin} + T_{SERVO})$$

$$0 + 0.7 + 0.1 + 1 + 1 = 2.8 \text{ ms} \leq T_{in} \leq 1.5 + 0.7 + 1.1 + 1 + 1 = 5.3 \text{ ms}$$

GRT1-OD4 output response time

$$T_{out} = T_{SYNC} + T_{MLout} + T_{CU} + T_{SL} + T_{ON/OFF}$$

$$0 + 1 + 0.1 + 0.7 + 0 = 1.8 \text{ ms} \leq T_{out} \leq 1 + 1 + 0.8 + 0.7 + 1.5 = 5.0 \text{ ms}$$

A.2.2 Example 2

Setup of the SmartSlice I/O system: GRT1-OD4 – GRT1-ID4 – GRT1-OD8 – GRT1-ID8 – GRT1-OD8 – GRT1-ID8 – GRT1-OD8 – GRT1-ID8 – GRT1-OD8 – GRT1-ID8 – GRT1-OD4 – GRT1-DA2 – GRT1-AD2 – GRT1-DA2 – GRT1-DA2 – GRT1-DA2 – GRT1-ID4 – GRT1-ID4

Inputs	Bits	Words	Data size ¹
4 × ID4	4		2 Bytes (Filled up to 1 word)
4 × ID8		4	8 Bytes
1 × AD2		2	4 Bytes
2 × ID4	8		1 Byte
TOTAL	12	6	15 Bytes (15 + 2) / 27, rounded up = 1 Page

1. For the contribution of the individual slices to the I/O data size, see section 2-2-2 of the GRT1 Series SmartSlice I/O Units Operation Manual (W455).

Outputs	Bits	Words	Data size
1 × OD4	4		2 Bytes (Filled up to 1 word)
4 × OD8		4	8 Bytes
1 × OD4	4		2 Bytes (Filled up to 1 word)
4 × DA2		8	16 Byte
TOTAL	8	12	28 Bytes 28 / 27, rounded up = 2 Pages

$$T_{SL} = 0.66 + 6 \times 0.022 + 12 \times 0.009 + 12 \times 0.008 + 8 \times 0.001 = 1.004 \text{ ms}$$

GRT1-ID4 input response time

$$(T_{in} = T_{ON/OFF} + T_{SL} + T_{CUin} + T_{MLin} + T_{SERVO})$$

$$0 + 1.004 + 0.1 + 1 + 1 = 3.104 \text{ ms} \leq T_{in} \leq 1.5 + 1.004 + 1.104 + 1 + 1 = 5.608 \text{ ms}$$

GRT1-AD2 input response time

$$(T_{in} = T_{ON/OFF} + T_{SL} + T_{CUin} + T_{MLin} + T_{SERVO})$$

$$0 + 1.004 + 0.1 + 1 + 1 = 3.104 \text{ ms} \leq T_{in} \leq 2.0 + 1.004 + 1.104 + 1 + 1 = 6.108 \text{ ms}$$

GRT1-OD4 output response time

$$(T_{out} = T_{SYNC} + T_{MLout} + T_{CU} + T_{SL} + T_{ON/OFF})$$

$$0 + 2.0 + 0.1 + 1.004 + 0 = 3.104 \text{ ms} \leq T_{out} \leq 1.0 + 2.0 + 1.104 + 1.004 + 1.5 = 6.608 \text{ ms}$$

GRT1-DA2 output response time

$$(T_{out} = T_{SYNC} + T_{MLout} + T_{CU} + T_{SL} + T_{ON/OFF})$$

$$0 + 2.0 + 0.1 + 1.004 + 2 = 5.104 \text{ ms} \leq T_{out} \leq 1.0 + 2.0 + 1.104 + 1.004 + 2 = 7.108 \text{ ms}$$

A

Application creation	251
Application window	254

B

Bag feeder program example	356
BASIC	
Data structures	24
Mathematical specifications	26
Variables	24
BASIC commands	31
BASIC programming	23
BASIC programs	28
Battery	367

C

CAM table example	359
CANopen	
Communication set-up	230
Communication status	232
Errors	369
Interface	230
Caution, safety	16
Command	
Axis	31
Communication	34
I/O	34
Program	35
Program control	36
System	36
Task	38
Command line interface	28
Constants	34
Correction example	363

D

DEVICENET

Communication set-up	225
Communication status	229
Errors	369
Interface	224

E

Errors

Axis	365
Configuration	367
TJ1-MC_	365
Unit	366
Ethernet protocol	204
Example	
Bag feeder program	356
CAM table	359
Correction program	363
Flying shear program	360
Gain settings	287
Homing	312
Initialization program	349
Origin search	312
Position mode	293
Position on a grid	354
Position with product detection	353
Registration	319
Servo Driver characteristics	309
Setting units	296
Shell program	336
Single axis program	352
Speed mode	288
Startup program	283
Tracing and monitoring	327

F

FINS slave protocol	208
Flexible axis	
Errors	373
Flying shear example	360
Function	
I/O	34
Mathematical	35
System	36

G

Gain example	287
GRT1-ML2	
errors	370
I/O mapping	234
timing	374

H

Hardware overview	21
Homing example	312
Host Link	
Basic commands	211
Master protocol	211
Slave protocol	216

I

Icons	255
Initialization example	349
Installation of software	242
Intelligent drives	266
Interface	
CANopen	230
DEVICENET	224
Ethernet	204
MECHATROLINK-II	233

PROFIBUS	219
Serial	211
Interface overview	204
IO status	274
J	
Jog	275
M	
MECHATROLINK	
Protocol	233
MECHATROLINK-II	
Errors	370
Menu	
Controller	258
Help	282
Options	279
Program	262
Project	256
Tools	264
Windows	282
Menu descriptions	256
ModbusTCP protocol	210
Modifier	
Slot	36
Motion execution	27
Multitasking	22
N	
Network connection	248
O	
Operand	35
Mathematical	35
Origin search example	312
Oscilloscope	269

P

Parameter

Axis	32
Communication	34
I/O	34
Slot	36
System	37
Task	38

PC

Connection	247
Direct connection	205
Remote connection	207
Specification	241
Start Trajexia Tools	248
Position mode example	293
Position on a grid example	354
Position with product detection example	353

PROFIBUS

Communication set-up	219
Communication status	224
Errors	368
Interface	219
Program file compare	252
Programming tool	241
Project compare	252

Protocol

CANopen	230
DEVICENET	224
FINS client	210
FINS slave	208
GRT1-ML2	234
Host Link master	211
Host Link slave	216
MECHATROLINK-II	233

ModbusTCP	210
PROFIBUS	219
Trajexia Tools	208
User-defined	218
Protocols overview	204
R	
Registration example	319
S	
Safety, operating environment	17
Safety, unit assembly	20
Serial interface	211
Servo Driver characteristics example	309
Shell example	336
Single axis example	352
SmartSlice	
I/O mapping	234
Speed mode example	288
Startup example	283
STARTUP program	
Modify	266
System overview	21
T	
Table viewer	277
Tracing and monitoring example	327
Trajexia compare	252
Trajexia Tools protocol	208
U	
Units example	296
User-defined protocol	218
V	
VR editor	277

Revision history

A manual revision code shows as a suffix to the catalogue number on the front cover of the manual.

Revision code	Date	Revised content
01	August 2006	Original
02	October 2006	DeviceNet update
03	May 2007	Updated with TJ1-MC04 and TJ1-ML04. Improved BASIC commands, programming examples and tips.
04	June 2008	Added illustrations and examples to BASIC commands. Added the BASIC commands ALL , BACKLASH , BACKLASH_DIST , CAN_CORT , INVERTER_COMMAND (function 8), READ_OP , SPEED_SIGN . Updated with TJ1-CORT, ModbusTCP, Slice I/O mapping via the GRT1-ML2, Sigma-V Servo Driver I/O mapping and Inverter-as-axis functionality via MECHATROLINK-II.



OMRON EUROPE B.V. Wegalaan 67-69, NL-2132 JD, Hoofddorp, The Netherlands. Tel: +31 (0) 23 568 13 00 Fax: +31 (0) 23 568 13 88 www.omron-industrial.com

Austria
Tel: +43 (0) 2236 377 800
www.omron.at

Belgium
Tel: +32 (0) 2 466 24 80
www.omron.be

Czech Republic
Tel: +420 234 602 602
www.omron-industrial.cz

Denmark
Tel: +45 43 44 00 11
www.omron.dk

Finland
Tel: +358 (0) 207 464 200
www.omron.fi

France
Tel: +33 (0) 1 56 63 70 00
www.omron.fr

Germany
Tel: +49 (0) 2173 680 00
www.omron.de

Hungary
Tel: +36 1 399 30 50
www.omron.hu

Italy
Tel: +39 02 326 81
www.omron.it

Middle East & Africa
Tel: +31 (0) 23 568 11 00
www.omron-industrial.com

Netherlands
Tel: +31 (0) 23 568 11 00
www.omron.nl

Norway
Tel: +47 (0) 22 65 75 00
www.omron.no

Poland
Tel: +48 (0) 22 645 78 60
www.omron.pl

Portugal
Tel: +351 21 942 94 00
www.omron.pt

Russia
Tel: +7 495 648 94 50
www.omron-industrial.ru

Spain
Tel: +34 913 777 900
www.omron.es

Sweden
Tel: +46 (0) 8 632 35 00
www.omron.se

Switzerland
Tel: +41 (0) 41 748 13 13
www.omron.ch

Turkey
Tel: +90 216 474 00 40
www.omron.com.tr

United Kingdom
Tel: +44 (0) 870 752 08 61
www.omron.co.uk

Authorised Distributor:

Note:

Although we do strive for perfection, Omron Europe BV and/or its subsidiary and affiliated companies do not warrant or make any representations regarding the correctness or completeness of information described in this catalogue. Product information in this catalogue is provided 'as is' without warranty of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability, fitness for a particular purpose, or non-infringement. In a jurisdiction where the exclusion of implied warranties is not valid, the exclusion shall be deemed to be replaced by such valid exclusion, which most closely matches the intent and purpose of the original exclusion. Omron Europe BV and/or its subsidiary and affiliated companies reserve the right to make any changes to the products, their specifications, data at its sole discretion at any time without prior notice. The material contained in this catalogue may be out of date and Omron Europe BV and/or its subsidiary and affiliated companies make no commitment to update such material.